




# F71-01





























































铝拉丝土豪金系列  
Aluminum wire drawing tuhao gold series



The panel structure is stylish and eye-catching, making the home instantly radiant;  
The whole body is injection molded from imported PC material, which adds quality to taste;  
The product itself is sturdy, anti-impact, anti-oxidation, and wear-resistant;  
The socket protection door ensures home safety.

# F71-01 铝拉丝土豪金系列

Aluminum wire drawing tuhao gold series

 <p><b>F71-01-0001</b> 小板16A一位开关单控 16A 1 gang 1 way switch ¥:48.00 小板16A一位开关双控 16A 1 gang 2 way switch ¥:52.00 小板16A一位开关多控 16A 1 gang more way switch ¥:88.00</p>	 <p><b>F71-01-0011</b> 小板16A拨动二位开关单控 2 gang 1 way toggle switch ¥:158.00 小板16A拨动二位开关双控 2 gang 2 way toggle switch ¥:170.00</p>	 <p><b>F71-01-0021</b> 二位轻触开关 2 gang 1 way tact switch 强电 /Strong electricity ¥:500.00 弱电 /Weak electricity ¥:350.00</p>	 <p><b>F71-01-0031</b> 16A三极插座 16A 3 pole socket ¥:58.00</p>	 <p><b>F71-01-0041</b> 10A二极插座 10A 2 pole socket ¥:55.00</p>	 <p><b>F71-01-0051</b> 小板16A意大利、德式插座 Italy+German socket ¥:105.00</p>
 <p><b>F71-01-0002</b> 小板16A二位开关单控 16A 1 gang 1 way switch ¥:62.00 小板16A二位开关双控 16A 1 gang 2 way switch ¥:68.00 小板16A二位开关多控 16A 1 gang more way switch ¥:120.00</p>	 <p><b>F71-01-0012</b> 小板16A拨动三位开关单控 3 gang 1 way toggle switch ¥:178.00 小板16A拨动三位开关双控 3 gang 2 way toggle switch ¥:196.00</p>	 <p><b>F71-01-0022</b> 三位轻触开关 3 gang 1 way tact switch 强电 /Strong electricity ¥:550.00 弱电 /Weak electricity ¥:400.00</p>	 <p><b>F71-01-0032</b> 10A二、三极五孔插座 10A 5 pole socket ¥:49.00</p>	 <p><b>F71-01-0042</b> 10A二极插座 10A Double 2 pole socket ¥:63.00</p>	 <p><b>F71-01-0052</b> 小板16A法式插座带二位USB 2 USB with German socket ¥:203.00</p>
 <p><b>F71-01-0003</b> 小板16A一位开关单控 16A 3 gang 1 way switch ¥:75.00 小板16A三位开关双控 16A 3 gang 2 way switch ¥:84.00</p>	 <p><b>F71-01-0013</b> 小板16A拨动四位开关单控 4 gang 1 way toggle switch ¥:198.00 小板16A拨动四位开关双控 4 gang 2 way toggle switch ¥:222.00</p>	 <p><b>F71-01-0023</b> 四位轻触开关 4 gang 1 way tact switch 强电 /Strong electricity ¥:600.00 弱电 /Weak electricity ¥:450.00</p>	 <p><b>F71-01-0033</b> 错位二、三极插座 10A Two or three pole socket ¥:61.00</p>	 <p><b>F71-01-0043</b> 小板10A一位开关带二极插座 1 gang switch and 2 pole socket ¥:61.00</p>	 <p><b>F71-01-0053</b> 小板16A法式插座带二位USB 2 USB with French socket ¥:203.00</p>
 <p><b>F71-01-0004</b> 小板16A四位开关单控 16A 4 gang 1 way switch ¥:88.00 小板16A四位开关双控 16A 4 gang 2 way switch ¥:100.00</p>	 <p><b>F71-01-0014</b> 一位轻触开关 1 gang 1 way tact switch 强电 /Strong electricity ¥:450.00 弱电 /Weak electricity ¥:300.00</p>	 <p><b>F71-01-0024</b> 一位轻触开关 1 gang 1 way tact switch 强电 /Strong electricity ¥:500.00 弱电 /Weak electricity ¥:300.00</p>	 <p><b>F71-01-0034</b> 二、三极插座 10A 2 pole socket ¥:66.00</p>	 <p><b>F71-01-0044</b> 小板10A一位开关带二极插座 1 gang switch and 4 pole socket ¥:71.00</p>	 <p><b>F71-01-0054</b> 小板16A法式插座+USB/Type-c Small board 16A German socket + USB / type-c ¥:330.00</p>
 <p><b>F71-01-0005</b> 小板16A二位开关多控 16A 3 gang 3 way switch ¥:88.00</p>	 <p><b>F71-01-0015</b> 二位轻触开关 2 gang 1 way tact switch 强电 /Strong electricity ¥:500.00 弱电 /Weak electricity ¥:350.00</p>	 <p><b>F71-01-0025</b> 二位轻触开关 2 gang 1 way tact switch 强电 /Strong electricity ¥:500.00 弱电 /Weak electricity ¥:350.00</p>	 <p><b>F71-01-0035</b> 小板16A多功能三极插座 16A 3 pin multi-function socket ¥:58.00</p>	 <p><b>F71-01-0045</b> 小板13A方角插座 13A square corner socket ¥:61.00</p>	 <p><b>F71-01-0055</b> 小板16A法式插座+USB/Type-c Small board 16A French socket + USB / type-c ¥:330.00</p>
 <p><b>F71-01-0006</b> 门铃开关 gating switch ¥:68.00</p>	 <p><b>F71-01-0016</b> 三位轻触开关 3 gang 1 way tact switch 强电 /Strong electricity ¥:500.00 弱电 /Weak electricity ¥:400.00</p>	 <p><b>F71-01-0026</b> 三位轻触开关 3 gang 1 way tact switch 强电 /Strong electricity ¥:550.00 弱电 /Weak electricity ¥:400.00</p>	 <p><b>F71-01-0036</b> 小板13A二、三极多功能插座 5 pin multi-function socket ¥:65.00</p>	 <p><b>F71-01-0046</b> 小板15A圆角插座 15A 3 round pins socket ¥:85.00</p>	 <p><b>F71-01-0056</b> 小板15A美式插座 15A THAI socket ¥:61.00</p>
 <p><b>F71-01-0007</b> 英式门铃开关 British gating switch ¥:68.00</p>	 <p><b>F71-01-0017</b> 一位轻触开关 1 gang 1 way tact switch 强电 /Strong electricity ¥:450.00 弱电 /Weak electricity ¥:300.00</p>	 <p><b>F71-01-0027</b> 四位轻触开关 4 gang 1 way tact switch 强电 /Strong electricity ¥:600.00 弱电 /Weak electricity ¥:450.00</p>	 <p><b>F71-01-0037</b> 小板13A错位多功能二、三极插座 Dislocation multi 5 pin multi-function socket ¥:95.00</p>	 <p><b>F71-01-0047</b> 小板16A德式插座 German socket ¥:71.00</p>	 <p><b>F71-01-0057</b> 小板15A美式插座 15A triode flat American standard socket ¥:65.00</p>
 <p><b>F71-01-0008</b> 门铃开关 doorbell switch ¥:68.00</p>	 <p><b>F71-01-0018</b> 二位轻触开关 2 gang 1 way tact switch 强电 /Strong electricity ¥:500.00 弱电 /Weak electricity ¥:350.00</p>	 <p><b>F71-01-0028</b> 小板20A双极开关带指示灯 20A switch with indicator light ¥:148.00 小板45A双极开关带指示灯 45A switch with indicator light ¥:168.00</p>	 <p><b>F71-01-0038</b> 一开单控带16A二、三极插座 16A 3 pole socket ¥:71.00 一开双控带16A二、三极插座 16A 3 pole socket ¥:74.00</p>	 <p><b>F71-01-0048</b> 小板16A法式插座 French socket ¥:71.00</p>	 <p><b>F71-01-0058</b> 小板错位六孔插座 Dislocation Thai 6 pin socket ¥:61.00</p>
 <p><b>F71-01-0009</b> 百叶窗升降开关 louwer window lifter switch ¥:83.00</p>	 <p><b>F71-01-0019</b> 三位轻触开关 3 gang 1 way tact switch 强电 /Strong electricity ¥:550.00 弱电 /Weak electricity ¥:400.00</p>	 <p><b>F71-01-0029</b> 45A开关带指示灯 45A switch with indicator light ¥:158.00</p>	 <p><b>F71-01-0039</b> 一开单控带10A二、三极插座 10A 5 pole socket ¥:68.00 一开双控带10A二、三极插座 10A 5 pole socket ¥:71.00</p>	 <p><b>F71-01-0049</b> 小板16A俄式插座 Russian socket ¥:71.00</p>	 <p><b>F71-01-0059</b> 小板一位开关带16A多功能插座 1 gang switch and 13A square pin socket ¥:78.00</p>
 <p><b>F71-01-0010</b> 小板16A拨动一位开关单控 1 gang 1 way toggle switch ¥:138.00 小板16A拨动一位开关双控 1 gang 2 way toggle switch ¥:148.00</p>	 <p><b>F71-01-0020</b> 一位轻触开关 1 gang 1 way tact switch 强电 /Strong electricity ¥:450.00 弱电 /Weak electricity ¥:300.00</p>	 <p><b>F71-01-0030</b> 小板16A带复位门铃开关 Shutter reset switch ¥:142.00</p>	 <p><b>F71-01-0040</b> 二位单控开关带二、三极插座 2 gang 1 way switch and 5 pole socket ¥:87.00 二位双控开关带二、三极插座 2 gang 2 way switch and 5 pole socket ¥:93.00</p>	 <p><b>F71-01-0050</b> 小板16A以色列插座 Israel socket ¥:105.00</p>	 <p><b>F71-01-0060</b> 一位开关带13A方角插座 1 gang switch and 13A square pin socket ¥:71.00</p>

# F71-01 铝拉丝土豪金系列

Aluminum wire drawing tuhao gold series



**F71-01-0061**  
小板一位开关带15A圆孔插座  
1 gang switch and 15A 3 round pin socket  
¥:76.00



**F71-01-0062**  
一位开关带13A方角插座  
(带指示灯)  
1 gang switch and 13A square pin socket with indicator light  
¥:73.00



**F71-01-0063**  
一位开关带15A圆孔插座  
(带指示灯)  
1 gang switch and 15A 3 round pins socket with indicator light  
¥:78.00



**F71-01-0064**  
小板一位开关带16A多功能插座  
(带指示灯)  
1 gang switch and 16A 3 pin MF socket with light  
¥:80.00



**F71-01-0065**  
小板一位开关带13A多功能五孔插座  
(带指示灯)  
1 gang switch and 5 pin multi-function socket with indicator light  
¥:88.00



**F71-01-0066**  
小板16A一位开关带德式插座  
1 gang German socket  
¥:110.00



**F71-01-0067**  
小板16A一位开关带法式插座  
1 gang French socket  
¥:110.00



**F71-01-0068**  
小板16A德式插座带防水  
German socket and Waterproof belt  
¥:105.00



**F71-01-0069**  
小板16A法式插座带防水  
French socket and Waterproof belt  
¥:105.00



**F71-01-0070**  
二位USB带13A方角插座  
2 USB with 13A square corner socket  
¥:163.00



**F71-01-0071**  
小板二位USB带13A多功能插座(横)  
2 USB with 3 pin multi-purpose socket  
¥:205.00



**F71-01-0072**  
15A美式三极扁插带USB+type-c  
American Standard + USB / type-c  
¥:310.00



**F71-01-0073**  
15A美式多功能插座带USB+type-c  
15A Thai + USB / type-c  
¥:310.00



**F71-01-0074**  
小板二位USB带13A多功能插座  
(带保护门)  
2 USB with 13A multi-purpose socket with flip cover  
¥:203.00



**F71-01-0075**  
小板二位USB带13A方角插座  
(带保护门)  
2 USB with 13A square corner socket with flip cover  
¥:203.00



**F71-01-0076**  
小板一位开关带二位USB带13A  
多功能插座(带指示灯)  
1 gang switch with 2USB and 13A MF socket  
¥:173.00



**F71-01-0077**  
小板一位开关带二位USB带13A  
方角插座(带指示灯)  
2 USB with 13A square corner socket with flip cover  
¥:173.00



**F71-01-0078**  
小板13A多功能带Type-C+USB  
13A multifunction with type-C + USB  
¥:310.00



**F71-01-0079**  
小板13A方角插座带Type-C+USB  
13A square angle band type-C + USB  
¥:310.00



**F71-01-0080**  
小板二位USB带13A多功能插座(竖)  
2 USB with three very multi-purpose socket  
¥:183.00



**F71-01-0081**  
小板二位USB带13A方角插座(竖)  
2 USB with 13A square corner socket  
¥:163.00



**F71-01-0082**  
小板二位USB带13A多功能插座  
带小开关(竖)  
2 USB with 13A 3 pin MF socket with little switch  
¥:173.00



**F71-01-0083**  
小板二位USB带13A方角插座  
带小开关(竖)  
2 USB with 13A square corner socket with little switch  
¥:173.00



**F71-01-0084**  
15A美式三极扁插带二位USB  
American Standard + 2USB  
¥:185.00



**F71-01-0085**  
15A美式多功能插座带二位USB  
15A Thai MF socket + 2USB  
¥:185.00



**F71-01-0086**  
二位USB带二 三极插座  
2 USB and 5 pin socket  
¥:163.00



**F71-01-0087**  
二位USB带二 三极插座  
(带开关)  
2 USB and 5 pin socket with switch  
¥:173.00



**F71-01-0088**  
小板10A二三极插座带Type-C+USB  
10A two and three pole socket with type-C + USB  
¥:310.00



**F71-01-0089**  
小板一位开关带13A多功能五孔  
插座带USB  
1 gang switch and 5 pin multi-function socket with USB and indicator light  
¥:240.00



**F71-01-0090**  
小板13A二位USB带多功能五孔插座  
2 USB with 5 pin multi-function socket  
¥:163.00



**F71-01-0091**  
小板13A二位USB带多功能五孔插座  
带开关  
2 USB with 5 pin multi-function socket with switch  
¥:173.00



**F71-01-0092**  
小板13A多功能五孔插座带Type-C+USB  
13A multi-functional five hole plug type type-C + USB  
¥:310.00



**F71-01-0093**  
小板一位电视插座  
TV socket  
¥:65.00



**F71-01-0094**  
小板双电视插座  
Two TV socket  
¥:91.00



**F71-01-0095**  
小板一位电话插座 ¥:65.00  
telephone socket ¥:78.00  
小板一位电脑插座  
computer socket ¥:118.00  
小板一位电脑插座(超六类)  
computer socket(6)



**F71-01-0096**  
小板双电话插座 ¥:91.00  
Two telephone socket ¥:121.00  
小板双电脑插座  
Two computer socket ¥:181.00  
小板双电脑插座(超六类)  
Two computer socket(6)



**F71-01-0097**  
小板电话电脑插座 ¥:101.00  
telephone+computer socket ¥:141.00  
小板电话电脑插座(超六类)  
telephone+computer socket(6)



**F71-01-0098**  
电视电话插座 ¥:91.00  
TV + telephone socket ¥:101.00  
电视电脑插座  
TV + computer socket ¥:141.00  
电视电脑插座(超六类)  
TV + computer socket(6)



**F71-01-0099**  
小板一位电话带USB插座  
TEL + USB socket ¥:238.00  
小板一位电话带USB插座  
computer + USB socket ¥:238.00  
小板一位电脑带USB插座(超六类)  
computer + USB socket(6) ¥:288.00



**F71-01-0100**  
小板一位TV+FM  
TV and FM  
¥:190.00



**F71-01-0101**  
小板一位卫星插座  
Satellite socket  
¥:78.00



**F71-01-0102**  
小板二位卫星插座  
Double satellite socket  
¥:121.00



**F71-01-0103**  
小板卫星+电视插座  
Satellite and TV socket  
¥:65.00



**F71-01-0104**  
小板卫星带电话插座 ¥:101.00  
Satellite and telephone socket ¥:111.00  
小板卫星带电脑插座  
Satellite and computer socket ¥:151.00  
小板卫星带电脑插座(超六类)  
Satellite and computer socket(6)



**F71-01-0105**  
小板二极插座带电视插座  
2 pin socket with TV  
¥:151.00



**F71-01-0106**  
小板二极插座带电话插座 ¥:270.00  
2 pin socket with telephone ¥:270.00  
小板二极插座带电脑插座  
2 pin socket with computer ¥:310.00  
小板二极插座带电脑(超六类)  
2 pin socket with computer



**F71-01-0107**  
小板一位光纤插座  
Optical fiber socket  
¥:128.00



**F71-01-0108**  
二位USB插座  
Double USB socket  
¥:203.00



**F71-01-0109**  
小板单联音插座  
Single audio socket  
¥:133.00



**F71-01-0110**  
小板双联音插座  
Double audio socket  
¥:183.00



**F71-01-0111**  
触摸延迟开关(节能)  
Touch delay switch (energy saving)  
¥:113.00



**F71-01-0112**  
声光控延迟开关(节能)  
Sound-light controlled delay switch (energy saving)  
¥:113.00



**F71-01-0113**  
红外线人体感应开关  
Human body induction  
¥:248.00



**F71-01-0114**  
凹型地脚灯(亮光/暖光)  
The footlights  
¥:153.00



**F71-01-0115**  
凹型红外线人体感应地脚灯  
(亮光/暖光)  
The human body induction footlights  
¥:268.00



**F71-01-0116**  
平面地脚灯(亮光/暖光)  
Footlights  
¥:153.00



**F71-01-0117**  
叮咚门铃  
Ding dong doorbell  
¥:175.80



**F71-01-0118**  
机械式40A插卡取电 ¥:263.00  
Mechanical card for electricity  
感应式低频40A插卡取电 ¥:453.00  
Low frequency induction card for electricity  
感应式高频40A插卡取电 ¥:553.00  
High frequency induction card for electricity































































**F71-01-0119**  
紧急呼叫开关  
Emergency call switch  
¥:163.00



**F71-01-0120**  
请勿打扰清理门铃开关  
(按钮式)  
Do not disturb, please namely cleaning  
please + later doorbell "button"  
¥:191.00





























































# F71-01 铝拉丝土豪金系列

Aluminum wire drawing tuhao gold series

 <p><b>F71-01-0121</b> 请勿打扰门铃开关 (按键式) Do not disturb + doorbell "button" ¥:323.00</p>	 <p><b>F71-01-0131</b> 13A开关带保险丝(带指示灯) 13A switch with fuse(with light) ¥:163.00</p>	 <p><b>F71-01-0141</b> AV + 3.5音频 AV +3.5 ¥:243.00</p>	 <p><b>F71-01-0151</b> 空白面板 Blank plate ¥:16.90</p>	 <p><b>F71-01-0161</b> 小板147型二位15A美标扁插座 147 Double 15A triode flat American standard socket ¥:138.00</p>	 <p><b>F71-01-0171</b> 147 二位开关带二位16A多功能插座(带指示灯) 147 low switch and double 16A MF socket with light ¥:168.00</p>
 <p><b>F71-01-0122</b> 请勿打扰请即清理门铃开关 (按键式) Do not disturb please namely cleaning please "button" ¥:323.00</p>	 <p><b>F71-01-0132</b> 20A出线柱 20A outgoing post ¥:82.50</p>	 <p><b>F71-01-0142</b> VGA + AV音频接口 VGA + AV audio interface ¥:243.00</p>	 <p><b>F71-01-0152</b> 小板147型二位开关单控 147 2 gang 1 way switch ¥:96.00 小板147型二位开关双控 147 2 gang 2 way switch ¥:242.00</p>	 <p><b>F71-01-0162</b> 小板147型二位15A欧式三极插座 147 Double 15A triode flat American standard socket ¥:138.00</p>	 <p><b>F71-01-0172</b> 147 二位开关二位13A方角+二位USB (小板) 147 low switch and double 13A square corner socket+2USB ¥:283.00</p>
 <p><b>F71-01-0123</b> 智能音乐控制开关 Intelligent music control switch ¥:2630.00</p>	 <p><b>F71-01-0133</b> 剃须插座 Shaving socket ¥:430.00</p>	 <p><b>F71-01-0143</b> HDMI + AV音频接口 HDMI + AV audio interface ¥:127.50</p>	 <p><b>F71-01-0153</b> 小板147型16A三位开关单控 147 3 gang 1 way switch ¥:110.00 小板147型16A三位开关双控 147 3 gang 2 way switch ¥:120.00</p>	 <p><b>F71-01-0163</b> 147 二位13A方角插座 147 Double 13A square corner ¥:123.00</p>	 <p><b>F71-01-0173</b> 147 二位开关二位13A多功能+二位USB (小板) 147 low switch and double 13A MF socket+2USB ¥:283.00</p>
 <p><b>F71-01-0124</b> 小板温度控制调节器 Temperature control switch ¥:710.00</p>	 <p><b>F71-01-0134</b> USB+电脑插座+无线路由 USB + computer socket+wireless router ¥:803.00</p>	 <p><b>F71-01-0144</b> 二分之一AV音频+卫星 Half AV audio interface+Satellite socket ¥:270.00</p>	 <p><b>F71-01-0154</b> 小板147型四位开关单控 147 4 gang 1 way switch ¥:276.00 小板147型四位开关双控 147 4 gang 2 way switch ¥:288.00</p>	 <p><b>F71-01-0164</b> 147 二位15A圆孔插座 147 Double 15A 3 round pins socket ¥:310.00</p>	 <p><b>F71-01-0174</b> 147 二位开关二位13A方角+USB/Type-c 147 two switch double 13A square band lamp+USB/Type-c ¥:500.00</p>
 <p><b>F71-01-0125</b> 温度控制调节开关 Temperature control switch ¥:663.00</p>	 <p><b>F71-01-0135</b> 蓝牙+3.5音频+二位USB+HDMI Bluetooth audio + 3.5 + 2USB + HDMI ¥:5203.00</p>	 <p><b>F71-01-0145</b> 二分之一AV音频+USB+3.5音频 Half AV audio interface+USB+3.5 ¥:270.00</p>	 <p><b>F71-01-0155</b> 小板147型16A五位开关单控 147 5 gang 1 way switch ¥:157.00 小板147型16A五位开关双控 147 5 gang 2 way switch ¥:152.00</p>	 <p><b>F71-01-0165</b> 小板147型二位13A槽位多功能五孔插座 147 2 gang Double 13A dislocation multi-function 5 hole socket ¥:332.00</p>	 <p><b>F71-01-0175</b> 147 二位开关二位13A多功能带灯+USB/Type-c 147 two switch double 13A MF band lamp+USB/Type-c ¥:500.00</p>
 <p><b>F71-01-0126</b> 调音开关(消防) Tuning switch ( fire) ¥:163.00</p>	 <p><b>F71-01-0136</b> HDMI ¥:243.00</p>	 <p><b>F71-01-0146</b> 二分之一VGA+TV Half VGA-TV ¥:270.00</p>	 <p><b>F71-01-0156</b> 小板147型六位开关单控 147 6 gang 1 way switch ¥:311.00 小板147型六位开关双控 147 6 gang 2 way switch ¥:334.00</p>	 <p><b>F71-01-0166</b> 147 二位10A二极插座 147 Double position two and three pole socket ¥:250.00</p>	 <p><b>F71-01-0176</b> 147 二位开关带二位15A圆角插座(带指示灯) 147 low switch and double 15A 3 round pins socket with indicator light ¥:156.00</p>
 <p><b>F71-01-0127</b> 调光开关300W Dimming 300W ¥:133.00 调光开关600W Dimming 600W ¥:173.00 调光开关1000W Dimming 1000W ¥:213.00</p>	 <p><b>F71-01-0137</b> USB+TYPE-C ¥:310.00</p>	 <p><b>F71-01-0147</b> 二分之一VGA+电脑插座 Half VGA-computer socket ¥:270.00</p>	 <p><b>F71-01-0157</b> 小板147型16A七位开关单控 147 7 gang 1 way switch ¥:163.00 小板147型16A七位开关双控 147 7 gang 2 way switch ¥:184.00</p>	 <p><b>F71-01-0167</b> 147 二开带二位16A多功能插座 Two switch and double 16A MF 3 pin socket ¥:168.00</p>	 <p><b>F71-01-0177</b> 小板147型二位开关带二位13A方角插座(带指示灯) 147 two switch double 13A square angle socket (with indicator light) ¥:146.00</p>
 <p><b>F71-01-0128</b> 调速开关300W Speed 300W ¥:133.00 调速开关600W Speed 600W ¥:173.00 调速开关1000W Speed 1000W ¥:213.00</p>	 <p><b>F71-01-0138</b> HDMI+USB ¥:243.00</p>	 <p><b>F71-01-0148</b> 二分之一VGA+USB Half VGA+USB ¥:270.00</p>	 <p><b>F71-01-0158</b> 小板147型16A八位开关单控 147 8 gang 1 way switch ¥:157.00 小板147型16A八位开关双控 147 8 gang 2 way switch ¥:200.00</p>	 <p><b>F71-01-0168</b> 二位开关带二位13A方角插座 Two switch and double 13A square corner socket ¥:168.00</p>	 <p><b>F71-01-0178</b> 147型二位剃须插座 147 two shaving socket ¥:563.00</p>
 <p><b>F71-01-0129</b> 一位开关带调光开关 1 gang with dimmer switch ¥:165.00</p>	 <p><b>F71-01-0139</b> HDMI+USB+3.5音频 hemi+USB+3.5 ¥:243.00</p>	 <p><b>F71-01-0149</b> 二分之一VGA+HDMI Half VGA+HDMI ¥:270.00</p>	 <p><b>F71-01-0159</b> 147 二位16A多功能三极插座 147 Double 16A MF socket ¥:123.00</p>	 <p><b>F71-01-0169</b> 147 二位开关带二位五孔多功能插座(带指示灯) 147 low switch and double 5 pin multi-course socket with indicator light ¥:310.00</p>	 <p><b>F71-01-0179</b> 147 45A开关+一位开关16A多功能带指示灯 (组合厨房开关) 147 kitchen switch ¥:263.00</p>
 <p><b>F71-01-0130</b> 一位开关带调速开关 1 gang with speed switch ¥:165.00</p>	 <p><b>F71-01-0140</b> VGA+USB+3.5音频 VGA+USB+3.5 ¥:243.00</p>	 <p><b>F71-01-0150</b> 45A出线柱 45A Outlet ¥:200.00</p>	 <p><b>F71-01-0160</b> 147 二位13A多功能五孔插座 147 Double 5 pin multi-function socket ¥:138.00</p>	 <p><b>F71-01-0170</b> 147 二位开关带二位13A方角插座(带指示灯) 147 low switch and double 13A square corner socket with indicator light ¥:168.00</p>	 <p><b>F71-01-0180</b> 147 45A开关+一位开关13A方角插座(带指示灯) 147 kitchen switch ¥:263.00</p>

# F71-01 铝拉丝土豪金系列

Aluminum wire drawing tuhao gold series

 <p><b>F71-01-0181</b> 147 45A开关+一位开关13A方插带灯(带指示灯) 147 Kitchen switch ¥:263.00</p>	 <p><b>F71-01-0191</b> 147 四位USB插座 147 4 USB socket ¥:413.00</p>	 <p><b>F71-01-0201</b> 147型二位开关带二位13A多功能带四位USB(带指示灯) 147 two switch and double 13A MF +4USB socket (with indicator light) ¥:480.00</p>	 <p><b>F71-01-0211</b> 147型二位13A多功能带四位USB带小开关 147 double 13A 3pin multi-function socket + 4USB with small switch ¥:480.00</p>	 <p><b>F71-01-0221</b> 147型二位一开单控带二位10A二极插座 147 type 2 gang 1 way switch double 10A 5 pole socket ¥:320.00</p>	 <p><b>F71-01-0231</b> 147二位开关二位16A法式插座带指示灯+USB/type-C(小板) 147 double switch double French socket +USB/type-c with light ¥:480.00</p>
 <p><b>F71-01-0182</b> 147 45A双极开关带指示灯 147 type 45A bipolar switch ¥:183.00</p>	 <p><b>F71-01-0192</b> 147 二位多功能插座+4USB 147 2-bit multi-function socket + 4USB ¥:326.00</p>	 <p><b>F71-01-0202</b> 147型二开带二位13A方插带四位USB 147 type two switch two position 13A square inserting band 4 USB ¥:480.00</p>	 <p><b>F71-01-0212</b> 147型二位13A方插带四位USB带小开关 147 double 13A square plug with 4USB with small switch ¥:480.00</p>	 <p><b>F71-01-0222</b> 147型二位10A二极插座带USB+type-C 147 type double 10A 5 pole socket USB + type-C ¥:720.00</p>	 <p><b>F71-01-0232</b> 147二位开关二位16A德式插座带指示灯 147 two switch double 16A German socket with light ¥:190.00</p>
 <p><b>F71-01-0183</b> 147 16A二位法式插座 147 Double German socket ¥:148.00</p>	 <p><b>F71-01-0193</b> 147 二位13A方插带四位USB 147 two bit 13A square socket +4USB ¥:326.00</p>	 <p><b>F71-01-0203</b> 147型二位13A方插带四位USB 147 type double position 13A square inserting band 4 USB ¥:335.00</p>	 <p><b>F71-01-0213</b> 147 二位一开16A多功能带指示灯 147 two switch and double 16A MF 3 pin socket with neon ¥:326.00</p>	 <p><b>F71-01-0223</b> 147型二位多功能五孔插座带USB+type-C 147 type double 5 pin multi-functional USB + type-c ¥:720.00</p>	 <p><b>F71-01-0233</b> 147二位开关二位16A法式插座带指示灯 147 two switch double 16A French socket with light ¥:190.00</p>
 <p><b>F71-01-0184</b> 147 16A二位法式插座 147 Double French socket ¥:148.00</p>	 <p><b>F71-01-0194</b> 147 一位13A方角插座+二位USB 13A square corner socket and two USB ¥:271.00</p>	 <p><b>F71-01-0204</b> 147 二位13A多功能+4USB(带盖板) 147 double 13A multi-function + 4USB (with cover plate) ¥:380.00</p>	 <p><b>F71-01-0214</b> 147 二位13A多功能带四位USB带指示灯 147 type MF 3 pin socket and 4USB with neon ¥:350.00</p>	 <p><b>F71-01-0224</b> 147型13A多功能双USB带五位孔插座 147 type 13A multi-functional socket with 5 pin ¥:389.00</p>	 <p><b>F71-01-0234</b> 147二位开关二位16A德式插座带指示灯+二位USB(小板) 147 two switch double 16A German socket + 2usb with light ¥:440.00</p>
 <p><b>F71-01-0185</b> 147 16A二位德式插座 147 Double German socket ¥:148.00</p>	 <p><b>F71-01-0195</b> 147 一位16A多功能插座+二位USB插座 16A MF 3 pin socket and 2USB socket ¥:271.00</p>	 <p><b>F71-01-0205</b> 147型一位13A方插带四位USB(带盖板) 147 double 13A square inserting +4USB socket ¥:380.00</p>	 <p><b>F71-01-0215</b> 147 16A多功能方五孔插座 147 16A MF 3 pin + 5 pin MF socket ¥:295.00</p>	 <p><b>F71-01-0225</b> 147型二位电脑插座带二位USB插座 147 type double computer with 2USB socket ¥:460.00</p>	 <p><b>F71-01-0235</b> 147二位开关二位16A法式插座带指示灯+二位USB(小板) 147 two switch double 16A French socket + 2USB with light ¥:460.00</p>
 <p><b>F71-01-0186</b> 147 16A二位法式插座 147 Double French socket ¥:148.00</p>	 <p><b>F71-01-0196</b> 147型二位开关带二位多功能五孔插座带双USB 147 1 gang 1 way switch with 5 pin MF socket +2USB ¥:310.00</p>	 <p><b>F71-01-0206</b> 147一开单开关带多功能五孔插座 147 1 gang 1 way switch with 5 pin MF socket ¥:274.00</p>	 <p><b>F71-01-0216</b> 147 10A二二二二极插座 10A 8 pole socket ¥:310.00</p>	 <p><b>F71-01-0226</b> 147型二位电话带二位电脑插座 147 double telephone with double computer socket ¥:390.00</p>	 <p><b>F71-01-0236</b> 147二位10A二极五孔插座+USB+小开关(带指示灯) 147 double 10A 5 pin socket +4USB two little switch with indicator light ¥:390.00</p>
 <p><b>F71-01-0187</b> 147型二位带USB+type-C(模块) 147 double German + USB / type-C (module) ¥:510.00</p>	 <p><b>F71-01-0197</b> 147 二位开关带二位13A多功能五孔插座+2USB(带指示灯) 147 two switch and double 13A MF 5 pin socket + 2USB (with indicator) ¥:460.00</p>	 <p><b>F71-01-0207</b> 147一开单控带13A方角插座+双USB 147 1 gang 1 way socket with 13A square Angle socket +2USB ¥:348.00</p>	 <p><b>F71-01-0217</b> 147二开单控开关带16A多功能插座 147 two switch single control 16A MF 3 pin socket ¥:276.00</p>	 <p><b>F71-01-0227</b> 147型二位电脑插座带16A多功能插座 147 double computer with 16A MF pin socket ¥:333.00</p>	 <p><b>F71-01-0237</b> 147二位一开13A多功能五孔插座带指示灯 147 two switch and double 13A MF 5 pin socket (with indicator) ¥:330.00</p>
 <p><b>F71-01-0188</b> 147型二位带USB+type-C(模块) 147 double French + USB / type-C (module) ¥:510.00</p>	 <p><b>F71-01-0198</b> 147 二位13A多功能五孔插座+四位USB 147 13A double 5 pin MF socket+4USB ¥:330.00</p>	 <p><b>F71-01-0208</b> 147型一开单控带15A德式插座 147 one open single control with 15A The German socket ¥:283.00</p>	 <p><b>F71-01-0218</b> 147型二位单控带13A方角插座 147 type double open single control socket with 13A square angle ¥:276.00</p>	 <p><b>F71-01-0228</b> 147型二位16A德式插座带防水 147 two position 16A German socket with waterproof ¥:276.00</p>	 <p><b>F71-01-0238</b> 147二位双16A法式插座带四位USB(带指示灯) 147 double 16A German socket 4 USB (with indicator) ¥:400.00</p>
 <p><b>F71-01-0189</b> 147型17A德式+二位USB(小板连体) 147 double German with 2USB (small plate) ¥:410.00</p>	 <p><b>F71-01-0199</b> 147 二位开关二位13A多功能五孔插座+四位USB 147 one open single control and MF 5 pin + 4USB socket ¥:460.00</p>	 <p><b>F71-01-0209</b> 147型一开单控带多功能五孔+双USB插座 147 one open single control and MF 5 pin + 2USB socket ¥:348.00</p>	 <p><b>F71-01-0219</b> 147型10A二极带10A二极插座 147 10A two pole with 10A two pole socket ¥:280.00</p>	 <p><b>F71-01-0229</b> 147型二位16A法式插座带防水 147 two position 16A French socket with waterproof ¥:350.00</p>	 <p><b>F71-01-0239</b> 147二位双16A法式插座带四位USB(带指示灯) 147 double 16A French socket 4 USB (with indicator) ¥:400.00</p>
 <p><b>F71-01-0190</b> 147 二位16A法式+2USB(小板连体) 147 Double French with 2USB (small plate) ¥:410.00</p>	 <p><b>F71-01-0200</b> 147型二位开关带二位多功能五孔插座+四位USB+type-C 147 Two switch and double 5 pin MF socket +USB/type-c ¥:500.00</p>	 <p><b>F71-01-0210</b> 147型二位10A二极五孔带四位USB插座+四位USB+type-C 147 double 10A 5 pin socket + 4 USB three pole socket + indicator light ¥:440.00</p>	 <p><b>F71-01-0220</b> 147型二位一开单控带二位16A二极插座 147 type double 1 way switch double 16A three pole socket ¥:320.00</p>	 <p><b>F71-01-0230</b> 147型二位开关二位16A法式插座带指示灯+USB/type-C(小板) 147 double switch double German socket +USB/type-c with light ¥:500.00</p>	 <p><b>F71-01-0240</b> 147型二位空白面板 147 Blank plate ¥:28.00</p>



# F71-02

铝拉丝时尚银系列

Aluminum wire drawing fashion silver series



铝拉丝面板  
Aluminum  
brushed panel



多模块多选择  
Multiple modules  
and multiple options



阻燃材料  
Flameresistant  
material



荧光格点  
Fluorescent  
lattice

**50+**  
耐用50年  
Durable  
50 years



超大银触点  
Extra large  
silver contacts



安全保护门  
Safety door



轻触开关  
Touch sensor  
switch

# F71-02 喷漆时尚银系列

Spray paint fashion silver series

**F71-02-0001**  
 小板16A一位开关单控  
 16A 1 gang 1 way switch ¥:48.00  
 小板16A一位开关双控  
 16A 1 gang 2 way switch ¥:52.00  
 小板16A一位开关多控  
 16A 1 gang more way switch ¥:88.00

**F71-02-0002**  
 小板16A二位开关单控  
 16A 1 gang 1 way switch ¥:62.00  
 小板16A二位开关双控  
 16A 1 gang 2 way switch ¥:68.00  
 小板16A二位开关多控  
 16A 1 gang more way switch ¥:120.00

**F71-02-0003**  
 小板16A三位开关单控  
 16A 3 gang 1 way switch ¥:75.00  
 小板16A三位开关双控  
 16A 3 gang 2 way switch ¥:84.00

**F71-02-0004**  
 小板16A四位开关单控  
 16A 4 gang 1 way switch ¥:88.00  
 小板16A四位开关双控  
 16A 4 gang 2 way switch ¥:100.00

**F71-02-0005**  
 小板16A二位开关多控  
 16A 3 gang 3 way switch ¥:88.00

**F71-02-0006**  
 门铃开关  
 gating switch ¥:68.00

**F71-02-0007**  
 英式门控开关  
 British gating switch ¥:68.00

**F71-02-0008**  
 门铃开关  
 doorbell switch ¥:68.00

**F71-02-0009**  
 百叶窗升降开关  
 louver window lifter switch ¥:83.00

**F71-02-0010**  
 小板16A一位开关单控  
 1 gang 1 way toggle switch ¥:138.00  
 小板16A一位开关双控  
 1 gang 2 way toggle switch ¥:148.00

**F71-02-0011**  
 小板16A一位开关单控  
 2 gang 1 way toggle switch ¥:158.00  
 小板16A一位开关双控  
 2 gang 2 way toggle switch ¥:170.00

**F71-02-0012**  
 小板16A一位开关单控  
 3 gang 1 way toggle switch ¥:178.00  
 小板16A一位开关双控  
 3 gang 2 way toggle switch ¥:196.00

**F71-02-0013**  
 小板16A一位开关单控  
 4 gang 1 way toggle switch ¥:198.00  
 小板16A一位开关双控  
 4 gang 2 way toggle switch ¥:222.00

**F71-02-0014**  
 一位轻触开关  
 1 gang 1 way tact switch  
 强电 /Strong electricity ¥:450.00  
 弱电 /Weak electricity ¥:300.00

**F71-02-0015**  
 二位轻触开关  
 2 gang 1 way tact switch  
 强电 /Strong electricity ¥:500.00  
 弱电 /Weak electricity ¥:350.00

**F71-02-0016**  
 三位轻触开关  
 3 gang 1 way tact switch  
 强电 /Strong electricity ¥:550.00  
 弱电 /Weak electricity ¥:400.00

**F71-02-0017**  
 一位轻触开关  
 1 gang 1 way tact switch  
 强电 /Strong electricity ¥:450.00  
 弱电 /Weak electricity ¥:300.00

**F71-02-0018**  
 二位轻触开关  
 2 gang 1 way tact switch  
 强电 /Strong electricity ¥:500.00  
 弱电 /Weak electricity ¥:350.00

**F71-02-0019**  
 三位轻触开关  
 3 gang 1 way tact switch  
 强电 /Strong electricity ¥:550.00  
 弱电 /Weak electricity ¥:400.00

**F71-02-0020**  
 一位轻触开关  
 1 gang 1 way tact switch  
 强电 /Strong electricity ¥:450.00  
 弱电 /Weak electricity ¥:300.00

**F71-02-0021**  
 二位轻触开关  
 2 gang 1 way tact switch  
 强电 /Strong electricity ¥:500.00  
 弱电 /Weak electricity ¥:350.00

**F71-02-0022**  
 三位轻触开关  
 3 gang 1 way tact switch  
 强电 /Strong electricity ¥:550.00  
 弱电 /Weak electricity ¥:400.00

**F71-02-0023**  
 四位轻触开关  
 4 gang 1 way tact switch  
 强电 /Strong electricity ¥:600.00  
 弱电 /Weak electricity ¥:450.00

**F71-02-0024**  
 一位轻触开关  
 1 gang 1 way tact switch  
 强电 /Strong electricity ¥:450.00  
 弱电 /Weak electricity ¥:300.00

**F71-02-0025**  
 二位轻触开关  
 2 gang 1 way tact switch  
 强电 /Strong electricity ¥:500.00  
 弱电 /Weak electricity ¥:350.00

**F71-02-0026**  
 三位轻触开关  
 3 gang 1 way tact switch  
 强电 /Strong electricity ¥:550.00  
 弱电 /Weak electricity ¥:400.00

**F71-02-0027**  
 四位轻触开关  
 4 gang 1 way tact switch  
 强电 /Strong electricity ¥:600.00  
 弱电 /Weak electricity ¥:450.00

**F71-02-0028**  
 小板20A双极开关带指示灯  
 20A switch with indicator light ¥:148.00  
 小板45A双极开关带指示灯  
 45A switch with indicator light ¥:168.00

**F71-02-0029**  
 45A开关带指示灯  
 45A switch with indicator light ¥:158.00

**F71-02-0030**  
 小板16A带灯门复位开关  
 Shutter reset switch ¥:142.00

**F71-02-0031**  
 16A三极插座  
 16A 3 pole socket ¥:58.00

**F71-02-0032**  
 10A二三级五孔插座  
 10A 5 pole socket ¥:49.00

**F71-02-0033**  
 二位二极插座  
 10A Two or three pole socket ¥:61.00

**F71-02-0034**  
 二二三级插座  
 10A 3 pole socket ¥:66.00

**F71-02-0035**  
 小板16A多功能三极插座  
 16A 3 pin multi-function socket ¥:58.00

**F71-02-0036**  
 小板13A二三级多功能插座  
 5 pin multi-function socket ¥:65.00

**F71-02-0037**  
 小板13A错位多功能二三级插座  
 Dislocation multi 5 pin multi-function socket ¥:95.00

**F71-02-0038**  
 一开单控带16A二三级插座 ¥:71.00  
 16A 3 pole socket  
 一开双控带16A二三级插座 ¥:74.00  
 16A 3 pole socket

**F71-02-0039**  
 一开单控带10A二三级插座 ¥:68.00  
 10A 5 pole socket  
 一开双控带10A二三级插座 ¥:71.00  
 10A 5 pole socket

**F71-02-0040**  
 二位单控开关带二三级插座 ¥:87.00  
 2 gang 1 way switch and 5 pole socket  
 二位双控开关带二三级插座 ¥:93.00  
 2 gang 2 way switch and 5 pole socket

**F71-02-0041**  
 10A二极插座  
 10A 2 pole socket ¥:55.00

**F71-02-0042**  
 10A二极插座  
 10A Double 2 pole socket ¥:63.00

**F71-02-0043**  
 小板10A一位开关带二极插座  
 1 gang switch and 2 pole socket ¥:61.00

**F71-02-0044**  
 小板10A一位开关带二极插座  
 1 gang switch and 4 pole socket ¥:71.00

**F71-02-0045**  
 小板13A方角插座  
 13A square corner socket ¥:61.00

**F71-02-0046**  
 小板15A圆角插座  
 15A 3 round pins socket ¥:85.00

**F71-02-0047**  
 小板16A德式插座  
 German socket ¥:71.00

**F71-02-0048**  
 小板16A法式插座  
 French socket ¥:71.00

**F71-02-0049**  
 小板16A俄式插座  
 Russian socket ¥:71.00

**F71-02-0050**  
 小板16A以色列插座  
 Israel socket ¥:105.00

**F71-02-0051**  
 小板16A意大利、德式插座  
 Italy+German socket ¥:105.00

**F71-02-0052**  
 小板16A法式插座带二位USB  
 2 USB with German socket ¥:203.00

**F71-02-0053**  
 小板16A法式插座带二位USB  
 2 USB with French socket ¥:203.00

**F71-02-0054**  
 小板16A德式插座+USB/Type-c  
 Small board 16A German socket + USB / type-c ¥:330.00

**F71-02-0055**  
 小板16A法式插座+USB/Type-c  
 Small board 16A French socket + USB / type-c ¥:330.00

**F71-02-0056**  
 小板15A泰式插座  
 15A Thai socket ¥:61.00

**F71-02-0057**  
 小板15A美式插座  
 15A triode flat American standard socket ¥:65.00

**F71-02-0058**  
 小板错位泰式六孔插座  
 Dislocation Thai 6 pin socket ¥:61.00

**F71-02-0059**  
 小板一位开关带16A多功能插座  
 1 gang switch and 13A square pin socket ¥:78.00

**F71-02-0060**  
 一位开关带13A方角插座  
 1 gang switch and 13A square pin socket ¥:71.00

# F71-02 喷漆时尚银系列

Spray paint fashion silver series



**F71-02-0061**  
小板一位开关带15A圆孔插座  
1 gang switch and 15A 3 round pin socket  
¥:76.00



**F71-02-0062**  
一位开关带13A方角插座  
(带指示灯)  
1 gang switch and 13A square pin socket with indicator light  
¥:73.00



**F71-02-0063**  
一位开关带15A方角插座  
(带指示灯)  
1 gang switch and 15A 3 round pins socket with indicator light  
¥:78.00



**F71-02-0064**  
小板一位开关带16A多功能插座  
(带指示灯)  
1 gang switch and 16A 3 pin MF socket with light  
¥:80.00



**F71-02-0065**  
小板一位开关带13A多功能五孔插座  
(带指示灯)  
1 gang switch and 5 pin multi-function socket with indicator light  
¥:88.00



**F71-02-0066**  
小板16A一位开关带德式插座  
1 gang German socket  
¥:110.00



**F71-02-0067**  
小板16A一位开关带法式插座  
1 gang French socket  
¥:110.00



**F71-02-0068**  
小板16A德式插座带防水  
German socket and Waterproof belt  
¥:105.00



**F71-02-0069**  
小板16A法式插座带防水  
French socket and Waterproof belt  
¥:105.00



**F71-02-0070**  
二位USB带13A方角插座  
2 USB with 13A square corner socket  
¥:163.00



**F71-02-0071**  
小板二位USB带13A多功能插座(横)  
2 USB with 3 pin multi-purpose socket  
¥:205.00



**F71-02-0072**  
15A美式三极扁插带USB+type-c  
American Standard + USB / type-c  
¥:310.00



**F71-02-0073**  
15A泰式多功能插座带USB+type-c  
15A Thai + USB / type-c  
¥:310.00



**F71-02-0074**  
小板二位USB带13A多功能插座  
(带保护门)  
2 USB with 13A multi-purpose socket with flip cover  
¥:203.00



**F71-02-0075**  
小板二位USB带13A方角插座  
(带保护门)  
2 USB with 13A square corner socket with flip cover  
¥:203.00



**F71-02-0076**  
小板一位开关带二位USB带13A  
多功能插座(带指示灯)  
1 gang switch with 2USB and 13A MF socket  
¥:173.00



**F71-02-0077**  
小板一位开关带二位USB带13A  
方角插座(带指示灯)  
2 USB with 13A square corner socket with flip cover  
¥:173.00



**F71-02-0078**  
小板13A多功能带Type-c+USB  
13A multifunction with type-c + USB  
¥:310.00



**F71-02-0079**  
小板13A方角带Type-c+USB  
13A square angle band type-c + USB  
¥:310.00



**F71-02-0080**  
小板二位USB带13A多功能插座(竖)  
2 USB with three very multi-purpose socket  
¥:183.00



**F71-02-0081**  
小板二位USB带13A方角插座(竖)  
2 USB with 13A square corner socket  
¥:163.00



**F71-02-0082**  
小板二位USB带13A多功能插座  
带小开关(竖)  
2 USB with 13A 3 pin MF socket with little switch  
¥:173.00



**F71-02-0083**  
小板二位USB带13A方角插座  
带小开关(竖)  
2 USB with 13A square corner socket with little switch  
¥:173.00



**F71-02-0084**  
15A美式三极扁插带二位USB  
American Standard + 2USB  
¥:185.00



**F71-02-0085**  
15A泰式多功能插座带二位USB  
15A Thai MF socket + 2USB  
¥:185.00



**F71-02-0086**  
二位USB带二 三极插座  
2 USB and 5 pin socket  
¥:163.00



**F71-02-0087**  
二位USB带二 三极插座  
(带开关)  
2 USB and 5 pin socket with switch  
¥:173.00



**F71-02-0088**  
小板10A二三极插座带Type-c+USB  
10A two and three pole socket with type-c + USB  
¥:310.00



**F71-02-0089**  
小板一位开关带13A多功能五孔  
插座带USB  
1 gang switch and 5 pin multi-function socket with USB and indicator light  
¥:240.00



**F71-02-0090**  
小板二位USB带13A多功能五孔插座  
2 USB with 5 pin multi-function socket  
¥:163.00



**F71-02-0091**  
小板13A二位USB带多功能五孔插座  
带开关  
2 USB with 5 pin multi-function socket with switch  
¥:173.00



**F71-02-0092**  
小板13A多功能五孔插座带Type-c+USB  
13A multi-functional five hole plug type type-c + USB  
¥:310.00



**F71-02-0093**  
小板一位电视插座  
TV socket  
¥:65.00



**F71-02-0094**  
小板双电视插座  
Two TV socket  
¥:91.00



**F71-02-0095**  
小板一位电话插座 ¥:65.00  
telephone socket  
小板一位电脑插座 ¥:78.00  
computer socket  
小板一位电脑插座(超六类) ¥:118.00  
computer socket(6)



**F71-02-0096**  
小板双电话插座 ¥:91.00  
Two telephone socket  
小板双电脑插座 ¥:121.00  
Two computer socket  
小板双电脑插座(超六类) ¥:181.00  
Two computer socket(6)



**F71-02-0097**  
小板电话电脑插座 ¥:101.00  
telephone+computer socket  
小板电话电脑插座(超六类) ¥:141.00  
telephone+computer socket(6)



**F71-02-0098**  
电视电话插座 ¥:91.00  
TV + telephone socket  
电视电脑插座 ¥:101.00  
TV + computer socket  
电视电脑插座(超六类) ¥:141.00  
TV + computer socket(6)



**F71-02-0099**  
小板一位带USB插座 ¥:238.00  
TEL + USB socket  
小板一位带USB插座 ¥:238.00  
computer + USB socket  
小板一位带USB插座(超六类) ¥:288.00  
computer + USB socket(6)



**F71-02-0100**  
小板一位TV+FM  
TV and FM  
¥:190.00



**F71-02-0101**  
小板一位卫星插座  
Satellite socket  
¥:78.00



**F71-02-0102**  
小板二位卫星插座  
Double satellite socket  
¥:121.00



**F71-02-0103**  
小板卫星+电视插座  
Satellite and TV socket  
¥:101.00



**F71-02-0104**  
小板卫星带电话插座 ¥:101.00  
Satellite and telephone socket  
小板卫星带电脑插座 ¥:111.00  
Satellite and computer socket  
小板卫星带电脑插座(超六类) ¥:151.00  
Satellite and computer socket(6)



**F71-02-0105**  
小板二极插座带电视插座  
2 pin socket with TV  
¥:151.00



**F71-02-0106**  
小板二极插座带电话插座 ¥:270.00  
2 pin socket with telephone  
小板二极插座带电脑插座 ¥:270.00  
2 pin socket with computer  
小板二极插座带电脑(超六类) ¥:310.00  
2 pin socket with computer



**F71-02-0107**  
小板一位光纤插座  
Optical fiber socket  
¥:128.00



**F71-02-0108**  
二位USB插座  
Double USB socket  
¥:203.00



**F71-02-0109**  
小板单联音插座  
Single audio socket  
¥:133.00



**F71-02-0110**  
小板双联音插座  
Double audio socket  
¥:183.00



**F71-02-0111**  
触摸延迟开关(节能)  
Touch delay delay switch  
(energy saving)  
¥:113.00



**F71-02-0112**  
声光控延迟开关(节能)  
Sound-light controlled delay switch  
(energy saving)  
¥:113.00



**F71-02-0113**  
红外线人体感应开关  
Human body induction  
¥:248.00



**F71-02-0114**  
凹型地脚灯(亮光/暖光)  
The footlights  
¥:153.00



**F71-02-0115**  
凹型红外线人体感应地脚灯  
(亮光/暖光)  
The human body induction footlights  
¥:268.00



**F71-02-0116**  
平面地脚灯(亮光/暖光)  
Footlights  
¥:153.00



**F71-02-0117**  
叮咚门铃  
Ding dong doorbell  
¥:175.80



**F71-02-0118**  
机械式40A插卡取电 ¥:263.00  
Mechanical card for electricity  
感应式低频40A插卡取电 ¥:453.00  
Low frequency induction card for electricity  
感应式高频40A插卡取电 ¥:553.00  
High frequency induction card for electricity



**F71-02-0119**  
紧急呼叫开关  
Emergency call switch  
¥:163.00



**F71-02-0120**  
请勿打扰请清理门铃开关  
(按钮式)  
Do not disturb, please namely cleaning  
please + later doorbell "button"  
¥:191.00



# F71-02 喷漆时尚银系列

Spray paint fashion silver series

**F71-02-0121**  
请勿打扰门铃开关 (按钮式)  
Do not disturb + doorbell "button"  
¥:323.00



**F71-02-0122**  
请勿打扰请即清理门铃开关 (按钮式)  
Do not disturb please namely cleaning please "button"  
¥:323.00



**F71-02-0123**  
智能音乐控制开关  
Intelligent music control switch  
¥:2630.00



**F71-02-0124**  
小柜温度控制调节器  
Temperature control switch  
¥:710.00



**F71-02-0125**  
温度控制调节开关  
Temperature control switch  
¥:663.00



**F71-02-0126**  
调音开关(消防)  
Tuning switch ( fire )  
¥:163.00



**F71-02-0127**  
调光开关300W  
Dimming 300W ¥:133.00  
调光开关600W  
Dimming 600W ¥:173.00  
调光开关1000W  
Dimming 1000W ¥:213.00



**F71-02-0128**  
调速开关300W  
Speed 300W ¥:133.00  
调速开关600W  
Speed 600W ¥:173.00  
调速开关1000W  
Speed 1000W ¥:213.00



**F71-02-0129**  
一位开关带调光开关  
1 gang with dimmer switch  
¥:165.00



**F71-02-0130**  
一位开关带调速开关  
1 gang with speed switch  
¥:165.00



**F71-02-0131**  
13A开关带保险丝(带指示灯)  
13A switch with fuse(with light)  
¥:163.00



**F71-02-0132**  
20A出线柱  
20A outgoing post  
¥:82.50



**F71-02-0133**  
剃须插座  
Shaving socket  
¥:430.00



**F71-02-0134**  
USB+电脑插座+无线路由  
USB + computer socket+wireless router  
¥:803.00



**F71-02-0135**  
蓝牙+3.5音频+二位USB+HDMI  
Bluetooth audio + 3.5 + 2USB + HDMI  
¥:5203.00



**F71-02-0136**  
HDMI  
¥:243.00



**F71-02-0137**  
USB+TYPE-C  
¥:310.00



**F71-02-0138**  
HDMI+USB  
¥:243.00




**F71-02-0139**  
HDMI+USB+3.5音频  
hemi+USB+3.5  
¥:243.00



**F71-02-0140**  
VGA+USB+3.5音频  
VGA+USB + 3.5  
¥:243.00



**F71-02-0141**  
AV+3.5音频  
AV+3.5  
¥:243.00



**F71-02-0142**  
VGA+AV音频接口  
VGA+AV audio interface  
¥:243.00



**F71-02-0143**  
HDMI+AV音频接口  
HDMI + AV audio interface  
¥:127.50



**F71-02-0144**  
二分之一AV音频+卫星  
Half AV audio interface+Satellite socket  
¥:270.00



**F71-02-0145**  
二分之一AV音频+USB+3.5音频  
Half AV audio interface+USB+3.5  
¥:270.00



**F71-02-0146**  
二分之一VGA+TV  
Half VGA-TV  
¥:270.00



**F71-02-0147**  
二分之一VGA+电脑插座  
Half VGA-computer socket  
¥:270.00



**F71-02-0148**  
二分之一VGA+USB  
Half VGA+USB  
¥:270.00



**F71-02-0149**  
二分之一VGA+HDMI  
Half VGA+HDMI  
¥:270.00



**F71-02-0150**  
45A出线柱  
45A Outlet  
¥:200.00



**F71-02-0151**  
空白面板  
Blank plate  
¥:16.90



**F71-02-0152**  
小柜147型二位开关单控  
147 2 gang 1 way switch  
¥:96.00  
小柜147型二位开关双控  
147 2 gang 2 way switch  
¥:242.00



**F71-02-0153**  
小柜147型16A三位开关单控  
147 3 gang 1 way switch  
¥:110.00  
小柜147型16A三位开关双控  
147 3 gang 2 way switch  
¥:120.00




**F71-02-0154**  
小柜147型四位开关单控  
147 4 gang 1 way switch  
¥:276.00  
小柜147型四位开关双控  
147 4 gang 2 way switch  
¥:288.00




**F71-02-0155**  
小柜147型16A五位开关单控  
147 5 gang 1 way switch  
¥:137.00  
小柜147型16A五位开关双控  
147 5 gang 2 way switch  
¥:152.00



**F71-02-0156**  
小柜147型六位开关单控  
147 6 gang 1 way switch  
¥:311.00  
小柜147型六位开关双控  
147 6 gang 2 way switch  
¥:334.00



**F71-02-0157**  
小柜147型16A七位开关单控  
147 7 gang 1 way switch  
¥:163.00  
小柜147型16A七位开关双控  
147 7 gang 2 way switch  
¥:184.00



**F71-02-0158**  
小柜147型16A八位开关单控  
147 8 gang 1 way switch  
¥:137.00  
小柜147型16A八位开关双控  
147 8 gang 2 way switch  
¥:200.00



**F71-02-0159**  
147二位16A多功能三极插座  
147 Double 16A MF socket  
¥:123.00



**F71-02-0160**  
147二位13A多功能五孔插座  
147 Double 5 pin multi-function socket  
¥:138.00



**F71-02-0161**  
小柜147型二位15A美标扁插座  
147 Double 15A triode flat American standard socket  
¥:138.00



**F71-02-0162**  
小柜147型二位15A欧式三极插座  
147 Double 15A triode flat American standard socket  
¥:138.00



**F71-02-0163**  
147二位13A方角插座  
147 Double 13A square corner  
¥:123.00



**F71-02-0164**  
147二位15A圆孔插座  
147 Double 15A 3 round pins socket  
¥:310.00



**F71-02-0165**  
小柜147型二位13A多功能去孔插座  
147 type Double 13A dislocation multi-function 5 hole socket  
¥:332.00



**F71-02-0166**  
147二位10A二极插座  
147 Double position two and three pole socket  
¥:250.00



**F71-02-0167**  
147二开带二位16A多功能插座  
Two switch and double 16A MF 3 pin socket  
¥:168.00



**F71-02-0168**  
二位开关带二位13A方角插座  
Two switch and double 13A square corner socket  
¥:168.00



**F71-02-0169**  
147二位开关带二位五孔多功能插座(带指示灯)  
147 two switch and double 5 pin multi-purpose socket with indicator light  
¥:310.00




**F71-02-0170**  
147二位开关带二位13A方角插座(带指示灯)  
147 two switch and double 13A square corner socket with indicator light  
¥:168.00




**F71-02-0171**  
147二位开关带二位16A多功能插座(带指示灯)  
147 two switch and double 16A MF socket with light  
¥:168.00



**F71-02-0172**  
147二位开关二位13A方角+二位USB (小板)  
147 two switch and double 13A square corner socket+2USB  
¥:283.00



**F71-02-0173**  
147二位开关二位13A多功能+二位USB (小板)  
147 two switch and double 13A MF socket+2USB  
¥:283.00



**F71-02-0174**  
147二位开关二位13A方角+USB/Type-c  
147 two switch double 13A square MF lamp+USB/Type-c  
¥:500.00



**F71-02-0175**  
147二位开关二位13A多功能带灯+USB/Type-c  
147 two switch double 13A MF lamp+USB/Type-c  
¥:500.00



**F71-02-0176**  
147二位开关带二位15A圆角插座(带指示灯)  
147 two switch and double 15A 3 round pins socket with indicator light  
¥:156.00



**F71-02-0177**  
小柜147型二位开关带二位13A方角插座(带指示灯)  
147 two switch and double 13A square angle socket (with indicator light)  
¥:146.00



**F71-02-0178**  
147型二位剃须插座  
147 two shaving socket  
¥:563.00



**F71-02-0179**  
147 45A开关+一位开关16A方角插座(带指示灯)  
147 kitchen switch  
¥:263.00



**F71-02-0180**  
147 45A开关+一位开关13A方角插座(带指示灯)(组合厨房开关)  
147 kitchen switch  
¥:263.00



# F71-02 喷漆时尚银系列

Spray paint fashion silver series



**F71-02-0181**  
147 45A开关+二位开关13A  
方带指示灯(带指示灯)  
147 Kitchen switch  
¥:263.00



**F71-02-0182**  
147 45A双极开关带指示灯  
147 type 45A bipolar switch  
¥:183.00



**F71-02-0183**  
147 16A二位法式插座  
147 Double German socket  
¥:148.00



**F71-02-0184**  
147 16A二位法式插座  
147 Double French socket  
¥:148.00



**F71-02-0185**  
147 16A二位法式插座  
147 Double German socket  
¥:148.00



**F71-02-0186**  
147 16A二位法式插座  
147 Double French socket  
¥:148.00



**F71-02-0187**  
147 二位带USB+type-c  
(模块)  
147 Double German + USB  
+type-C (module)  
¥:510.00



**F71-02-0188**  
147 二位带USB+type-c  
(模块)  
147 Double French + USB  
+type-C (module)  
¥:510.00



**F71-02-0189**  
二位17A德式+二位USB  
(小板连体)  
147 Double German with 2USB  
¥:410.00



**F71-02-0190**  
147 二位16A法式+2USB  
(小板连体)  
147 Double French with 2USB  
¥:410.00



**F71-02-0191**  
147 四位USB插座  
147 4 USB socket  
¥:413.00



**F71-02-0192**  
147 二位多功能插座+4USB  
147 2-bit multi-function socket  
+4USB  
¥:326.00



**F71-02-0193**  
147 二位13A方插座+4USB  
147 two bit 13A square socket  
+4USB  
¥:326.00



**F71-02-0194**  
147 一位13A方角插座  
+二位USB  
13A square corner  
socket and two USB  
¥:271.00



**F71-02-0195**  
147 一位16A多功能插座  
+二位USB插座  
16A MF 3 pin socket and  
2USB socket  
¥:271.00



**F71-02-0196**  
147 二位开关带二位多功能  
五孔插座带双USB  
147 2 gang 1 way switch with 5 pin  
MF socket+2USB  
¥:310.00



**F71-02-0197**  
147 二位开关带二位13A多功能  
五孔插座+2USB(带指示灯)  
147 two switch and double 13A  
MF 5 pin socket + 2USB  
(with indicator)  
¥:460.00



**F71-02-0198**  
147 二位13A多功能五孔插座  
+四位USB  
147 13A double 5 pin MF  
socket+4USB  
¥:330.00



**F71-02-0199**  
147 二位开关二位13A多功能  
五孔插座+四位USB  
147 one open single control and  
MF 5 pin + 4USB socket  
¥:460.00



**F71-02-0200**  
147 二位开关二位多功能  
五孔插座+USB+type-c  
147 Two switch and double 5 pin  
MF socket+USB+type-c  
¥:500.00



**F71-02-0201**  
147 二位开关二位13A多功能  
带四位USB (带指示灯)  
147 two switch and double 13A MF  
+4USB socket (with indicator light)  
¥:480.00



**F71-02-0202**  
147 二位开关二位13A方带  
四位USB  
147 type two switch two position  
13A square inserting band 4 USB  
¥:480.00



**F71-02-0203**  
147 二位13A方带四位  
四位USB  
147 type double position 13A  
square inserting band 4 USB  
¥:335.00



**F71-02-0204**  
147 二位13A多功能+4USB(带盖板)  
+二位USB  
147 double 13A multi-function + 4USB  
(with cover plate) + 4USB  
¥:380.00



**F71-02-0205**  
147 二位13A方带四位USB  
(带盖板)  
147 double 13A square inserting  
+4USB socket  
¥:380.00



**F71-02-0206**  
147 一开单开关带多功能五孔  
插座  
147 1 gang 1 way switch with 5 pin  
MF socket  
¥:274.00



**F71-02-0207**  
147 一开单控带13A方角  
插座+2USB  
147 1 gang 1 way socket with  
13A square Angle socket +2USB  
¥:348.00



**F71-02-0208**  
147 一开单控带15A德式插座  
147 one open single control with  
15A The German socket  
¥:283.00



**F71-02-0209**  
147 一开单控带多功能五孔  
+双USB插座  
147 one open single control and  
MF 5 pin + 2USB socket  
¥:348.00



**F71-02-0210**  
147 二位二位10A二位五孔带四位  
USB插座+USB+type-c  
147 type 2 gang 10A 5 pin socket +  
4 USB indicator light  
¥:440.00



**F71-02-0211**  
147 二位13A多功能带四位USB  
带小开关  
147 double 13A 3pin multi-function  
socket + 4USB with small switch  
¥:480.00



**F71-02-0212**  
147 二位13A方带四位USB  
带小开关  
147 double 13A square plug with  
4USB with small switch  
¥:480.00



**F71-02-0213**  
147 二位一开16A多功能带指示灯  
3 pin socket with neon  
¥:326.00



**F71-02-0214**  
147 二位13A多功能带四位USB  
(带盖板)  
147 type MF 3 pin socket and 4USB  
with neon  
¥:350.00



**F71-02-0215**  
147 16A多功能一开五孔插座  
147 16A MF 3 pin + 5 pin MF socket  
¥:295.00



**F71-02-0216**  
147 10A二二二二极插座  
10A 8 pole socket  
¥:310.00



**F71-02-0217**  
147 二开单控带16A  
多功能插座  
147 two switch single control  
16A MF 3 pin socket  
¥:276.00




**F71-02-0218**  
147 二开单控带13A方角插座  
147 type double open single control  
socket with 13A square angle  
¥:276.00



**F71-02-0219**  
147 10A二极带10A二极插座  
147 10A two pole with 10A two  
pole socket  
¥:280.00




**F71-02-0220**  
147 二位二位一开单控二位16A  
多功能插座  
147 type 2 gang 1 way switch double  
16A three pole socket  
¥:320.00



**F71-02-0221**  
147 二位一开单控带二位10A  
二极插座  
147 type 2 gang 1 way switch double  
10A 5 pole socket  
¥:320.00



**F71-02-0222**  
147 二位10A二二二极插座带  
USB+type-c  
147 type double 10A 5 pole socket  
USB + type-C  
¥:720.00



**F71-02-0223**  
147 二位多功能五孔插座带  
USB+type-c  
147 type double 5 pin multi-  
functional USB + type-c  
¥:720.00



**F71-02-0224**  
147 13A多功能双USB带五  
孔插座  
147 type 13A multi-functional socket  
with 5 pin multi-functional socket  
¥:389.00



**F71-02-0225**  
147 二位电脑插座带二位  
USB插座  
147 type double computer with  
2USB socket  
¥:460.00



**F71-02-0226**  
147 二位电话带二位电脑  
插座  
147 double telephone with double  
computer socket  
¥:390.00



**F71-02-0227**  
147 二位电脑插座带16A  
多功能插座  
147 double computer with 16A  
MF pin socket  
¥:333.00



**F71-02-0228**  
147 二位16A德式插座带防水  
147 two position 16A German socket  
with waterproof  
¥:350.00



**F71-02-0229**  
147 二位16A法式插座带防水  
147 two position 16A French socket  
with waterproof  
¥:350.00



**F71-02-0230**  
147 二位开关二位16A德式插座  
带指示灯+USB/type-c (小板)  
147 double switch double German  
socket+USB+type-c with light  
¥:500.00



**F71-02-0231**  
147 二位开关二位16A法式插座  
带指示灯+USB/type-c (小板)  
147 double switch double French  
socket+USB+type-c with light  
¥:500.00



**F71-02-0232**  
147 二位开关二位16A德式插座  
(带指示灯)  
147 two switch double 16A German  
socket with light  
¥:190.00



**F71-02-0233**  
147 二位开关二位16A法式插座  
(带指示灯)  
147 two switch double 16A French  
socket with light  
¥:190.00



**F71-02-0234**  
147 二位开关二位16A德式插座  
带指示灯+二位USB (小板)  
147 two switch double 16A German  
socket + 2usb with light  
¥:440.00



**F71-02-0235**  
147 二位开关二位16A法式插座  
带指示灯+二位USB (小板)  
147 two switch double 16A French  
socket + 2USB with light  
¥:440.00



**F71-02-0236**  
147 二位10A二二二极五孔USB  
+小开关 (带指示灯)  
147 double 10A 5 pin socket+4USB  
two little switch with indicator light  
¥:390.00



**F71-02-0237**  
147 二位一开13A多功能五孔  
插座带双USB  
147 two switch and double 13A  
MF 5 pin socket (with indicator)  
¥:330.00




**F71-02-0238**  
147 二位双16A法式插座带  
四位USB (带指示灯)  
147 double 16A German socket  
4 USB (with indicator)  
¥:400.00



**F71-02-0239**  
147 二位双16A法式插座带  
四位USB (带指示灯)  
147 double 16A French socket  
4 USB (with indicator)  
¥:400.00



**F71-02-0240**  
147 二位一位空白面板  
147 blank-gate  
¥:28.00



## F71-05 铝拉丝深空灰系列

Aluminum brushed deep space ash series

### 臻品质 · 匠心设计

层层闪耀，展现典雅气质  
释放品质生活魅力，精致而不失个性  
基于现代生活理念研发而出的系列产品  
以一贯严谨的态度，不断创新

Layers of sparkle, show elegant temperament  
Release the charm of quality life, delicate without losing personality  
A series of products developed based on the concept of modern life  
With a consistent rigorous attitude, continuous innovation



铝拉丝面板  
Aluminum  
brushed panel



多模块多选择  
Multiple modules  
and multiple options



阻燃材料  
Flameresistant  
material



荧光格点  
Fluorescent  
lattice

50<sup>+</sup>

耐用50年  
Durable  
50 years



超大银触点  
Extra large  
silver contacts































































安全保护门  
Safety door



轻触开关  
Touch sensor  
switch

# F71-05 铝拉丝深空灰系列

Aluminum brushed deep space ash series

 <p><b>F71-05-0001</b> 小板16A一位开关单控 16A 1 gang 1 way switch ¥:48.00 小板16A一位开关双控 16A 1 gang 2 way switch ¥:52.00 小板16A一位开关多控 16A 1 gang more way switch ¥:88.00</p>	 <p><b>F71-05-0011</b> 小板16A拨动二位开关单控 2 gang 1 way toggle switch ¥:158.00 小板16A拨动二位开关双控 2 gang 2 way toggle switch ¥:170.00</p>	 <p><b>F71-05-0021</b> 二位轻触开关 2 gang 1 way tact switch 强电 /Strong electricity ¥:500.00 弱电 /Weak electricity ¥:350.00</p>	 <p><b>F71-05-0031</b> 16A三级插座 16A 3 pole socket ¥:58.00</p>	 <p><b>F71-05-0041</b> 10A二级插座 10A 2 pole socket ¥:55.00</p>	 <p><b>F71-05-0051</b> 小板16A意大利、德式插座 Italy+German socket ¥:105.00</p>
 <p><b>F71-05-0002</b> 小板16A二位开关单控 16A 1 gang 1 way switch ¥:62.00 小板16A二位开关双控 16A 1 gang 2 way switch ¥:68.00 小板16A二位开关多控 16A 1 gang more way switch ¥:120.00</p>	 <p><b>F71-05-0012</b> 小板16A拨动三位开关单控 3 gang 1 way toggle switch ¥:178.00 小板16A拨动三位开关双控 3 gang 2 way toggle switch ¥:196.00</p>	 <p><b>F71-05-0022</b> 三位轻触开关 3 gang 1 way tact switch 强电 /Strong electricity ¥:550.00 弱电 /Weak electricity ¥:400.00</p>	 <p><b>F71-05-0032</b> 10A二三极五孔插座 10A 5 pole socket ¥:49.00</p>	 <p><b>F71-05-0042</b> 10A二级插座 10A Double 2 pole socket ¥:63.00</p>	 <p><b>F71-05-0052</b> 小板16A法式插座带二位USB 2 USB with German socket ¥:203.00</p>
 <p><b>F71-05-0003</b> 小板16A三位开关单控 16A 3 gang 1 way switch ¥:75.00 小板16A三位开关双控 16A 3 gang 2 way switch ¥:84.00</p>	 <p><b>F71-05-0013</b> 小板16A拨动四位开关单控 4 gang 1 way toggle switch ¥:198.00 小板16A拨动四位开关双控 4 gang 2 way toggle switch ¥:222.00</p>	 <p><b>F71-05-0023</b> 四位轻触开关 4 gang 1 way tact switch 强电 /Strong electricity ¥:600.00 弱电 /Weak electricity ¥:450.00</p>	 <p><b>F71-05-0033</b> 错位二三极插座 10A Two or three pole socket ¥:61.00</p>	 <p><b>F71-05-0043</b> 小板10A一位开关带二位插座 1 gang switch and 2 pole socket ¥:61.00</p>	 <p><b>F71-05-0053</b> 小板16A法式插座带二位USB 2 USB with French socket ¥:203.00</p>
 <p><b>F71-05-0004</b> 小板16A四位开关单控 16A 4 gang 1 way switch ¥:88.00 小板16A四位开关双控 16A 4 gang 2 way switch ¥:100.00</p>	 <p><b>F71-05-0014</b> 一位轻触开关 1 gang 1 way tact switch 强电 /Strong electricity ¥:450.00 弱电 /Weak electricity ¥:300.00</p>	 <p><b>F71-05-0024</b> 一位轻触开关 1 gang 1 way tact switch 强电 /Strong electricity ¥:450.00 弱电 /Weak electricity ¥:300.00</p>	 <p><b>F71-05-0034</b> 二二三极插座 10A 3 pole socket ¥:66.00</p>	 <p><b>F71-05-0044</b> 小板10A一位开关带二位插座 1 gang switch and 4 pole socket ¥:71.00</p>	 <p><b>F71-05-0054</b> 小板16A法式插座+USB/Type-c Small board 16A German socket + USB / type-c ¥:330.00</p>
 <p><b>F71-05-0005</b> 小板16A二位开关多控 16A 3 gang 3 way switch ¥:88.00</p>	 <p><b>F71-05-0015</b> 二位轻触开关 2 gang 1 way tact switch 强电 /Strong electricity ¥:500.00 弱电 /Weak electricity ¥:350.00</p>	 <p><b>F71-05-0025</b> 二位轻触开关 2 gang 1 way tact switch 强电 /Strong electricity ¥:500.00 弱电 /Weak electricity ¥:350.00</p>	 <p><b>F71-05-0035</b> 小板16A多功能三极插座 16A 3 pin multi-function socket ¥:58.00</p>	 <p><b>F71-05-0045</b> 小板13A方角插座 13A square corner socket ¥:61.00</p>	 <p><b>F71-05-0055</b> 小板16A法式插座+USB/Type-c Small board 16A French socket + USB / type-c ¥:330.00</p>
 <p><b>F71-05-0006</b> 门控开关 gating switch ¥:68.00</p>	 <p><b>F71-05-0016</b> 三位轻触开关 3 gang 1 way tact switch 强电 /Strong electricity ¥:550.00 弱电 /Weak electricity ¥:400.00</p>	 <p><b>F71-05-0026</b> 三位轻触开关 3 gang 1 way tact switch 强电 /Strong electricity ¥:550.00 弱电 /Weak electricity ¥:400.00</p>	 <p><b>F71-05-0036</b> 小板13A二三极多功能插座 5 pin multi-function socket ¥:65.00</p>	 <p><b>F71-05-0046</b> 小板15A圆角插座 15A 3 round pins socket ¥:85.00</p>	 <p><b>F71-05-0056</b> 小板15A美式插座 15A Thai socket ¥:61.00</p>
 <p><b>F71-05-0007</b> 英式门控开关 British gating switch ¥:68.00</p>	 <p><b>F71-05-0017</b> 一位轻触开关 1 gang 1 way tact switch 强电 /Strong electricity ¥:450.00 弱电 /Weak electricity ¥:300.00</p>	 <p><b>F71-05-0027</b> 四位轻触开关 4 gang 1 way tact switch 强电 /Strong electricity ¥:600.00 弱电 /Weak electricity ¥:450.00</p>	 <p><b>F71-05-0037</b> 小板13A错位多功能二三极插座 Dislocation multi 5 pin multi-function socket ¥:95.00</p>	 <p><b>F71-05-0047</b> 小板16A德式插座 German socket ¥:71.00</p>	 <p><b>F71-05-0057</b> 小板15A美式插座 15A triode flat American standard socket ¥:65.00</p>
 <p><b>F71-05-0008</b> 门铃开关 doorbell switch ¥:68.00</p>	 <p><b>F71-05-0018</b> 二位轻触开关 2 gang 1 way tact switch 强电 /Strong electricity ¥:500.00 弱电 /Weak electricity ¥:350.00</p>	 <p><b>F71-05-0028</b> 小板20A双极开关带指示灯 20A switch with indicator light ¥:148.00 小板45A双极开关带指示灯 45A switch with indicator light ¥:168.00</p>	 <p><b>F71-05-0038</b> 一开单控带16A三极插座 ¥:71.00 1gang 1 way switch and 16A 3 pole socket 一开双控带16A三极插座 ¥:74.00 1gang 2 way switch and 16A 3 pole socket</p>	 <p><b>F71-05-0048</b> 小板16A法式插座 French socket ¥:71.00</p>	 <p><b>F71-05-0058</b> 小板错位六孔插座 Dislocation Thai 6 pin socket ¥:61.00</p>
 <p><b>F71-05-0009</b> 百叶窗升降开关 louwer window lifter switch ¥:83.00</p>	 <p><b>F71-05-0019</b> 三位轻触开关 3 gang 1 way tact switch 强电 /Strong electricity ¥:550.00 弱电 /Weak electricity ¥:400.00</p>	 <p><b>F71-05-0029</b> 45A开关带指示灯 45A switch with indicator light ¥:158.00</p>	 <p><b>F71-05-0039</b> 一开单控带10A二三极插座 ¥:68.00 1gang 1 way switch and 10A 5 pole socket 一开双控带10A二三极插座 ¥:71.00 1gang 2 way switch and 10A 5 pole socket</p>	 <p><b>F71-05-0049</b> 小板16A俄式插座 Russian socket ¥:71.00</p>	 <p><b>F71-05-0059</b> 小板一位开关带16A多功能插座 1 gang switch and 3 pin MF socket ¥:78.00</p>
 <p><b>F71-05-0010</b> 小板16A拨动一位开关单控 1 gang 1 way toggle switch ¥:138.00 小板16A拨动一位开关双控 1 gang 2 way toggle switch ¥:148.00</p>	 <p><b>F71-05-0020</b> 一位轻触开关 1 gang 1 way tact switch 强电 /Strong electricity ¥:450.00 弱电 /Weak electricity ¥:300.00</p>	 <p><b>F71-05-0030</b> 小板16A卷帘门复位开关 Shutter reset switch ¥:142.00</p>	 <p><b>F71-05-0040</b> 二位单控开关带二三极插座 ¥:87.00 2 gang 1 way switch and 5 pole socket 二位双控开关带二三极插座 ¥:93.00 2 gang 2 way switch and 5 pole socket</p>	 <p><b>F71-05-0050</b> 小板16A以色列插座 Israel socket ¥:105.00</p>	 <p><b>F71-05-0060</b> 一位开关带13A方角插座 1 gang switch and 13A square pin socket ¥:71.00</p>

# F71-05 不锈钢本色+灰

Stainless steel color + grey series



**F71-05-0061**  
小版一位开关带15A圆孔插座  
1 gang switch and 15A 3 round pin socket  
¥:76.00



**F71-05-0062**  
一位开关带13A方角插座  
(带指示灯)  
1 gang switch and 13A square pin socket with indicator light  
¥:73.00



**F71-05-0063**  
一位开关带15A圆角插座  
(带指示灯)  
1 gang switch and 15A 3 round pins socket with indicator light  
¥:78.00



**F71-05-0064**  
小版一位开关带16A多功能插座  
(带指示灯)  
1 gang switch and 16A 3 pin MF socket with light  
¥:80.00



**F71-05-0065**  
小版一位开关带13A多功能五孔插座  
(带指示灯)  
1 gang switch and 5 pin multi-function socket with indicator light  
¥:88.00



**F71-05-0066**  
小版16A一位开关带德式插座  
1 gang German socket  
¥:110.00



**F71-05-0067**  
小版16A一位开关带法式插座  
1 gang French socket  
¥:110.00



**F71-05-0068**  
小版16A德式插座带防水  
German socket and Waterproof belt  
¥:105.00



**F71-05-0069**  
小版16A法式插座带防水  
French socket and Waterproof belt  
¥:105.00



**F71-05-0070**  
二位USB带13A方角插座  
2 USB with 13A square corner socket  
¥:163.00



**F71-05-0071**  
小版二位USB带13A多功能插座(横)  
2 USB with 3 pin multi-purpose socket  
¥:205.00



**F71-05-0072**  
15A美式三极扁插带USB+type-c  
American Standard + USB / type-c  
¥:310.00



**F71-05-0073**  
15A泰式多功能插座带USB+type-c  
15A Thai + USB / type-c  
¥:310.00



**F71-05-0074**  
小版二位USB带13A多功能插座  
(带保护门)  
2 USB with 13A multi-purpose socket with flip cover  
¥:203.00



**F71-05-0075**  
小版二位USB带13A方角插座  
(带保护门)  
2 USB with 13A square corner socket with flip cover  
¥:203.00



**F71-05-0076**  
小版一位开关带二位USB带13A  
多功能插座(带指示灯)  
1 gang switch with 2USB and 13A MF socket  
¥:173.00



**F71-05-0077**  
小版一位开关带二位USB带13A  
方角插座(带指示灯)  
2 USB with 13A square corner socket with flip cover  
¥:173.00



**F71-05-0078**  
小版13A多功能带Type-c+USB  
13A multifunction with type-C + USB  
¥:310.00



**F71-05-0079**  
小版13A方角带Type-c+USB  
13A square angle band type-C + USB  
¥:310.00



**F71-05-0080**  
小版二位USB带13A多功能插座(竖)  
2 USB with Three very multi-purpose socket  
¥:183.00



**F71-05-0081**  
小版二位USB带13A方角插座(竖)  
2 USB with 13A square corner socket  
¥:163.00



**F71-05-0082**  
小版二位USB带13A多功能插座  
带小开关(竖)  
2 USB with 13A 3 pin MF socket with little switch  
¥:173.00



**F71-05-0083**  
小版二位USB带13A方角插座  
带小开关(竖)  
2 USB with 13A square corner socket with little switch  
¥:173.00



**F71-05-0084**  
15A美式三极扁插带二位USB  
American Standard + 2USB  
¥:185.00



**F71-05-0085**  
15A泰式多功能插座带二位USB  
15A Thai MF socket + 2USB  
¥:185.00



**F71-05-0086**  
二位USB带二 三极插座  
2 USB and 5 pin socket  
¥:163.00



**F71-05-0087**  
二位USB带二 三极插座  
(带开关)  
2 USB and 5 pin socket with switch  
¥:173.00



**F71-05-0088**  
小版10A二三极插座带Type-c+USB  
10A two and three pole socket with type-C + USB  
¥:310.00



**F71-05-0089**  
小版一位开关带13A多功能五孔  
插座带USB  
1 gang switch and 5 pin multi-function socket with USB and indicator light  
¥:240.00



**F71-05-0090**  
小版13A二位USB带多功能五孔插座  
2 USB with 5 pin multi-function socket  
¥:163.00



**F71-05-0091**  
小版13A二位USB带多功能五孔插座  
带开关  
2 USB with 5 pin multi-function socket with switch  
¥:173.00



**F71-05-0092**  
小版13A多功能五孔插座带Type-c+USB  
13A multi-functional five hole plug type type-C + USB  
¥:310.00



**F71-05-0093**  
小版一位电视插座  
TV socket  
¥:65.00



**F71-05-0094**  
小版双电视插座  
Two TV socket  
¥:91.00



**F71-05-0095**  
小版一位电脑插座 ¥:65.00  
telephone socket ¥:78.00  
小版一位电脑插座  
computer socket  
小版一位电脑插座(超六类)  
computer socket(6) ¥:118.00



**F71-05-0096**  
小版双电话插座 ¥:91.00  
Two telephone socket ¥:121.00  
小版双电脑插座  
Two computer socket  
小版双电脑插座(超六类)  
Two computer socket(6) ¥:181.00



**F71-05-0097**  
小版电话电脑插座 ¥:101.00  
telephone+computer socket  
小版电话电脑插座(超六类)  
telephone+computer socket(6) ¥:141.00



**F71-05-0098**  
电视电话插座 ¥:91.00  
TV + telephone socket  
电视电脑插座 ¥:101.00  
TV + computer socket  
电视电脑插座(超六类)  
TV + computer socket(6) ¥:141.00



**F71-05-0099**  
小版一位电视带USB插座  
TEL + USB socket ¥:238.00  
小版一位电视带USB插座  
computer + USB socket ¥:238.00  
小版一位电视带USB插座(超六类)  
computer + USB socket(6) ¥:288.00



**F71-05-0100**  
小版一位TV+FM  
TV and FM  
¥:190.00



**F71-05-0101**  
小版一位卫星插座  
Satellite socket  
¥:78.00



**F71-05-0102**  
小版二位卫星插座  
Double satellite socket  
¥:121.00



**F71-05-0103**  
小版一位卫星+电视插座  
Satellite and TV socket  
¥:101.00



**F71-05-0104**  
小版卫星带电话插座 ¥:101.00  
Satellite and telephone socket  
小版卫星带电话插座  
Satellite and telephone socket  
¥:111.00  
小版卫星带电脑插座(超六类)  
Satellite and computer socket(6) ¥:151.00



**F71-05-0105**  
小版二位插座带电视插座  
2 pin socket with TV  
¥:151.00



**F71-05-0106**  
小版二位插座带电话插座 ¥:270.00  
2 pin socket with telephone  
小版二位插座带电脑插座  
2 pin socket with computer  
¥:270.00  
小版二位插座带电脑(超六类)  
2 pin socket with computer  
¥:310.00



**F71-05-0107**  
小版一位光纤插座  
Optical fiber socket  
¥:128.00



**F71-05-0108**  
二位USB插座  
Double USB socket  
¥:203.00



**F71-05-0109**  
小版单联音插座  
Single audio socket  
¥:133.00



**F71-05-0110**  
小版双联音插座  
Double audio socket  
¥:183.00



**F71-05-0111**  
触摸延迟开关(节能)  
Touch delay delay switch  
(energy saving)  
¥:113.00



**F71-05-0112**  
声光控延迟开关(节能)  
Sound-light controlled delay  
switch (energy saving)  
¥:113.00



**F71-05-0113**  
红外线人体感应开关  
Human body induction  
¥:248.00



**F71-05-0114**  
凹型地脚灯(亮光/暖光)  
The footlights  
¥:153.00



**F71-05-0115**  
凹型红外线人体感应地脚灯  
(亮光/暖光)  
The human body induction footlights  
¥:268.00



**F71-05-0116**  
平面地脚灯(亮光/暖光)  
Footlights  
¥:153.00



**F71-05-0117**  
叮咚门铃  
Ding dong doorbell  
¥:175.80



**F71-05-0118**  
机械式40A插卡取电 ¥:263.00  
Mechanical card for electricity  
感应式低频40A插卡取电 ¥:453.00  
Low frequency induction card for electricity  
感应式高频40A插卡取电 ¥:553.00  
High frequency induction card for electricity



**F71-05-0119**  
紧急呼叫开关  
Emergency call switch  
¥:163.00



**F71-05-0120**  
请勿打扰清理门铃开关  
(按钮式)  
Do not disturb, please namely cleaning  
please + later doorbell "button"  
¥:191.00

# F71-05 不锈钢本色+灰

Stainless steel color + grey series



**F71-05-0121**  
请勿打扰门铃开关 (按钮式)  
Do not disturb + doorbell "button"  
¥:323.00



**F71-05-0122**  
请勿打扰请即清理门铃开关 (按钮式)  
Do not disturb please namely cleaning please "button"  
¥:323.00



**F71-05-0123**  
智能音乐控制开关  
Intelligent music control switch  
¥:2630.00



**F71-05-0124**  
小框温度控制调节器  
Temperature control switch  
¥:710.00



**F71-05-0125**  
温度控制调节开关  
Temperature control switch  
¥:663.00



**F71-05-0126**  
调音开关(消防)  
Tuning switch ( fire )  
¥:163.00



**F71-05-0127**  
调光开关300W  
Dimming 300W ¥:133.00  
调光开关600W  
Dimming 600W ¥:173.00  
调光开关1000W  
Dimming 1000W ¥:213.00



**F71-05-0128**  
调速开关300W  
Speed 300W ¥:133.00  
调速开关600W  
Speed 600W ¥:173.00  
调速开关1000W  
Speed 1000W ¥:213.00



**F71-05-0129**  
一位开关带调光开关  
1 gang with dimmer switch  
¥:165.00



**F71-05-0130**  
一位开关带调速开关  
1 gang with speed switch  
¥:165.00



**F71-05-0131**  
13A开关带保险丝(带指示灯)  
13A switch with fuse(with light)  
¥:163.00



**F71-05-0132**  
20A出线柱  
20A outgoing post  
¥:82.50



**F71-05-0133**  
剃须插座  
Shaving socket  
¥:430.00



**F71-05-0134**  
USB+电源插座+无线路由  
USB + power socket+wireless router  
¥:803.00



**F71-05-0135**  
蓝牙+3.5音频+二位USB+HDMI  
Bluetooth audio + 3.5 + 2USB + HDMI  
¥:5203.00



**F71-05-0136**  
HDMI  
¥:243.00



**F71-05-0137**  
USB+TYPE-C  
¥:310.00



**F71-05-0138**  
HDMI+USB  
¥:243.00



**F71-05-0139**  
HDMI+USB+3.5音频  
hemi+USB+3.5  
¥:243.00



**F71-05-0140**  
VGA+USB+3.5音频  
VGA+USB + 3.5  
¥:243.00



**F71-05-0141**  
AV+3.5音频  
AV +3.5  
¥:243.00



**F71-05-0142**  
VGA+AV音频接口  
VGA+AV audio interface  
¥:243.00



**F71-05-0143**  
HDMI+AV音频接口  
HDMI + AV audio interface  
¥:127.50



**F71-05-0144**  
二分之一AV音频+卫星  
Half AV audio interface+Satellite  
socket  
¥:270.00



**F71-05-0145**  
二分之一AV音频+USB+3.5音频  
Half AV audio interface+USB+3.5  
¥:270.00



**F71-05-0146**  
二分之一VGA+TV  
Half VGA+TV  
¥:270.00



**F71-05-0147**  
二分之一VGA+电脑插座  
Half VGA+computer socket  
¥:270.00



**F71-05-0148**  
二分之一VGA+USB  
Half VGA+USB  
¥:270.00



**F71-05-0149**  
二分之一VGA+HDMI  
Half VGA+HDMI  
¥:270.00



**F71-05-0150**  
45A出线柱  
45A Outlet  
¥:200.00



**F71-05-0151**  
空白面板  
Blank plate  
¥:16.90



**F71-05-0152**  
小框147型一位开关单控  
147 3 gang 1 way switch  
¥:96.00  
小框147型二位开关双控  
147 2 gang 2 way switch  
¥:242.00



**F71-05-0153**  
小框147型16A三位开关单控  
147 3 gang 1 way switch  
¥:110.00  
小框147型16A三位开关双控  
147 3 gang 2 way switch  
¥:120.00



**F71-05-0154**  
小框147型四位开关单控  
147 4 gang 1 way switch  
¥:276.00  
小框147型四位开关双控  
147 4 gang 2 way switch  
¥:288.00



**F71-05-0155**  
小框147型五位开关单控  
147 5 gang 1 way switch  
¥:157.00  
小框147型五位开关双控  
147 5 gang 2 way switch  
¥:152.00



**F71-05-0156**  
小框147型六位开关单控  
147 6 gang 1 way switch  
¥:311.00  
小框147型六位开关双控  
147 6 gang 2 way switch  
¥:334.00



**F71-05-0157**  
小框147型七位开关单控  
147 7 gang 1 way switch  
¥:163.00  
小框147型七位开关双控  
147 7 gang 2 way switch  
¥:184.00



**F71-05-0158**  
小框147型16A八位开关单控  
147 8 gang 1 way switch  
¥:116.00  
小框147型16A八位开关双控  
147 8 gang 2 way switch  
¥:200.00



**F71-05-0159**  
147型16A多功能三极插座  
147 Double 16A MF socket  
¥:123.00



**F71-05-0160**  
147 二位13A多功能五孔插座  
147 Double 5 pin multi-function  
socket  
¥:138.00



**F71-05-0161**  
小框147型二位15A美标扁  
插座  
147 Double 15A triode flat  
American standard socket  
¥:138.00



**F71-05-0162**  
小框147型二位15A欧式  
三极插座  
147 Double 15A triode flat  
American standard socket  
¥:138.00



**F71-05-0163**  
147 二位13A方角插座  
147 Double 13A square corner  
¥:123.00



**F71-05-0164**  
147 二位15A圆孔插座  
147 Double 15A 3 round pins  
socket  
¥:310.00



**F71-05-0165**  
小框147型二位13A多功能  
五孔插座  
147 type Double 13A dislocation  
multi-function 5 hole socket  
¥:332.00



**F71-05-0166**  
147 二位10A二极插座  
147 Double position two and  
three pole socket  
¥:250.00



**F71-05-0167**  
147 二开带二位16A多功  
能插座  
Two switch and double 16A  
MF 3 pin socket  
¥:168.00



**F71-05-0168**  
二位开关带二位13A方角  
插座  
Two switch and double 13A square  
corner socket  
¥:168.00



**F71-05-0169**  
147 二位开关带二位五孔多功  
能插座(带指示灯)  
147 low switch and double 5 pin  
multi-purpose socket with indicator  
light  
¥:310.00



**F71-05-0170**  
147 二位开关带二位13A方角  
插座(带指示灯)  
147 low switch and double 13A  
square corner socket with indicator  
light  
¥:168.00



**F71-05-0171**  
147 二位开关带二位16A多功  
能插座(带指示灯)  
147 low switch and double 16A  
MF socket with light  
¥:168.00



**F71-05-0172**  
147 二位开关二位13A方角+二位  
USB (小框)  
147 low switch and double 13A  
square corner socket+2USB  
¥:283.00



**F71-05-0173**  
147 二位开关二位13A多功  
能+二位USB (小框)  
147 two switch and double 13A  
band lamp+USB+USB  
¥:283.00



**F71-05-0174**  
147 二位15A圆孔插座  
147 two switch double 15A square  
band lamp+USB+USB  
¥:500.00



**F71-05-0175**  
147 二位开关二位13A多功  
能插座  
147 two switch double 13A MF  
band lamp+USB+USB  
¥:500.00



**F71-05-0176**  
147 二位开关带二位15A圆角插  
座  
147 low switch and double 15A 3  
round pins socket with indicator light  
¥:156.00



**F71-05-0177**  
小框147型一位开关带二位13A  
方角插座(带指示灯)  
147 low switch with double 13A square  
angle socket (with indicator light)  
¥:146.00



**F71-05-0178**  
147型二位剃须插座  
147 two shaving socket  
¥:563.00



**F71-05-0179**  
147 45A开关+一位开关16A  
多功能插座(带指示灯)  
147 kitchen switch  
¥:263.00



**F71-05-0180**  
147 45A开关+一位开关13A  
方角插座(带指示灯)  
147 kitchen switch  
¥:263.00

# F71-05 不锈钢本色+灰

Stainless steel color + grey series



**F71-05-0181**  
147 45A开关+二位开关13A  
方指示灯(带指示灯)  
147 Kitchen switch  
¥:263.00



**F71-05-0182**  
147 45A双极开关带指示灯  
147 type 45A bipolar switch  
¥:183.00



**F71-05-0183**  
147 16A二位法式插座  
147 Double German socket  
¥:148.00



**F71-05-0184**  
147 16A二位法式插座  
147 Double French socket  
¥:148.00



**F71-05-0185**  
147 16A二位法式插座  
147 Double German socket  
¥:148.00



**F71-05-0186**  
147 16A二位法式插座  
147 Double French socket  
¥:148.00



**F71-05-0187**  
147 二位带USB+type-c  
(模块)  
147 double German + USB /  
type-C (module)  
¥:510.00



**F71-05-0188**  
147 二位带USB+type-c  
(模块)  
147 double French + USB /  
type-C (module)  
¥:510.00



**F71-05-0189**  
二位17A德式+二位USB  
(小板连体)  
147 double German with 2USB  
socket+4USB  
¥:410.00



**F71-05-0190**  
147 二位16A法式+2USB  
147 Double French with 2USB  
socket+4USB  
¥:410.00



**F71-05-0191**  
147 四位USB插座  
147 4 USB socket  
¥:413.00



**F71-05-0192**  
147 二位多功能插座+4USB  
147 2-bit multi-function socket  
+ 4USB  
¥:326.00



**F71-05-0193**  
147 二位13A方角插座+4USB  
147 two bit 13A square socket  
+4USB  
¥:326.00



**F71-05-0194**  
147 一位13A方角插座+4USB  
13A square corner  
socket and two USB  
¥:271.00



**F71-05-0195**  
147 一位16A多功能插座  
+二位USB插座  
16A MF 3 pin socket and  
2USB socket  
¥:271.00



**F71-05-0196**  
147 二位开关带二位多功能  
五孔插座带双USB  
147 two switch and double 13A  
5 pin MF socket+2USB  
¥:310.00



**F71-05-0197**  
147 二位开关带二位13A多功能  
五孔插座+2USB(带指示灯)  
147 two switch and double 13A  
MF 5 pin socket + 2USB  
(with indicator)  
¥:460.00



**F71-05-0198**  
147 二位13A多功能五孔插座  
+二位USB  
147 13A double 5 pin MF  
socket+4USB  
¥:330.00



**F71-05-0199**  
147 二位开关二位13A多功能  
五孔插座+四位USB  
147 one open single control and  
MF 5 pin + 4USB socket  
¥:460.00



**F71-05-0200**  
147 二位开关二位多功能  
五孔插座+USB+type-c  
147 two switch and double 5 pin  
MF socket+USB+type-c  
¥:500.00



**F71-05-0201**  
147 二位开关带二位13A多功能  
带四位USB (带指示灯)  
147 two switch and double 13A MF  
+4USB socket (with indicator light)  
¥:480.00



**F71-05-0202**  
147 二位开关带二位13A方角插  
带四位USB  
147 type two switch two position  
13A square inserting band 4 USB  
¥:480.00



**F71-05-0203**  
147 二位13A方角插带  
四位USB  
147 type double position 13A  
square inserting band 4 USB  
¥:335.00



**F71-05-0204**  
147 二位13A多功能+4USB(带盖板)  
+二位USB  
147 double 13A multi-function + 4USB  
(with cover plate)  
¥:380.00



**F71-05-0205**  
147 二位13A方角插带四位USB  
(带盖板)  
147 double 13A square inserting  
+4USB socket  
¥:380.00



**F71-05-0206**  
147 一位单开关带多功能五孔  
插座  
147 1 gang 1 way switch with 5 pin  
MF socket  
¥:274.00



**F71-05-0207**  
147 一位单控带13A方角  
插座+2USB  
147 1 gang 1 way socket with  
13A square Angle socket +2USB  
¥:348.00



**F71-05-0208**  
147 一位单控带15A德式插座  
147 one open single control with  
15A The German socket  
¥:283.00



**F71-05-0209**  
147 一位单控带多功能五孔  
+双USB插座  
147 one open single control and  
MF 5 pin + 2USB socket  
¥:348.00



**F71-05-0210**  
147 二位10A二极插座带四位  
USB插座  
147 double 10A 5 pin socket +  
4USB with indicator light  
¥:440.00



**F71-05-0211**  
147 二位13A多功能带四位USB  
带小开关  
147 double 13A 3pin multi-function  
socket + 4USB with small switch  
¥:480.00



**F71-05-0212**  
147 二位13A方角插带四位USB  
带小开关  
147 type double 13A square plug with  
4USB with small switch  
¥:480.00



**F71-05-0213**  
147 一位一开16A多功能带指示灯  
147 low switch and double 16A MF  
3 pin socket with neon  
¥:326.00



**F71-05-0214**  
147 二位13A多功能带四位USB  
(带指示灯)  
147 type MF 3 pin socket and 4USB  
with neon  
¥:350.00



**F71-05-0215**  
147 16A多功能1方用五孔插座  
147 16A MF 3 pin + 5 pin MF socket  
¥:295.00



**F71-05-0216**  
147 10A二二二极插座  
10A 3 pole socket  
¥:310.00



**F71-05-0217**  
147 二位单控开关带16A  
多功能插座  
147 two switch single control  
16A MF 3 pin socket  
¥:276.00



**F71-05-0218**  
147 一位单控带13A方角插座  
147 type double open single control  
socket with 13A square angle  
¥:276.00



**F71-05-0219**  
147 10A二极带10A二极插座  
147 10A two pole with 10A two  
pole socket  
¥:280.00



**F71-05-0220**  
147 二位一位一开单控二位16A  
三极插座  
147 type 2 gang 1 way switch double  
16A three pole socket  
¥:320.00



**F71-05-0221**  
147 二位一位一开单控带二位10A  
二极插座  
147 type 2 gang 1 way switch double  
10A 5 pole socket  
¥:320.00



**F71-05-0222**  
147 二位10A二二二极插座带  
USB+type-c  
147 type double 10A 5 pole socket  
USB + type-C  
¥:720.00



**F71-05-0223**  
147 二位多功能五孔插座带  
USB+type-c  
147 two switch double 5 pin multi-  
functional USB + type-c  
¥:720.00



**F71-05-0224**  
147 13A多功能双USB带五  
孔插座  
147 type 13A multi-functional 2USB  
with 5 pin multi-functional socket  
¥:389.00



**F71-05-0225**  
147 二位电脑插座带二位  
USB插座  
147 type double computer with  
2USB socket  
¥:460.00



**F71-05-0226**  
147 二位电话带二位电脑  
插座  
147 double telephone with double  
computer socket  
¥:390.00



**F71-05-0227**  
147 二位电脑插座带16A  
多功能插座  
147 double computer with 16A  
MF pin socket  
¥:333.00



**F71-05-0228**  
147 二位16A德式插座带防水  
147 two position 16A German socket  
with waterproof  
¥:350.00



**F71-05-0229**  
147 二位16A法式插座带防水  
147 two position 16A French socket  
with waterproof  
¥:350.00



**F71-05-0230**  
147 二位一位一开单控带二位16A  
三极插座  
147 type double 16A German  
socket+USB+type-c with light  
¥:500.00



**F71-05-0231**  
147 二位开关二位16A法式插座  
带指示灯+USB/type-c (小板)  
147 double switch double French  
socket+USB+type-c with light  
¥:490.00



**F71-05-0232**  
147 二位开关二位16A德式插座  
(带指示灯)  
147 two switch double 16A German  
socket with light  
¥:190.00



**F71-05-0233**  
147 二位开关二位16A法式插座  
(带指示灯)  
147 two switch double 16A French  
socket with light  
¥:190.00



**F71-05-0234**  
147 二位开关二位16A德式插座  
带指示灯+二位USB (小板)  
147 two switch double 16A German  
socket + 2usb with light  
¥:440.00



**F71-05-0235**  
147 二位开关二位16A法式插座  
带指示灯+二位USB (小板)  
147 two switch double 16A French  
socket + 2USB with light  
¥:440.00



**F71-05-0236**  
147 二位10A二二二极五孔USB  
+小开关(带指示灯)  
147 double 10A 5 pin socket+4USB  
two little switch with indicator light  
¥:390.00



**F71-05-0237**  
147 一位一开13A多功能五孔  
插座带双USB  
147 two switch and double 13A  
MF 5 pin socket (with indicator)  
¥:330.00



**F71-05-0238**  
147 二位双16A法式插座带  
四位USB (带指示灯)  
147 double 16A German socket  
4 USB (with indicator)  
¥:400.00



**F71-05-0239**  
147 二位双16A法式插座带  
四位USB (带指示灯)  
147 double 16A French socket  
4 USB (with indicator)  
¥:400.00



**F71-05-0240**  
147 二位一位白面板  
147 2-bit 1-bit white plate  
¥:28.00



# F71-07

铝拉丝雅致黑系列  
Aluminum brushed elegant black series



## 连体产品 Conjoined products





# F71-07 铝拉丝雅致黑系列

Aluminum brushed elegant black series

**F71-07-0001**  
 小板16A一位开关单控  
 16A 1 gang 1 way switch ¥:48.00  
 小板16A一位开关双控  
 16A 1 gang 2 way switch ¥:52.00  
 小板16A一位开关多控  
 16A 1 gang more way switch ¥:88.00

**F71-07-0002**  
 小板16A二位开关单控  
 16A 1 gang 1 way switch ¥:62.00  
 小板16A二位开关双控  
 16A 1 gang 2 way switch ¥:68.00  
 小板16A二位开关多控  
 16A 1 gang more way switch ¥:120.00

**F71-07-0003**  
 小板16A三位开关单控  
 16A 3 gang 1 way switch ¥:75.00  
 小板16A三位开关双控  
 16A 3 gang 2 way switch ¥:84.00

**F71-07-0004**  
 小板16A四位开关单控  
 16A 4 gang 1 way switch ¥:88.00  
 小板16A四位开关双控  
 16A 4 gang 2 way switch ¥:100.00

**F71-07-0005**  
 小板16A二位开关多控  
 16A 3 gang 3 way switch ¥:88.00

**F71-07-0006**  
 门铃开关  
 gating switch ¥:68.00

**F71-07-0007**  
 英式门控开关  
 British gating switch ¥:68.00

**F71-07-0008**  
 门铃开关  
 doorbell switch ¥:68.00

**F71-07-0009**  
 百叶窗升降开关  
 louver window lifter switch ¥:83.00

**F71-07-0010**  
 小板16A一位开关单控  
 1 gang 1 way toggle switch ¥:138.00  
 小板16A一位开关双控  
 1 gang 2 way toggle switch ¥:148.00

**F71-07-0011**  
 小板16A一位开关单控  
 2 gang 1 way toggle switch ¥:158.00  
 小板16A一位开关双控  
 2 gang 2 way toggle switch ¥:170.00

**F71-07-0012**  
 小板16A一位开关单控  
 3 gang 1 way toggle switch ¥:178.00  
 小板16A一位开关双控  
 3 gang 2 way toggle switch ¥:196.00

**F71-07-0013**  
 小板16A一位开关单控  
 4 gang 1 way toggle switch ¥:198.00  
 小板16A一位开关双控  
 4 gang 2 way toggle switch ¥:222.00

**F71-07-0014**  
 一位轻触开关  
 1 gang 1 way tact switch  
 强电 /Strong electricity ¥:450.00  
 弱电 /Weak electricity ¥:300.00

**F71-07-0015**  
 二位轻触开关  
 2 gang 1 way tact switch  
 强电 /Strong electricity ¥:500.00  
 弱电 /Weak electricity ¥:350.00

**F71-07-0016**  
 三位轻触开关  
 3 gang 1 way tact switch  
 强电 /Strong electricity ¥:550.00  
 弱电 /Weak electricity ¥:400.00

**F71-07-0017**  
 一位轻触开关  
 1 gang 1 way tact switch  
 强电 /Strong electricity ¥:450.00  
 弱电 /Weak electricity ¥:300.00

**F71-07-0018**  
 二位轻触开关  
 2 gang 1 way tact switch  
 强电 /Strong electricity ¥:500.00  
 弱电 /Weak electricity ¥:350.00

**F71-07-0019**  
 三位轻触开关  
 3 gang 1 way tact switch  
 强电 /Strong electricity ¥:550.00  
 弱电 /Weak electricity ¥:400.00

**F71-07-0020**  
 一位轻触开关  
 1 gang 1 way tact switch  
 强电 /Strong electricity ¥:450.00  
 弱电 /Weak electricity ¥:300.00

**F71-07-0021**  
 二位轻触开关  
 2 gang 1 way tact switch  
 强电 /Strong electricity ¥:500.00  
 弱电 /Weak electricity ¥:350.00

**F71-07-0022**  
 三位轻触开关  
 3 gang 1 way tact switch  
 强电 /Strong electricity ¥:550.00  
 弱电 /Weak electricity ¥:400.00

**F71-07-0023**  
 四位轻触开关  
 4 gang 1 way tact switch  
 强电 /Strong electricity ¥:600.00  
 弱电 /Weak electricity ¥:450.00

**F71-07-0024**  
 一位轻触开关  
 1 gang 1 way tact switch  
 强电 /Strong electricity ¥:450.00  
 弱电 /Weak electricity ¥:300.00

**F71-07-0025**  
 二位轻触开关  
 2 gang 1 way tact switch  
 强电 /Strong electricity ¥:500.00  
 弱电 /Weak electricity ¥:350.00

**F71-07-0026**  
 三位轻触开关  
 3 gang 1 way tact switch  
 强电 /Strong electricity ¥:550.00  
 弱电 /Weak electricity ¥:400.00

**F71-07-0027**  
 四位轻触开关  
 4 gang 1 way tact switch  
 强电 /Strong electricity ¥:600.00  
 弱电 /Weak electricity ¥:450.00

**F71-07-0028**  
 小板20A双极开关带指示灯  
 20A switch with indicator light ¥:148.00  
 小板45A双极开关带指示灯  
 45A switch with indicator light ¥:168.00

**F71-07-0029**  
 45A开关带指示灯  
 45A switch with indicator light ¥:158.00

**F71-07-0030**  
 小板16A带灯门复位开关  
 Shutter reset switch ¥:142.00

**F71-07-0031**  
 16A三级插座  
 16A 3 pole socket ¥:58.00

**F71-07-0032**  
 10A二三级五孔插座  
 10A 5 pole socket ¥:49.00

**F71-07-0033**  
 二位二极插座  
 10A Two or three pole socket ¥:61.00

**F71-07-0034**  
 二二三级插座  
 10A 5 pole socket ¥:66.00

**F71-07-0035**  
 小板16A多功能二极插座  
 16A 2 pin multi-function socket ¥:58.00

**F71-07-0036**  
 小板13A二三级多功能插座  
 5 pin multi-function socket ¥:65.00

**F71-07-0037**  
 小板13A二位多功能二三级插座  
 Dislocation multi 5 pin multi-function socket ¥:95.00

**F71-07-0038**  
 一开单控带16A二三级插座 ¥:71.00  
 10gang 1 way switch and 16A 3 pole socket  
 一开双控带16A二三级插座 ¥:74.00  
 10gang 2 way switch and 16A 3 pole socket

**F71-07-0039**  
 一开单控带10A二三级插座 ¥:68.00  
 10gang 1 way switch and 10A 5 pole socket  
 一开双控带10A二三级插座 ¥:71.00  
 10gang 2 way switch and 10A 5 pole socket

**F71-07-0040**  
 二位单控开关带二三级插座 ¥:87.00  
 2 gang 1 way switch and 5 pole socket  
 二位双控开关带二三级插座 ¥:93.00  
 2 gang 2 way switch and 5 pole socket

**F71-07-0041**  
 10A二极插座  
 10A 2 pole socket ¥:55.00

**F71-07-0042**  
 10A二极插座  
 10A Double 2 pole socket ¥:63.00

**F71-07-0043**  
 小板10A一位开关带二极插座  
 1 gang switch and 2 pole socket ¥:61.00

**F71-07-0044**  
 小板10A一位开关带二极插座  
 1 gang switch and 4 pole socket ¥:71.00

**F71-07-0045**  
 小板13A方角插座  
 13A square corner socket ¥:61.00

**F71-07-0046**  
 小板15A圆角插座  
 15A 3 round pins socket ¥:85.00

**F71-07-0047**  
 小板16A德式插座  
 German socket ¥:71.00

**F71-07-0048**  
 小板16A法式插座  
 French socket ¥:71.00

**F71-07-0049**  
 小板16A俄式插座  
 Russian socket ¥:71.00

**F71-07-0050**  
 小板16A以色列插座  
 Israel socket ¥:105.00

**F71-07-0051**  
 小板16A意大利、德式插座  
 Italy+German socket ¥:105.00

**F71-07-0052**  
 小板16A德式插座带二位USB  
 2 USB with German socket ¥:203.00

**F71-07-0053**  
 小板16A法式插座带二位USB  
 2 USB with French socket ¥:203.00

**F71-07-0054**  
 小板16A德式插座+USB/Type-c  
 Small board 16A German socket + USB / type-c ¥:330.00

**F71-07-0055**  
 小板16A法式插座+USB/Type-c  
 Small board 16A French socket + USB / type-c ¥:330.00

**F71-07-0056**  
 小板15A泰式插座  
 15A Thai socket ¥:61.00

**F71-07-0057**  
 小板15A美式插座  
 15A triode flat American standard socket ¥:65.00

**F71-07-0058**  
 小板错位泰式六孔插座  
 Dislocation Thai 6 pin socket ¥:61.00

**F71-07-0059**  
 小板一位开关带16A多功能插座  
 1 gang switch and 3 pin MF socket ¥:78.00

**F71-07-0060**  
 一位开关带13A方角插座  
 1 gang switch and 13A square pin socket ¥:71.00

# F71-07 铝拉丝雅致黑系列

Aluminum brushed elegant black series



**F71-07-0061**  
小版一位开关带15A圆孔插座  
1 gang switch and 15A 3 round pin socket  
¥:76.00



**F71-07-0062**  
一位开关带13A方角插座  
(带指示灯)  
1 gang switch and 13A square pin socket with indicator light  
¥:73.00



**F71-07-0063**  
一位开关带15A圆角插座  
(带指示灯)  
1 gang switch and 15A 3 round pins socket with indicator light  
¥:78.00



**F71-07-0064**  
小版一位开关带16A多功能插座  
(带指示灯)  
1 gang switch and 16A 3 pin MF socket with light  
¥:80.00



**F71-07-0065**  
小版一位开关带13A多功能五孔插座  
(带指示灯)  
1 gang switch and 5 pin multi-function socket with indicator light  
¥:88.00



**F71-07-0066**  
小版16A一位开关带德式插座  
1 gang German socket  
¥:110.00



**F71-07-0067**  
小版16A一位开关带法式插座  
1 gang French socket  
¥:110.00



**F71-07-0068**  
小版16A德式插座带防水  
German socket and Waterproof belt  
¥:105.00



**F71-07-0069**  
小版16A法式插座带防水  
French socket and Waterproof belt  
¥:105.00



**F71-07-0070**  
二位USB带13A方角插座  
2 USB with 13A square corner socket  
¥:163.00



**F71-07-0071**  
小版二位USB带13A多功能插座(横)  
2 USB with 3 pin multi-purpose socket  
¥:205.00



**F71-07-0072**  
15A美式三极扁插带USB+type-c  
American Standard + USB / type-c  
¥:310.00



**F71-07-0073**  
15A泰式多功能插座带USB+type-c  
15A Thai + USB / type-c  
¥:310.00



**F71-07-0074**  
小版二位USB带13A多功能插座  
(带保护门)  
2 USB with 13A multi-purpose socket with flip cover  
¥:203.00



**F71-07-0075**  
小版二位USB带13A方角插座  
(带保护门)  
2 USB with 13A square corner socket with flip cover  
¥:203.00



**F71-07-0076**  
小版一位开关带二位USB带13A  
多功能插座(带指示灯)  
1 gang switch with 2USB and 13A MF socket  
¥:173.00



**F71-07-0077**  
小版一位开关带二位USB带13A  
方角插座(带指示灯)  
2 USB with 13A square corner socket with flip cover  
¥:173.00



**F71-07-0078**  
小版13A多功能带Type-C+USB  
13A multifunction with type-C + USB  
¥:310.00



**F71-07-0079**  
小版13A方角带Type-C+USB  
13A square angle band type-C + USB  
¥:310.00



**F71-07-0080**  
小版二位USB带13A多功能插座(竖)  
2 USB with Three very multi-purpose socket  
¥:183.00



**F71-07-0081**  
小版二位USB带13A方角插座(竖)  
2 USB with 13A square corner socket  
¥:163.00



**F71-07-0082**  
小版二位USB带13A多功能插座  
带小开关(竖)  
2 USB with 13A 3 pin MF socket with little switch  
¥:173.00



**F71-07-0083**  
小版一位电视插座  
带小开关(竖)  
2 USB with 13A square corner socket with little switch  
¥:173.00



**F71-07-0084**  
15A美式三极扁插带二位USB  
American Standard + 2USB  
¥:185.00



**F71-07-0085**  
15A泰式多功能插座带二位USB  
15A Thai MF socket + 2USB  
¥:185.00



**F71-07-0086**  
二位USB带二 三极插座  
2 USB and 5 pin socket  
¥:163.00



**F71-07-0087**  
二位USB带二 三极插座  
(带开关)  
2 USB and 5 pin socket with switch  
¥:173.00



**F71-07-0088**  
小版10A二三极插座带Type-c+USB  
10A two and three pole socket with type-C + USB  
¥:310.00



**F71-07-0089**  
小版一位开关带13A多功能五孔  
插座带USB  
1 gang switch and 5 pin multi-function socket with USB and indicator light  
¥:240.00



**F71-07-0090**  
小版二位USB带13A多功能五孔插座  
2 USB with 5 pin multi-function socket  
¥:163.00



**F71-07-0091**  
小版13A二位USB带多功能五孔插座  
带开关  
2 USB with 5 pin multi-function socket with switch  
¥:173.00



**F71-07-0092**  
小版13A多功能五孔插座带Type-c+USB  
13A multi-functional five hole plug type type-C + USB  
¥:310.00



**F71-07-0093**  
小版一位电视插座  
TV socket  
¥:65.00



**F71-07-0094**  
小版双电视插座  
Two TV socket  
¥:91.00



**F71-07-0095**  
小版一位电话插座 ¥:65.00  
telephone socket ¥:78.00  
小版一位电脑插座  
computer socket ¥:118.00  
小版一位电脑插座(超六类)  
computer socket(6)



**F71-07-0096**  
小版双电话插座 ¥:91.00  
Two telephone socket ¥:121.00  
小版双电脑插座  
Two computer socket ¥:181.00  
小版双电脑插座(超六类)  
Two computer socket(6)



**F71-07-0097**  
小版电话电脑插座 ¥:101.00  
telephone+computer socket ¥:141.00  
小版电话电脑插座(超六类)  
telephone+computer socket(6)



**F71-07-0098**  
电视电话插座 ¥:91.00  
TV + telephone socket ¥:101.00  
电视电脑插座  
TV + computer socket ¥:141.00  
电视电脑插座(超六类)  
TV + computer socket(6)



**F71-07-0099**  
小版一位带USB插座  
TEL + USB socket ¥:238.00  
小版一位带USB插座  
computer + USB socket ¥:238.00  
小版一位带USB插座(超六类)  
computer + USB socket(6) ¥:288.00



**F71-07-0100**  
小版一位TV+FM  
TV and FM  
¥:190.00



**F71-07-0101**  
小版一位卫星插座  
Satellite socket  
¥:78.00



**F71-07-0102**  
小版二位卫星插座  
Double satellite socket  
¥:121.00



**F71-07-0103**  
小版卫星+电视插座  
Satellite and TV socket  
¥:101.00



**F71-07-0104**  
小版卫星带电话插座 ¥:101.00  
Satellite and telephone socket  
小版卫星带电话插座  
Two TV socket ¥:111.00  
小版卫星带电话插座  
Satellite and computer socket  
小版卫星带电话插座(超六类) ¥:151.00  
Satellite and computer socket(6)



**F71-07-0105**  
小版二位插座带电视插座  
2 pin socket with TV  
¥:151.00



**F71-07-0106**  
小版二位插座带电话插座 ¥:270.00  
2 pin socket with telephone  
小版二位插座带电话插座  
2 pin socket with computer ¥:270.00  
小版二位插座带电话(超六类)  
2 pin socket with computer  
¥:310.00



**F71-07-0107**  
小版一位光纤插座  
Optical fiber socket  
¥:128.00



**F71-07-0108**  
二位USB插座  
Double USB socket  
¥:203.00



**F71-07-0109**  
小版单联音插座  
Single audio socket  
¥:133.00



**F71-07-0110**  
小版双联音插座  
Double audio socket  
¥:183.00



**F71-07-0111**  
触摸延迟开关(节能)  
Touch delay delay switch  
(energy saving)  
¥:113.00



**F71-07-0112**  
声光控延迟开关(节能)  
Sound-light controlled delay  
switch (energy saving)  
¥:113.00



**F71-07-0113**  
红外线人体感应开关  
Human body induction  
¥:248.00



**F71-07-0114**  
凹型地脚灯(亮光/暖光)  
The footlights  
¥:153.00



**F71-07-0115**  
凹型红外线人体感应地脚灯  
(亮光/暖光)  
The human body induction footlights  
¥:268.00



**F71-07-0116**  
平面地脚灯(亮光/暖光)  
Footlights  
¥:153.00



**F71-07-0117**  
叮咚门铃  
Ding dong doorbell  
¥:175.80



**F71-07-0118**  
机械式40A插卡取电 ¥:263.00  
Mechanical card for electricity  
感应式低频40A插卡取电 ¥:453.00  
Low frequency induction card  
for electricity  
感应式高频40A插卡取电 ¥:553.00  
High frequency induction card  
for electricity



**F71-07-0119**  
紧急呼叫开关  
Emergency call switch  
¥:163.00



**F71-07-0120**  
请勿打扰请清理门铃开关  
(按钮式)  
Do not disturb, please namely cleaning  
please + later doorbell "button"  
¥:191.00

# F71-07 铝拉丝雅致黑系列

Aluminum brushed elegant black series



**F71-07-0121**  
请勿打扰门铃开关 (按钮式)  
Do not disturb + doorbell "button"  
¥:323.00



**F71-07-0122**  
请勿打扰请即清理门铃开关 (按钮式)  
Do not disturb please namely cleaning please "button"  
¥:323.00



**F71-07-0123**  
智能音乐控制开关  
Intelligent music control switch  
¥:2630.00



**F71-07-0124**  
小框温度控制调节器  
Temperature control switch  
¥:710.00



**F71-07-0125**  
温度控制调节开关  
Temperature control switch  
¥:663.00



**F71-07-0126**  
调音开关(消防)  
Tuning switch (fire)  
¥:163.00



**F71-07-0127**  
调光开关300W  
Dimming 300W ¥:133.00  
调光开关600W  
Dimming 600W ¥:173.00  
调光开关1000W  
Dimming 1000W ¥:213.00



**F71-07-0128**  
调速开关300W  
Speed 300W ¥:133.00  
调速开关600W  
Speed 600W ¥:173.00  
调速开关1000W  
Speed 1000W ¥:213.00



**F71-07-0129**  
一位开关带调光开关  
1 gang with dimmer switch  
¥:165.00



**F71-07-0130**  
一位开关带调速开关  
1 gang with speed switch  
¥:165.00



**F71-07-0131**  
13A开关带保险丝(带指示灯)  
13A switch with fuse(with light)  
¥:163.00



**F71-07-0132**  
20A出线柱  
20A outgoing post  
¥:82.50



**F71-07-0133**  
剃须插座  
Shaving socket  
¥:430.00



**F71-07-0134**  
USB+电源插座+无线路由  
USB + computer socket+wireless router  
¥:803.00



**F71-07-0135**  
蓝牙+3.5音频+USB+HDMI  
Bluetooth audio + 3.5 + USB + HDMI  
¥:5203.00



**F71-07-0136**  
HDMI  
¥:243.00



**F71-07-0137**  
USB+TYPE-C  
¥:310.00



**F71-07-0138**  
HDMI+USB  
¥:243.00



**F71-07-0139**  
HDMI+USB+3.5音频  
hemi+USB+3.5  
¥:243.00



**F71-07-0140**  
VGA+USB+3.5音频  
VGA+USB +3.5  
¥:243.00



**F71-07-0141**  
AV+3.5音频  
AV +3.5  
¥:243.00



**F71-07-0142**  
VGA+AV音频接口  
VGA + AV audio interface  
¥:243.00



**F71-07-0143**  
HDMI+AV音频接口  
HDMI + AV audio interface  
¥:127.50



**F71-07-0144**  
二分之一AV音频+卫星  
Half AV audio interface+Satellite socket  
¥:270.00



**F71-07-0145**  
二分之一AV音频+USB+3.5音频  
Half AV audio interface+USB+3.5  
¥:270.00



**F71-07-0146**  
二分之一VGA+TV  
Half VGA+TV  
¥:270.00



**F71-07-0147**  
二分之一VGA+电脑插座  
Half VGA+computer socket  
¥:270.00



**F71-07-0148**  
二分之一VGA+USB  
Half VGA+USB  
¥:270.00



**F71-07-0149**  
二分之一VGA+HDMI  
Half VGA+HDMI  
¥:270.00



**F71-07-0150**  
45A出线柱  
45A Outlet  
¥:200.00



**F71-07-0151**  
空白面板  
Blank plate  
¥:16.90



**F71-07-0152**  
小框147型一位开关单控  
147 1 gang 1 way switch  
¥:96.00  
小框147型二位开关双控  
147 2 gang 2 way switch  
¥:242.00



**F71-07-0153**  
小框147型16A三位开关单控  
147 3 gang 1 way switch  
¥:110.00  
小框147型16A三位开关双控  
147 3 gang 2 way switch  
¥:120.00



**F71-07-0154**  
小框147型四位开关单控  
147 4 gang 1 way switch  
¥:276.00  
小框147型四位开关双控  
147 4 gang 2 way switch  
¥:288.00



**F71-07-0155**  
小框147型16A五位开关单控  
147 5 gang 1 way switch  
¥:157.00  
小框147型16A五位开关双控  
147 5 gang 2 way switch  
¥:152.00



**F71-07-0156**  
小框147型六位开关单控  
147 6 gang 1 way switch  
¥:311.00  
小框147型六位开关双控  
147 6 gang 2 way switch  
¥:334.00



**F71-07-0157**  
小框147型16A七位开关单控  
147 7 gang 1 way switch  
¥:163.00  
小框147型16A七位开关双控  
147 7 gang 2 way switch  
¥:184.00



**F71-07-0158**  
小框147型16A八位开关单控  
147 8 gang 1 way switch  
¥:156.00  
小框147型16A八位开关双控  
147 8 gang 2 way switch  
¥:200.00



**F71-07-0159**  
147二位16A多功能三极插座  
147 Double 16A MF socket  
¥:123.00



**F71-07-0160**  
147二位13A多功能五孔插座  
147 Double 5 pin multi-function socket  
¥:138.00



**F71-07-0161**  
小框147型二位15A美标扁插座  
147 Double 15A triode flat American standard socket  
¥:138.00



**F71-07-0162**  
小框147型二位15A欧式三极插座  
147 Double 15A triode flat American standard socket  
¥:138.00



**F71-07-0163**  
147二位13A方角插座  
147 Double 13A square corner  
¥:123.00



**F71-07-0164**  
147二位15A圆孔插座  
147 Double 15A 3 round pins socket  
¥:310.00



**F71-07-0165**  
小框147型二位13A槽位多功能五孔插座  
147 type Double 13A dislocation multi-function 5 hole socket  
¥:332.00



**F71-07-0166**  
147二位10A二极插座  
147 Double position two and three pole socket  
¥:250.00



**F71-07-0167**  
147二开带二位16A多功能插座  
Two switch and double 16A MF 3 pin socket  
¥:168.00



**F71-07-0168**  
二位开关带二位13A方角插座  
Two switch and double 13A square corner socket  
¥:168.00



**F71-07-0169**  
147二位开关一位五孔多功能插座(带指示灯)  
147 two switch and double 5 pin multi-purpose socket with indicator light  
¥:310.00



**F71-07-0170**  
147二位开关二位13A方角插座(带指示灯)  
147 two switch and double 13A square corner socket with indicator light  
¥:168.00



**F71-07-0171**  
147二位开关二位16A多功能插座(带指示灯)  
147 two switch and double 16A MF socket with light  
¥:168.00



**F71-07-0172**  
147二位开关二位13A方角+二位USB(小框)  
147 two switch and double 13A square corner socket+2USB  
¥:283.00



**F71-07-0173**  
147二位开关二位13A多功能+二位USB(小框)  
147 two switch and double 13A MF socket+2USB  
¥:283.00



**F71-07-0174**  
147二位15A圆孔插座  
147 two switch double 15A square lamp+USB/Type-c  
¥:500.00



**F71-07-0175**  
147二位开关二位13A多功能插座(带灯)+USB/Type-c  
147 two switch double 13A MF lamp+USB/Type-c  
¥:500.00



**F71-07-0176**  
147二位开关带二位15A圆角插座(带指示灯)  
147 two switch and double 15A 3 round pins socket with indicator light  
¥:156.00



**F71-07-0177**  
小框147型二位开关带二位13A方角插座(带指示灯)  
147 two switch with double 13A square angle socket (with indicator light)  
¥:146.00



**F71-07-0178**  
147型二位剃须插座  
147 two shaving socket  
¥:563.00



**F71-07-0179**  
147 45A开关一位开关16A多功能带指示灯  
(组合厨房开关)  
147 kitchen switch  
¥:263.00



**F71-07-0180**  
147 45A开关一位开关13A方角带指示灯(组合厨房开关)  
147 kitchen switch  
¥:263.00

# F71-07 铝拉丝雅致黑系列

Aluminum brushed elegant black series



**F71-07-0181**  
147 45A开+二位开关13A  
方指示灯(带指示灯)  
147 Kitchen switch  
¥:263.00



**F71-07-0182**  
147 45A双极开关带指示灯  
147 type 45A bipolar switch  
¥:183.00



**F71-07-0183**  
147 16A二位德式插座  
147 Double German socket  
¥:148.00



**F71-07-0184**  
147 16A二位法式插座  
147 Double French socket  
¥:148.00



**F71-07-0185**  
147 16A二位德式插座  
147 Double German socket  
¥:148.00



**F71-07-0186**  
147 16A二位法式插座  
147 Double French socket  
¥:148.00



**F71-07-0187**  
147 二位带USB+type-c  
(模块)  
147 Double German + USB /  
type-C (module)  
¥:510.00



**F71-07-0188**  
147 二位带USB+type-c  
(模块)  
147 Double French + USB /  
type-C (module)  
¥:510.00



**F71-07-0189**  
二位17A德式+二位USB  
(小板连体)  
147 Double German with 2USB  
¥:410.00



**F71-07-0190**  
147 二位16A法式+2USB  
(小板连体)  
147 Double French with 2USB  
¥:410.00



**F71-07-0191**  
147 四位USB插座  
147 4 USB socket  
¥:413.00



**F71-07-0192**  
147 二位多功能插座+4USB  
147 2-bit multi-function socket  
+ 4USB  
¥:326.00



**F71-07-0193**  
147 二位13A方插座+4USB  
147 two bit 13A square socket  
+4USB  
¥:326.00



**F71-07-0194**  
147 一位13A方角插座  
+二位USB  
13A square corner  
socket and two USB  
¥:271.00



**F71-07-0195**  
147 一位16A多功能插座  
+二位USB插座  
16A MF 3 pin socket and  
2USB socket  
¥:271.00



**F71-07-0196**  
147 二位带开关二位多功能  
五孔插座带双USB  
147 2 gang 1 way switch and double 13A  
5 pin MF socket+2USB  
¥:310.00



**F71-07-0197**  
147 二位开关带二位13A多功能  
五孔插座+2USB(带指示灯)  
147 two switch and double 13A  
MF 5 pin socket + 2USB  
(with indicator)  
¥:460.00



**F71-07-0198**  
147 二位13A多功能五孔插座  
+二位USB  
147 13A double 5 pin MF  
socket+4USB  
¥:330.00



**F71-07-0199**  
147 二位开关二位13A多功能  
五孔插座+四位USB  
147 one open switch double 5 pin MF  
socket+4USB  
¥:460.00



**F71-07-0200**  
147 二位开关二位多功能  
五孔插座+USB+type-c  
147 Two switch and double 5 pin  
MF socket+USB+type-c  
¥:500.00



**F71-07-0201**  
147 二位开关二位13A多功能  
带四位USB (带指示灯)  
147 two switch and double 13A MF  
+4USB socket (with indicator light)  
¥:480.00



**F71-07-0202**  
147 二位开关二位13A方带  
四位USB  
147 type two switch two position  
13A square inserting band 4 USB  
¥:480.00



**F71-07-0203**  
147 二位13A方带插带  
四位USB  
147 type double position 13A  
square inserting band 4 USB  
¥:335.00



**F71-07-0204**  
147 二位13A多功能+4USB(带盖板)  
+二位USB  
147 double 13A multi-function + 4USB  
(with cover plate)  
147 type MF 3 pin socket and 4USB  
with neon  
¥:380.00



**F71-07-0205**  
147 二位13A方带四位USB  
(带盖板)  
147 double 13A square inserting  
+4USB socket  
¥:380.00



**F71-07-0206**  
147 一位单控带二位多功能  
五孔插座  
147 1 gang 1 way switch with 5 pin  
MF socket  
¥:274.00



**F71-07-0207**  
147 一位单控带13A方角  
插座+2USB  
147 1 gang 1 way socket with  
13A square Angle socket +2USB  
¥:348.00



**F71-07-0208**  
147 一位单控带15A法式插座  
147 one open single control with  
15A The square angle  
¥:283.00



**F71-07-0209**  
147 一位单控带二位五孔  
+双USB插座  
147 one open single control and  
MF 5 pin + 2USB socket  
¥:348.00



**F71-07-0210**  
147 二位二位10A二三位多功能  
五孔插座+二位USB+type-c  
147 double 10A 5 pin socket +  
4 USB with indicator light  
¥:440.00



**F71-07-0211**  
147 二位13A多功能带四位USB  
带小开关  
147 double 13A 3pin multi-function  
socket + 4USB with small switch  
¥:480.00



**F71-07-0212**  
147 二位13A方带四位USB  
带小开关  
147 double 13A square plug with  
4USB with small switch  
¥:480.00



**F71-07-0213**  
147 一位开16A多功能带指示灯  
147 low switch and double 16A MF  
3 pin socket with neon  
¥:326.00



**F71-07-0214**  
147 二位13A多功能带四位USB  
(带指示灯)  
147 type MF 3 pin socket and 4USB  
with neon  
¥:350.00



**F71-07-0215**  
147 16A多功能+万用五孔插座  
147 16A MF 3 pin + 5 pin MF socket  
¥:295.00



**F71-07-0216**  
147 10A二三位插座  
10A 8 pole socket  
¥:310.00



**F71-07-0217**  
147 二位单控带16A  
多功能插座  
147 two switch single control  
16A MF 3 pin socket  
¥:276.00



**F71-07-0218**  
147 二位单控带13A方角插座  
147 type double open single control  
socket with 13A square angle  
¥:276.00



**F71-07-0219**  
147 10A二位带10A二位插座  
147 10A two pole with 10A two  
pole socket  
¥:280.00



**F71-07-0220**  
147 二位一位开二位16A  
三位插座  
147 type 2 gang 1 way switch double  
16A three pole socket  
¥:320.00



**F71-07-0221**  
147 二位一位开单控二位10A  
二位插座  
147 type 2 gang 1 way switch double  
10A 5 pole socket  
¥:320.00



**F71-07-0222**  
147 二位10A二三位插座带  
USB+type-c  
147 type double 10A 5 pole socket  
USB + type-C  
¥:720.00



**F71-07-0223**  
147 二位多功能五孔插座带  
USB+type-c  
147 type double 5 pin multi-  
functional USB + type-c  
¥:720.00



**F71-07-0224**  
147 13A多功能双USB带五位  
孔插座  
147 type 13A multi-functional socket  
with 5 pin multi-functional socket  
¥:389.00



**F71-07-0225**  
147 二位电脑插座带二位  
USB插座  
147 type double computer with  
2USB socket  
¥:460.00



**F71-07-0226**  
147 二位电话带二位电脑  
插座  
147 double telephone with double  
computer socket  
¥:390.00



**F71-07-0227**  
147 二位电脑插座带16A  
多功能插座  
147 double computer with 16A  
MF pin socket  
¥:333.00



**F71-07-0228**  
147 二位16A法式插座带防水  
147 two position 16A German socket  
with waterproof  
¥:350.00



**F71-07-0229**  
147 二位16A法式插座带防水  
147 two position 16A French socket  
with waterproof  
¥:350.00



**F71-07-0230**  
147 二位开关二位16A法式插座  
带指示灯+USB+type-c (小板)  
147 double switch double German  
socket+USB+type-c with light  
¥:500.00



**F71-07-0231**  
147 二位开关二位16A法式插座  
带指示灯+USB+type-c (小板)  
147 double switch double French  
socket+USB+type-c with light  
¥:500.00



**F71-07-0232**  
147 二位开关一位16A德式插座  
(带指示灯)  
147 two switch double 16A German  
socket with light  
¥:190.00



**F71-07-0233**  
147 二位开关二位16A法式插座  
(带指示灯)  
147 two switch double 16A French  
socket with light  
¥:190.00



**F71-07-0234**  
147 二位开关二位16A德式插座  
带指示灯+二位USB (小板)  
147 two switch double 16A German  
socket + 2usb with light  
¥:440.00



**F71-07-0235**  
147 二位开关二位16A法式插座  
带指示灯+二位USB (小板)  
147 two switch double 16A French  
socket + 2USB with light  
¥:440.00



**F71-07-0236**  
147 二位10A二三位五孔插座  
+小开关 (带指示灯)  
147 double 10A 5 pin socket+4USB  
two line switch with indicator light  
¥:390.00



**F71-07-0237**  
147 一位开13A多功能五孔  
插座带双USB  
147 two switch and double 13A  
MF 5 pin socket (with indicator)  
¥:330.00



**F71-07-0238**  
147 二位双16A法式插座带  
四位USB (带指示灯)  
147 double 16A German socket  
4 USB (with indicator)  
¥:400.00



**F71-07-0239**  
147 二位双16A法式插座带  
四位USB (带指示灯)  
147 double 16A French socket  
4 USB (with indicator)  
¥:400.00



**F71-07-0240**  
147 二位一位空白面板  
147 Blank plate  
¥:28.00