

AB-G1

钢化玻璃水晶白
Tempered glass crystal white

设计与房间的良好互动
照明开关清新典雅的设计与房间完美贴合
开关不会淹没在视野之中
其他元素也自然浮现。

Good interaction between design and room
The fresh and elegant design of the lighting switch fits perfectly with the room
The switch will not be submerged in the field of vision
Other elements also naturally emerge.



- 2.5D玻璃
2.5D glass
- 强力融合
Plastic base material
- 塑胶基材
Plastic base material

- 语音/APP/轻触机械控制
Voice /APP/ touch mechanical control
- 情景模式/联动/定时
Scenario mode/linkage/timing
- 支持多款AI音响
Support a variety of AI audio
- 涂鸦无线涂鸦开关
(即火零火通用)
Doodle wireless scene switch
(Single fire and zero fire universal)

Zigbee智能按键开关 Zigbee Intelligent button switch



Zigbee一开 ¥1150.00 Zigbee二开 ¥1250.00 Zigbee三开 ¥1350.00 二三口USB/Type-c+开关 ¥240.00

联体产品 Conjoined products



二位联体面框
Two-position face frame
塑板/钢板:50.00
Plastic board/Steel plate:50.00



三位联体面框
Three-position face frame
塑板/钢板:70.00
Plastic board/Steel plate:70.00



四位联体面框
Four-position face frame
塑板/钢板:90.00
Plastic board/Steel plate:90.00



五位联体面框
Five-position face frame
塑板/钢板:110.00
Plastic board/Steel plate:110.00

模块颜色 / Module Color

- 珍珠白 Pearl White
- 香槟金 Champagne gold
- 太空灰 Space gray
- 摩卡黑 Mocha Black
- 欧泊蓝 Opal blue



AB-G1 钢化玻璃水晶白



AB-G1-0001
一位触摸开关(零火线) Y:400.00
1 gang 1 way touch switch
蓝牙WiFi一位触摸开关(零火线) Y:500.00
1 gang 1 way touch switch
涂鸦Zigbee一位触摸开关(零火线) Y:600.00
1 gang 1 way touch switch



AB-G1-0011
大板16A英式门控开关
Large panel British gating switch
Y:109.00



AB-G1-0021
大板13A方角插座
13A square corner socket
Y:109.00



AB-G1-0031
大板一位开关带13A方角插
+二位USB(指示灯)
Board one position switch with
13A square angle plug +
two position USB (indicator)
Y:295.00



AB-G1-0041
大板二位电话电脑插座
TV+telephone socket Y:158.00
大板一位电话电脑插座
TV+computer socket Y:168.00
大板一位电视电脑插座
(超六类) Y:208.00
TV+computer socket(6)



AB-G1-0051
小板16A门控开关
gating switch
Y:109.00



AB-G1-0002
二位触摸开关(零火线) Y:450.00
2 gang 1 way touch switch
蓝牙WiFi二位触摸开关(零火线) Y:550.00
2 gang 1 way touch switch
涂鸦Zigbee二位触摸开关(零火线) Y:650.00
2 gang 1 way touch switch



AB-G1-0012
大板16A门铃开关
Large panel doorbell switch
Y:109.00



AB-G1-0022
大板二位USB带16A多功能孔插座
2 USB with 5 pin multi-function socket
Y:213.00



AB-G1-0032
大板16A德式插座
Large board 16A German socket
Y:163.00



AB-G1-0042
大板二位电视插座
Two TV socket
Y:158.00



AB-G1-0052
小板16A英式门控开关
British gating switch
Y:109.00



AB-G1-0003
三位触摸开关(零火线) Y:500.00
3 gang 1 way touch switch
蓝牙WiFi三位触摸开关(零火线) Y:600.00
3 gang 1 way touch switch
涂鸦Zigbee三位触摸开关(零火线) Y:700.00
3 gang 1 way touch switch



AB-G1-0013
大板20A双极开关带指示灯
20A bipolar switch with indicator
light Y:168.00
大板3A双极开关带指示灯
3A bipolar switch with indicator
light Y:186.00



AB-G1-0023
大板16A一位开关带16A三极插座
1gang1 way switch and 16A 3 pole socket
Y:140.00
大板16A一位开关带16A三极插座
1gang2 way switch and 16A 3 pole socket
Y:143.00



AB-G1-0033
大板16A法式插座
Large plate 16A French socket
Y:163.00



AB-G1-0043
大板二位电视插座
Two TV socket Y:158.00
大板二位电脑插座
Two computer socket Y:178.00
大板二位电视插座(超六类)
Y:258.00
大板电话+电脑插座(超六类)
Y:168.00
大板电话+电脑插座
大板电话+电脑插座(超六类)
telephone+computer socket
Y:208.00



AB-G1-0053
小板16A门铃开关
doorbell switch
Y:109.00



AB-G1-0004
四位触摸开关(零火线) Y:550.00
4 gang 1 way touch switch
蓝牙WiFi四位触摸开关(零火线) Y:650.00
4 gang 1 way touch switch
涂鸦Zigbee四位触摸开关(零火线) Y:750.00
4 gang 1 way touch switch



AB-G1-0014
大板45A双极开关带指示灯
45A bipolar switch with indicator
light Y:200.00



AB-G1-0024
大板16A一位开关带16A三极插座
1gang2 way switch and 16A 3 pole socket
Y:140.00
大板16A一位开关带16A三极插座
1gang2 way switch and 5 pole socket
Y:143.00



AB-G1-0034
大板16A俄式插座
Large board 16A Russian socket
Y:163.00



AB-G1-0044
大板空白面板
Large blank panel
Y:80.00



AB-G1-0054
小板16A一位开关单控
1 gang 1 way toggle switch
Y:175.00
小板16A一位开关双控
1 gang 2 way toggle switch
Y:180.00



AB-G1-0005
大板16A一位开关单控
1 gang 1 way switch Y:86.00
大板16A一位开关双控
Large panel 16A 1 gang 2 way switch
Y:90.00
大板16A一位开关三控
Large panel 16A 1 gang 3 way switch
Y:123.00



AB-G1-0015
大板16A三极插座
16A 3 pole socket
Y:109.00



AB-G1-0025
大板10A二位开关带三极插座
2 gang 1 way switch and 3 pole socket
Y:167.00
大板10A二位开关带三极插座
2 gang 2 way switch and 5 pole socket
Y:167.00



AB-G1-0035
大板16A德式插座+二位USB
German socket+2 USB
Y:255.00



AB-G1-0045
小板16A一位开关单控
16A 1 gang 1 way switch Y:87.00
小板16A一位开关双控
16A 1 gang 2 way switch Y:90.00
小板16A一位开关多控
16A 1 gang more way switch Y:123.00



AB-G1-0055
小板16A一位开关单控
2 gang 1 way toggle switch
Y:190.00
小板16A一位开关双控
2 gang 2 way toggle switch
Y:200.00



AB-G1-0006
大板16A二位开关单控
Large panel 16A 2 gang 1 way switch
Y:109.00
大板16A二位开关双控
Large panel 16A 2 gang 2 way switch
Y:110.00
大板16A二位开关多控
Large panel 16A 2 gang 3 way switch
Y:158.00



AB-G1-0016
大板16A多功能插座
16A 3 pin universal socket
Y:109.00



AB-G1-0026
大板一位开关带16A三极多功能
插座(带指示灯)
1 gang switch and 16A 3 pin multi-
purpose socket with indicator light
Y:146.00



AB-G1-0036
大板16A法式插座+二位USB
French socket + 2 USB
Y:255.00



AB-G1-0046
小板16A二位开关单控
16A 2 gang 1 way switch Y:109.00
小板16A二位开关双控
16A 2 gang 2 way switch Y:110.00
小板16A二位开关多控
16A 2 gang more way switch Y:158.00



AB-G1-0056
小板16A一位开关单控
3 gang 1 way toggle switch
Y:205.00
小板16A一位开关双控
3 gang 2 way toggle switch
Y:220.00



AB-G1-0007
大板16A三位开关单控
Large panel 16A 3 gang 1 way switch
Y:139.00
大板16A三位开关双控
Large panel 16A 3 gang 1 way switch
Y:156.00



AB-G1-0017
大板10A二极插座
10A 5 pole socket
Y:93.00



AB-G1-0027
大板一位双极开关带13A方角插座
(指示灯)
Large board one position bipolar switch
with 13A square angle socket
with indicator light
Y:139.00



AB-G1-0037
大板16A德标插座+USB/Type-C
Large board 16A German socket
+ USB / type-C
Y:255.00



AB-G1-0047
小板16A三位开关单控
16A 3 gang 1 way switch
Y:139.00
小板16A三位开关双控
16A 3 gang 2 way switch
Y:156.00



AB-G1-0057
小板16A一位开关单控
4 gang 1 way toggle switch
Y:220.00
小板16A一位开关双控
4 gang 2 way toggle switch
Y:240.00



AB-G1-0008
大板16A四位开关单控
Large panel 16A 4 gang 1 way switch
Y:169.00
大板16A四位开关双控
Large panel 16A 4 gang 2 way switch
Y:183.00



AB-G1-0018
大板10A二位三极插座
10A Two or three pole socket
Y:117.00



AB-G1-0028
大板一位开关带15A圆孔插座(带指示灯)
1 gang switch and 15A 3 square pin socket
with indicator light
Y:146.00



AB-G1-0038
大板16A法式插座+USB/Type-C
Large board 16A French socket
+ USB / type-C
Y:255.00



AB-G1-0048
小板16A四位开关单控
16A 4 gang 1 way switch
Y:169.00
小板16A四位开关双控
16A 4 gang 2 way switch
Y:183.00



AB-G1-0058
小板20A双极开关带指示灯
20A switch with indicator light
Y:165.00
小板45A双极开关带指示灯
45A switch with indicator light
Y:185.00



AB-G1-0009
大板16A带升降开关
Large panel lower window filter switch
Y:145.00



AB-G1-0019
大板16A多功能五孔插座
16A MF 5 pin socket
Y:128.00



AB-G1-0029
大板一位开关带16A二极多功能
插座(带指示灯)
1 gang switch and 5 pin multi-function socket
with indicator light
Y:152.00



AB-G1-0039
大板一位电视插座
TV socket
Y:128.00



AB-G1-0049
小板16A三位开关多控
16A 3 gang 3 way switch
Y:230.00



AB-G1-0059
小板45A双极开关带指示灯
45A switch with indicator light
Y:185.00



AB-G1-0010
大板16A门铃开关
Large panel gating switch
Y:109.00



AB-G1-0020
大板10A二极三极插座
10A 7 pole socket
Y:128.00



AB-G1-0030
大板一位开关带13A多功能插座
+二位USB(指示灯)
Large board one position switch with
13A multi-function socket + 2USB
(indicator)
Y:295.00



AB-G1-0040
大板一位电话插座
telephone socket Y:128.00
大板一位电脑插座
computer socket Y:138.00
大板一位电脑插座(超六类)
computer socket(6) Y:178.00



AB-G1-0050
小板16A带升降开关
lower window filter switch
Y:145.00



AB-G1-0060
小板16A卷帘门限位开关
16A shutter reset switch
Y:195.00

AB-G1 钢化玻璃水晶白



AB-G1-0061
小板16A德式插座
German socket
¥:146.00



AB-G1-0062
小板16A法式插座
French socket
¥:146.00



AB-G1-0063
小板16A俄式插座
Russian socket
¥:146.00



AB-G1-0064
小板16A以色列插座
Israel socket
¥:165.00



AB-G1-0065
小板16A意大利+德式插座
Italy-German socket
¥:165.00



AB-G1-0066
小板10A二极插座
10A 2 pole socket
¥:126.00



AB-G1-0067
小板10A二极插座
10A Double 2 pole socket
¥:139.00



AB-G1-0068
小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:139.00



AB-G1-0069
小板10A一位开关带二极插座
1 gang switch and 4 pole socket
¥:146.00



AB-G1-0070
小板16A多功能三极插座
16A MF 3 pin socket
¥:109.00



AB-G1-0071
小板13A二三极多功能插座
5 pin multi-function socket
¥:128.00



AB-G1-0072
小板13A四位多五孔插座
Dislocation multi 5 pin multi function socket
¥:128.00



AB-G1-0073
小板13A方角插座
13A square corner socket
¥:109.00



AB-G1-0074
小板13A侧插插座
13A 3 round pins socket
¥:128.00



AB-G1-0075
小板13A美国三极插座
13A three flat American 3 pin universal socket
¥:128.00



AB-G1-0076
小板15A泰式插座
15A Thai socket
¥:128.00



AB-G1-0077
小板15A泰式六孔插座
Small plate 15A Thai six hole socket
¥:138.00



AB-G1-0078
小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:136.00



AB-G1-0079
小板一位开关带15A侧插插座
1 gang switch and 15A 3 round pin socket
¥:143.00



AB-G1-0080
小板一位开关带16A三极插座
1 gang French and 3 pin MF socket
¥:143.00



AB-G1-0081
小板一位开关带13A方角插座
(带指示灯)
1 gang switch and 13A square pin socket with indicator light
¥:139.00



AB-G1-0082
小板一位开关带15A侧插插座
(带指示灯)
1 gang switch and 15A 3 round pins socket with indicator light
¥:146.00



AB-G1-0083
小板一位开关带16A多功能插座
(带指示灯)
1 gang switch and 16A MF 3 pin socket with light
¥:146.00



AB-G1-0084
小板一位开关带13A多功能五孔插座
(带指示灯)
1 gang switch and 5 pin multi-function socket with indicator light
¥:152.00



AB-G1-0085
小板16A德式插座+二位USB
2 USB with German socket
¥:225.00



AB-G1-0086
小板16A法式插座带二位USB
2 USB with French socket
¥:225.00



AB-G1-0087
小板16A德式插座+USB/Type-c
Small board 16A German socket + USB / type-c
¥:225.00



AB-G1-0088
小板16A法式插座+USB/Type-c
Small board 16A French socket + USB / type-c
¥:225.00



AB-G1-0089
小板16A一位开关带德式插座
16A German socket
¥:165.00



AB-G1-0090
小板16A一位开关带法式插座
1 gang French socket
¥:165.00



AB-G1-0091
小板16A德式插座带防水
German socket and Waterproof belt
¥:135.00



AB-G1-0092
小板16A法式插座带防水
French socket and Waterproof belt
¥:155.00



AB-G1-0093
小板二位USB带13A方角插座
(横)
2 USB with 13A square corner socket with switch
¥:225.00



AB-G1-0094
小板15A美式+USB/Type-c
15A American Standard + USB / type-c
¥:225.00



AB-G1-0095
小板15A美式+USB/Type-c
15A Thai + USB / type-c
¥:225.00



AB-G1-0096
小板二位USB带13A方角插座
(带保护门)
2 USB with 13A square corner socket with flip cover
¥:225.00



AB-G1-0097
小板二位USB带13A多功能插座
(带保护门)
2 USB with 3 pin multi-purpose socket with flip cover
¥:225.00



AB-G1-0098
小板一位开关13A多功能插座带指示灯
(带保护门)
1 gang switch and 13A square corner socket with indicator light with flip cover
¥:225.00



AB-G1-0099
小板一位开关13A方角插座带指示灯
+二位USB
Small board one position switch 13A square corner socket with indicator light + two position USB
¥:225.00



AB-G1-0100
小板13A多功能带Type-c+USB
13A multifunction with type-C + USB
¥:225.00



AB-G1-0101
小板13A方角插座Type-c+USB
13A square angle band type-C + USB
¥:225.00



AB-G1-0102
小板一位开关13A多功能插座带Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose socket with type-c+USB(with light)
¥:225.00



AB-G1-0103
小板二位USB带13A多功能插座
带小开关(竖)
2 USB with three very multi-purpose socket with switch
¥:235.00



AB-G1-0104
小板一位开关13A方角插座Type-c+USB(带指示灯)
1 gang switch 13A square insert belt Type-c+USB(with light)
¥:225.00



AB-G1-0105
小板二位USB带13A方角插座
带小开关
2 USB with 13A square corner socket with switch
¥:235.00



AB-G1-0106
小板15A美式插座+二位USB插座
15A American Standard + 2USB
¥:225.00



AB-G1-0107
小板15A泰式+二位USB插座
15A Thai + 2USB
¥:225.00



AB-G1-0108
小板二位USB带13A多功能插座(横)
2 USB with 3 pin multi-purpose socket
¥:225.00



AB-G1-0109
小板二位USB带10A二极插座
2 USB and 5 pin socket
¥:185.00



AB-G1-0110
小板二位USB带10A二三极插座
带开关
2 USB and 5 pin socket with switch
¥:195.00



AB-G1-0111
小板10A五孔插座带USB+Type-c(10W)
10A 5 pole socket with USB type-C(10W)
¥:185.00
小板10A五孔插座带USB+Type-c(18W)
10A 5 pole socket with USB type-C(18W)
¥:290.00



AB-G1-0112
小板一位开关13A多功能五孔插座带USB
1 gang switch and 5 pin multi-function socket with USB and indicator light
¥:230.00



AB-G1-0113
小板二位USB带13A多功能插座+二位USB
Small board 13A two three pole multi function socket + 2 USB
¥:180.00



AB-G1-0114
小板一位开关13A二极多功能插座+二位USB
带小开关
Small board 13A two three pole multi-function socket + 2 USB With small switch
¥:190.00



AB-G1-0115
小板13A多功能五孔插座带USB+Type-C(10W)
13A MF 5 pin socket USB+type-C(10W)
¥:180.00
小板13A多功能五孔插座带USB+Type-C(18W)
13A MF 5 pin socket USB+type-C(18W)
¥:290.00



AB-G1-0116
小板一位电视插座
TV socket
¥:128.00



AB-G1-0117
小板一位电话插座
telephone socket
¥:128.00
小板一位电脑插座
computer socket
¥:138.00
小板一位电脑插座(超六类)
computer socket(6)
¥:178.00



AB-G1-0118
小板双电视插座
Two TV socket
¥:158.00































































AB-G1-0119
小板双电话插座
Two telephone socket
¥:158.00
小板双电脑插座
Two computer socket
¥:178.00
小板双电话插座(超六类)
Two telephone socket(6)
¥:258.00
小板双电脑插座(超六类)
Two computer socket(6)
¥:168.00
小板电话电脑插座
telephone-computer socket
¥:208.00
小板电话电脑插座(超六类)
telephone-computer socket(6)
¥:208.00































































AB-G1-0120
小板电视电话插座
TV+telephone socket
¥:158.00
小板电视电脑插座
TV+computer socket
¥:168.00
小板电视电脑插座(超六类)
TV+computer socket(6)
¥:208.00

AB-G1 钢化玻璃水晶白

 <p>AB-G1-0121 小板一位电话带USB插座 TV+USB socket 小板一位电脑带USB插座 computer+USB socket 小板一位电脑带USB插座 (超六类) computer+USB socket(6)</p> <p>¥:280.00 ¥:290.00 ¥:330.00</p>	 <p>AB-G1-0131 小板单联音频插座 Single audio socket</p> <p>¥:202.00</p>	 <p>AB-G1-0141 紧急呼叫开关 Emergency call switch</p> <p>¥:210.00</p>	 <p>AB-G1-0151 一位开关带调光开关500W 1 gang with dimmer switch 500W</p> <p>¥:212.00</p>	 <p>AB-G1-0161 HDMI+USB+3.5音频 HDMI+USB+3.5 ¥:288.00</p>	 <p>AB-G1-0171 二分之一—VGA+HDMI Half VGA+HDMI ¥:288.00</p>
 <p>AB-G1-0122 小板一位TV+FM TV and FM</p> <p>¥:198.00</p>	 <p>AB-G1-0132 小板双联音频插座 Double audio socket</p> <p>¥:275.00</p>	 <p>AB-G1-0142 请勿打扰请勿清理门铃开关 (按键式) Do not disturb please namely cleaning please:late doorbell "button" ¥:250.00</p>	 <p>AB-G1-0152 一位开关带调速开关500W 1 gang with speed switch 500W</p> <p>¥:212.00</p>	 <p>AB-G1-0162 VGA+USB+3.5音频 VGA+USB+3.5 ¥:288.00</p>	 <p>AB-G1-0172 45A出线柱 45A Outlet ¥:248.00</p>
 <p>AB-G1-0123 小板一位卫星插座 Satellite socket</p> <p>¥:148.00</p>	 <p>AB-G1-0133 触摸延时开关(节能) Touch delay switch ¥:202.00</p>	 <p>AB-G1-0143 请勿打扰门铃开关(按键式) Do not disturb-doorbell "button" ¥:385.00</p>	 <p>AB-G1-0153 13A开关带保险丝(带指示灯) 13A switch with fuse with neon ¥:239.00</p>	 <p>AB-G1-0163 AV+3.5音频 AV+3.5 ¥:288.00</p>	 <p>AB-G1-0173 空白面板 Blank plate ¥:102.00</p>
 <p>AB-G1-0124 小板一位卫星插座 Double satellite socket</p> <p>¥:175.00</p>	 <p>AB-G1-0134 声光控制延时开关(节能) Sound-light controlled delay switch (energy saving) ¥:202.00</p>	 <p>AB-G1-0144 请勿打扰请勿清理门铃开关 (按键式) Do not disturb please namely cleaning please: "button" ¥:475.00</p>	 <p>AB-G1-0154 小板20A出线柱 20A outgoing post ¥:221.00</p>	 <p>AB-G1-0164 VGA+AV音频接口 VGA+AV audio interface ¥:288.00</p>	 <p>AB-G1-0174 大板二位双联开关带二位13A方角 插座(带指示灯) Large board two position bipolar switch with two position 13A square angle socket (indicator) ¥:258.00</p>
 <p>AB-G1-0125 小板卫星+电视插座 Satellite and TV socket</p> <p>¥:166.00</p>	 <p>AB-G1-0135 红外线人体感应开关 Human body induction ¥:220.00</p>	 <p>AB-G1-0145 智能音乐控制开关 Intelligent music control switch ¥:2950.00</p>	 <p>AB-G1-0155 剃须插座 Shave socket ¥:450.00</p>	 <p>AB-G1-0165 HDMI+AV音频接口 HDMI+AV audio interface ¥:288.00</p>	 <p>AB-G1-0175 大板二位开关带二位16A多功能 插座(带指示灯) 147 Low switch and double 16A MF socket with light ¥:258.00</p>
 <p>AB-G1-0126 小板卫星带电话插座 Satellite and telephone socket 小板卫星带电脑插座 Satellite and computer socket 小板卫星带电脑插座(超六类) Satellite and computer socket(6)</p> <p>¥:166.00 ¥:175.00 ¥:215.00</p>	 <p>AB-G1-0136 凹型脚踏灯(亮光/暖光) The footlights ¥:395.00</p>	 <p>AB-G1-0146 温度控制调节开关 Temperature control switch ¥:800.00</p>	 <p>AB-G1-0156 USB+电脑插座+无线路由 USB-computer socket wireless router ¥:800.00</p>	 <p>AB-G1-0166 二分之一—AV音频+卫星 Half AV audio interface+Satellite ¥:288.00</p>	 <p>AB-G1-0176 147二位开关带二位13A方角插座 带二位USB-(带指示灯) 147 Low switch and double 13A square corner socket with two USB light ¥:358.00</p>
 <p>AB-G1-0127 小板二位插带带电视插座 2 pin socket with TV ¥:290.00</p>	 <p>AB-G1-0137 凹型红外线人体感应脚踏灯 (亮光/暖光) The human body induction footlights ¥:330.00</p>	 <p>AB-G1-0147 温度控制调节开关 Tuning switch/control switch ¥:850.00</p>	 <p>AB-G1-0157 蓝牙+3.5音频+二位USB+HDMI Bluetooth audio+3.5+USB+HDMI ¥:2520.00</p>	 <p>AB-G1-0167 二分之一—AV音频+USB+3.5音频 Half AV audio interface+USB+3.5 ¥:288.00</p>	 <p>AB-G1-0177 大板二位开关带二位16A多功能插座 +双USB(带指示灯) 147 Low switch and double 16A MF socket + 2USB with light ¥:358.00</p>
 <p>AB-G1-0128 小板二极插座带电话插座 2 pin socket with telephone 小板二极插座带电脑插座 2 pin socket with computer 小板二极插座带电脑插座 (超六类) 2 pin socket with computer</p> <p>¥:290.00 ¥:290.00 ¥:330.00</p>	 <p>AB-G1-0138 平面脚踏灯(亮光/暖光) footlights ¥:395.00</p>	 <p>AB-G1-0148 调音开关 Tuning switch ¥:260.00</p>	 <p>AB-G1-0158 HDMI ¥:288.00</p>	 <p>AB-G1-0168 二分之一—VGA+TV Half VGA+TV ¥:288.00</p>	 <p>AB-G1-0178 大板147型二位开关带二位13A方插 +USB/type-c(带指示灯) Large board 147 two position switch with two position 13A square plug +USB / type-c (indicator) ¥:388.00</p>
 <p>AB-G1-0129 小板一位光纤插座 Optical fiber socket ¥:390.00</p>	 <p>AB-G1-0139 叮咚门铃 Ding dong doorbell ¥:245.00</p>	 <p>AB-G1-0149 调光开关300W Dimming 300W ¥:198.00 调光开关600W Dimming 600W ¥:225.00 调光开关1000W Dimming 1000W ¥:252.00</p>	 <p>AB-G1-0159 USB+Type-c ¥:324.00</p>	 <p>AB-G1-0169 二分之一—VGA+电脑 Half VGA+Computer ¥:288.00</p>	 <p>AB-G1-0179 大板147型二位开关带二位13A多功能 插座+USB/type-c(带指示灯) Large plate 147 two position switch with two position 13A multifunction +USB / type-c (indicator) ¥:388.00</p>
 <p>AB-G1-0130 小板二位USB插座 Double USB socket ¥:230.00</p>	 <p>AB-G1-0140 机械式40A插卡取电 Mechanical card for electricity ¥:280.00 感应式低频40A插卡取电 Low frequency induction card ¥:400.00 感应式高频40A插卡取电 High frequency induction card for electricity ¥:460.00</p>	 <p>AB-G1-0150 调速开关400W Speed 300W ¥:198.00 调速开关600W Speed 600W ¥:225.00 调速开关1000W Speed 1000W ¥:252.00</p>	 <p>AB-G1-0160 HDMI+USB ¥:288.00</p>	 <p>AB-G1-0170 二分之一—VGA+USB Half VGA+USB ¥:288.00</p>	 <p>AB-G1-0180 147型45A双联开关+一开 13A方角插带灯(带开关) 147 type 45A bipolar switch + 13A square angle plug With light (stove switch) ¥:310.00</p>

AB-G1 钢化玻璃水晶白

 <p>AB-G1-0181 147型45A双极开关带指示灯 147 type 45A bipolar switch with indicator light ¥:280.00</p>	 <p>AB-G1-0182 147型空白面板 147 blank panel ¥:185.00</p>	 <p>AB-G1-0183 小板147型16A二位开关单控 Small plate 147 type 16A two position switch single control ¥:212.00 小板147型16A二位开关双控 Small plate 147 type 16A two position switch double control ¥:218.00</p>	 <p>AB-G1-0184 小板147型16A二位开关单控 Small plate 147 type 16A 2 gang 2 way switch ¥:230.00 小板147型16A二位开关双控 Small plate 147 type 16A 3 gang 2 way switch ¥:239.00</p>	 <p>AB-G1-0185 小板147型16A四位开关单控 Small plate 147 type 16A 4 gang 1 way switch ¥:248.00 小板147型16A四位开关双控 Small plate 147 type 16A 4 gang 2 way switch ¥:259.00</p>	 <p>AB-G1-0186 小板147型16A五位开关单控 Small plate 147 type 16A 5 gang 1 way switch ¥:256.00 小板147型16A五位开关双控 Small plate 147 type 16A 5 gang 2 way switch ¥:280.00</p>	 <p>AB-G1-0187 小板147型16A六位开关单控 Small plate 147 type 16A 6 gang 1 way switch ¥:280.00 小板147型16A六位开关双控 Small plate 147 type 16A 6 gang 2 way switch ¥:301.00</p>	 <p>AB-G1-0188 小板147型16A七位开关单控 Small plate 147 type 16A 7 gang 1 way switch ¥:302.00 小板147型16A七位开关双控 Small plate 147 type 16A 7 gang 2 way switch ¥:321.00</p>	 <p>AB-G1-0189 小板147型16A八位开关单控 Small plate 147 type 16A 8 gang 1 way switch ¥:320.00 小板147型16A八位开关双控 Small plate 147 type 16A 8 gang 2 way switch ¥:342.00</p>	 <p>AB-G1-0190 147 二位16A多功能三极插座 147 Double 13A MF 3 pin socket ¥:248.00</p>	 <p>AB-G1-0191 147 二位13A多功能五孔插座 147 Double 5 pin multi-function socket ¥:281.00</p>	 <p>AB-G1-0192 小板147型二位15A美标插座 Small plate 147 two position 15A American standard flat socket ¥:279.00</p>	 <p>AB-G1-0193 147 二位15A欧式多功能六孔插座 147 Double 15A Thai MF six-hole socket ¥:279.00</p>	 <p>AB-G1-0194 147 二位13A方角插座 147 Double 13A square corner ¥:248.00</p>	 <p>AB-G1-0195 147 二位15A三极插座 147 Double 15A 3 round pins socket ¥:279.00</p>	 <p>AB-G1-0196 小板147型二位13A错位多功能三极插座 147 type Double 13A dislocation MF 3 pin socket ¥:299.00</p>	 <p>AB-G1-0197 147型小板二位10A三极插座 147 type Double 10A two and three pole socket ¥:225.00</p>	 <p>AB-G1-0198 147 二位开关带二位13A方角插座 147 low switch and double 13A square corner socket ¥:257.00</p>	 <p>AB-G1-0199 147 二位开关带二位13A多功能插座 147 low switch and double 13A MF 3 pin socket with light ¥:257.00</p>	 <p>AB-G1-0200 小板147型二位开关二位13A多功能三极插座 Small board 147 two position switch two position 13A multi-function three pole socket ¥:284.00</p>	 <p>AB-G1-0201 147 二位开关带二位13A方角插座 (带指示灯) 147 low switch and double 13A square corner socket with indicator light ¥:258.00</p>	 <p>AB-G1-0202 147 二位开关带二位13A多功能插座 (带指示灯) 147 low switch and double 13A MF socket with light ¥:258.00</p>	 <p>AB-G1-0203 147 二位开关带二位13A方角插座带二位USB 147 Double 13A Thai MF square socket with 2USB ¥:358.00</p>	 <p>AB-G1-0204 147 二位开关带二位13A多功能带二位USB 147 low switch and double 13A MF socket+2USB ¥:358.00</p>	 <p>AB-G1-0205 147 二位开关二位13A方插+USB/Type-C (小板) 147 two switch Double 13A square plug+USB/Type-C ¥:358.00</p>	 <p>AB-G1-0206 147 二位开关二位13A多功能+USB/Type-C (小板) 147 two switch Double 13A square round pins socket with indicator light ¥:358.00</p>	 <p>AB-G1-0207 147 二位开关带二位15A侧角插座 (带指示灯) 147 low switch and double 15A 3 round pins socket with indicator light ¥:293.00</p>	 <p>AB-G1-0208 147 二位开关带二位13A方角插座 147 low switch and double 13A square Angle socket (with neon) ¥:293.00</p>	 <p>AB-G1-0209 147 四孔剃须插座 147 two shaving socket ¥:612.00</p>	 <p>AB-G1-0210 147 45A开关+一位开关16A多功能插座带指示灯 (组合厨房开关) 147 kitchen switch ¥:346.00</p>	 <p>AB-G1-0211 147 45A开关+一位开关13A方角插座带指示灯 (组合厨房开关) 147 kitchen switch + 13A square corner socket with indicator light ¥:346.00</p>	 <p>AB-G1-0212 147 型45A双极开关+一位开关13A方角插座 (带指示灯) 147 type 45A bipolar switch + 13A square angle plug with light (below switch) ¥:374.00</p>	 <p>AB-G1-0213 147 型45A双极开关带指示灯 147 type 45A bipolar switch with indicator light ¥:324.00</p>	 <p>AB-G1-0214 147 16A二位法式插座 147 Double German socket ¥:293.00</p>	 <p>AB-G1-0215 147 16A二位法式插座 147 Double French socket ¥:293.00</p>	 <p>AB-G1-0216 小板147型二位16A插座 Small plate 147 connected two position German standard socket ¥:293.00</p>	 <p>AB-G1-0217 小板147型二位16A插座 Small plate 147 connected two position normal socket ¥:293.00</p>	 <p>AB-G1-0218 147 二位16A法式插座+USB/Type-C (小板) 147 double 16A German with USB/Type-C ¥:390.00</p>	 <p>AB-G1-0219 147 二位16A法式插座+USB/Type-C (小板) 147 double 16A French with USB/Type-C ¥:390.00</p>	 <p>AB-G1-0220 小板147型二位16A法式插座+二位USB 147 double 16A German+2USB ¥:369.00</p>	 <p>AB-G1-0221 小板147型二位16A法式+二位USB 147 Double 16A German+2USB ¥:369.00</p>	 <p>AB-G1-0222 147 四位USB插座 147 4 USB socket ¥:477.00</p>	 <p>AB-G1-0223 147 二位多功能插座+4USB+二位USB插座 147 2 bit multi-function socket + 4USB + 2 USB socket ¥:414.00</p>	 <p>AB-G1-0224 147 二位13A方角插座+4USB 147 two bit 13A square socket + 4USB ¥:414.00</p>	 <p>AB-G1-0225 小板147型13A方角插座+二位USB Small board 147 type 13A square corner socket + 2 USB ¥:376.00</p>	 <p>AB-G1-0226 147 一位16A多功能插座 (带指示灯) 147 13A MF 3 pin socket + 2 USB (with indicator) ¥:376.00</p>	 <p>AB-G1-0227 147型二位开关二位13A多功能五孔+双USB 147 two switch and double 13A MF 5 pin + 2USB ¥:374.00</p>	 <p>AB-G1-0228 147 一位开关带二位13A多功能五孔插座+2USB (带指示灯) 147 two position switch with two position 13A multi-function five hole socket + 2 USB (with indicator) ¥:522.00</p>	 <p>AB-G1-0229 147 二位13A多功能五孔插座+四位USB 147 double 13A multi-function socket+4USB ¥:414.00</p>	 <p>AB-G1-0230 小板147型二位16A法式插座+二位USB 147 double 16A German+2USB ¥:369.00</p>	 <p>AB-G1-0231 小板147型二位开关二位13A多功能五孔+USB/Type-C 147 two switch and double 13A MF 5 pin + USB / type-C ¥:495.00</p>	 <p>AB-G1-0232 147 二位开关带二位13A多功能插座+4USB (带指示灯) 147 two switch and double 13A MF + 4USB (with neon) ¥:432.00</p>	 <p>AB-G1-0233 147 二位开关带二位13A方角插座+4USB (带指示灯) 147 two switch and double 13A square Angle socket +4USB (with neon) ¥:329.00</p>	 <p>AB-G1-0234 147 二位开关二位16A法式插座带指示灯+USB/Type-C (小板) 147 two switch double German socket +USB/Type-C (with neon) ¥:495.00</p>	 <p>AB-G1-0235 147型二位开关二位16A法式插座带指示灯+USB/Type-C (小板) 147 two switch double French socket +USB/Type-C (with neon) ¥:495.00</p>	 <p>AB-G1-0236 147型二位开关二位16A插座 (带指示灯) 147 two switch double German socket (with neon) ¥:329.00</p>	 <p>AB-G1-0237 147型二位开关二位16A法式插座 (带指示灯) 147 two switch double French socket (with neon) ¥:329.00</p>	 <p>AB-G1-0238 147 二位开关带二位16A法式插座带指示灯+二位USB (小板) 147 two switch double 16A German socket with neon + 2USB ¥:405.00</p>	 <p>AB-G1-0239 147 二位开关二位16A法式插座带指示灯+二位USB (小板) 147 two switch double 16A French socket with 2USB (with neon) ¥:405.00</p>	 <p>AB-G1-0240 小板147型空白面板 147 Blank plate ¥:167.00</p>
--	--	--	--	--	--	--	--	--	---	---	--	---	--	--	--	---	---	--	--	---	---	---	--	--	--	--	--	---	--	---	---	---	--	--	---	--	---	---	--	--	--	--	---	---	--	---	--	--	---	--	--	---	--	--	---	--	--	--	--



ZIGBEE智能按键开关

ZIGBEE Intelligent button switch



Zigbee一开
¥1150.00

语音/APP/轻触机械控制
Voice /APP/ touch mechanical control



Zigbee二开
¥1250.00

情景模式/联动/定时
Scenario mode/linkage/timing



Zigbee三开
¥1350.00

支持多数AL音响
Support a variety of AL audio































































二USB/Type-c+开关
¥240.00

涂鸦无线场景开关
(即火零火通用)
Doodie wireless scene switch
(Single fire and zero fire universal)

AB-G2
钢化玻璃香槟金
Tempered glass champagne gold

AB-G2 Tempered glass champagne gold 钢化玻璃香槟金

	AB-G2-0001 一位触摸开关(零火线) 1 gang 1 way touch switch 蓝牙WiFi一位触摸开关(零火线) 1 gang 1 way touch switch 涂鸦Zigbee一位触摸开关(零火线) 1 gang 1 way touch switch	Y:400.00 Y:500.00 Y:600.00		AB-G2-0011 大板16A英式门控开关 Large panel British gating switch	Y:109.00		AB-G2-0021 大板13A方角插座 13A square corner socket	Y:109.00		AB-G2-0031 大板一位开关带13A方角插 +二位USB(指示灯) Board one position switch with 13A square angle plug + two position USB (indicator)	Y:295.00		AB-G2-0041 大板二位电话插座 TV+telephone socket 大板一位电话电脑插座 TV+computer socket 大板一位电话电脑插座 (超六类) TV+computer socket(6)	Y:158.00 Y:168.00 Y:208.00		AB-G2-0051 小板16A门控开关 gating switch	Y:109.00
	AB-G2-0002 二位触摸开关(零火线) 2 gang 1 way touch switch 蓝牙WiFi二位触摸开关(零火线) 2 gang 1 way touch switch 涂鸦Zigbee二位触摸开关(零火线) 2 gang 1 way touch switch	Y:450.00 Y:550.00 Y:650.00		AB-G2-0012 大板16A门铃开关 Large panel doorbell switch	Y:109.00		AB-G2-0022 大板二位USB带16A多功能孔插座 2 USB with 5 pin multi-function socket	Y:213.00		AB-G2-0032 大板16A德式插座 Large board 16A German socket	Y:163.00		AB-G2-0042 大板二位电视插座 Two TV socket	Y:158.00		AB-G2-0052 小板16A英式门控开关 British gating switch	Y:109.00
	AB-G2-0003 三位触摸开关(零火线) 3 gang 1 way touch switch 蓝牙WiFi三位触摸开关(零火线) 3 gang 1 way touch switch 涂鸦Zigbee三位触摸开关(零火线) 3 gang 1 way touch switch	Y:500.00 Y:600.00 Y:700.00		AB-G2-0013 大板20A双极开关带指示灯 20A bipolar switch with indicator light 大板32A双极开关带指示灯 32A bipolar switch with indicator light	Y:168.00 Y:186.00		AB-G2-0023 大板16A一位开关带16A三极插座 16A 1 way switch and 16A 3 pole socket 大板16A一位开关带16A三极插座 16A 1 way switch and 16A 3 pole socket	Y:140.00 Y:143.00		AB-G2-0033 大板16A法式插座 Large plate 16A French socket	Y:163.00		AB-G2-0043 大板二位电视插座 Two TV socket 大板二位电脑插座 Two computer socket 大板二位电视插座(超六类) 大板电话+电脑插座(超六类) telephone+computer socket 大板电话+电脑插座(超六类) telephone+computer socket(6)	Y:158.00 Y:178.00 Y:258.00 Y:168.00 Y:208.00		AB-G2-0053 小板16A门铃开关 doorbell switch	Y:109.00
	AB-G2-0004 四位触摸开关(零火线) 4 gang 1 way touch switch 蓝牙WiFi四位触摸开关(零火线) 4 gang 1 way touch switch 涂鸦Zigbee四位触摸开关(零火线) 4 gang 1 way touch switch	Y:550.00 Y:650.00 Y:750.00		AB-G2-0014 大板45A双极开关带指示灯 45A bipolar switch with indicator light	Y:200.00		AB-G2-0024 大板16A一位开关带16A三极插座 16A 1 way switch and 16A 3 pole socket 大板16A一位开关带16A三极插座 16A 1 way switch and 5 pole socket	Y:140.00 Y:143.00		AB-G2-0034 大板16A俄式插座 Large board 16A Russian socket	Y:163.00		AB-G2-0044 大板空白面板 Large blank panel	Y:80.00		AB-G2-0054 小板16A一位开关单控 1 gang 1 way toggle switch 小板16A一位开关双控 1 gang 2 way toggle switch	Y:175.00 Y:180.00
	AB-G2-0005 大板16A一位开关单控 16A 1 gang 1 way switch 大板16A一位开关双控 16A 1 gang 2 way switch 大板16A一位开关三控 16A 1 gang 3 way switch	Y:86.00 Y:90.00 Y:123.00		AB-G2-0015 大板16A三极插座 16A 3 pole socket	Y:109.00		AB-G2-0025 大板10A二位开关带二二三极插座 2 gang 1 way switch and 2 pole socket 大板10A二位开关带二二三极插座 2 gang 2 way switch and 5 pole socket	Y:167.00		AB-G2-0035 大板16A德式插座+二位USB German socket+2 USB	Y:255.00		AB-G2-0045 小板16A一位开关单控 16A 1 gang 1 way switch 小板16A一位开关双控 16A 1 gang 2 way switch 小板16A一位开关三控 16A 1 gang more way switch	Y:87.00 Y:90.00 Y:123.00		AB-G2-0055 小板16A一位开关单控 2 gang 1 way toggle switch 小板16A一位开关双控 2 gang 2 way toggle switch 小板16A一位开关三控 2 gang 3 way toggle switch	Y:190.00 Y:200.00 Y:200.00
	AB-G2-0006 大板16A二位开关单控 Large panel 16A 2 gang 1 way switch 大板16A二位开关双控 Large panel 16A 2 gang 2 way switch 大板16A二位开关三控 Large panel 16A 2 gang 3 way switch	Y:109.00 Y:110.00 Y:158.00		AB-G2-0016 大板16A多功能插座 16A 3 pin universal socket	Y:109.00		AB-G2-0026 大板一位开关带16A三极多功能 插座(带指示灯) 1 gang switch and 16A 3 pin multi- purpose socket with indicator light	Y:146.00		AB-G2-0036 大板16A法式插座+二位USB French socket + 2 USB	Y:255.00		AB-G2-0046 小板16A二位开关单控 16A 2 gang 1 way switch 小板16A二位开关双控 16A 2 gang 2 way switch 小板16A二位开关三控 16A 2 gang more way switch	Y:109.00 Y:110.00 Y:158.00		AB-G2-0056 小板16A一位开关单控 3 gang 1 way toggle switch Y:205.00 小板16A一位开关双控 3 gang 2 way toggle switch Y:220.00	Y:205.00 Y:220.00
	AB-G2-0007 大板16A三位开关单控 Large panel 16A 3 gang 1 way switch 大板16A三位开关双控 Large panel 16A 3 gang 1 way switch	Y:139.00 Y:156.00		AB-G2-0017 大板10A二二三极插座 10A 3 pole socket	Y:93.00		AB-G2-0027 大板一位双极开关带13A方角插座 (指示灯) Large board one position bipolar switch with 13A square angle socket indicator light	Y:139.00		AB-G2-0037 大板16A德式插座+USB/Type-C Large board 16A German socket + USB / type-C	Y:255.00		AB-G2-0047 小板16A三位开关单控 16A 3 gang 1 way switch 小板16A三位开关双控 16A 3 gang 2 way switch	Y:139.00 Y:156.00		AB-G2-0057 小板16A一位开关单控 4 gang 1 way toggle switch Y:220.00 小板16A一位开关双控 4 gang 2 way toggle switch Y:240.00	Y:220.00 Y:240.00
	AB-G2-0008 大板16A四位开关单控 Large panel 16A 4 gang 1 way switch 大板16A四位开关双控 Large panel 16A 4 gang 2 way switch	Y:169.00 Y:183.00		AB-G2-0018 大板10A带二二三极插座 10A Two or three pole socket	Y:117.00		AB-G2-0028 大板一位开关带15A圆孔插座(带指示灯) 1 gang switch and 15A 3 square pin socket with indicator light	Y:146.00		AB-G2-0038 大板16A法式插座+USB/Type-C Large board 16A French socket + USB / type-C	Y:255.00		AB-G2-0048 小板16A四位开关单控 16A 4 gang 1 way switch 小板16A四位开关双控 16A 4 gang 2 way switch	Y:169.00 Y:183.00		AB-G2-0058 大板20A双极开关带指示灯 20A switch with indicator light Y:165.00 大板45A双极开关带指示灯 45A switch with indicator light Y:185.00	Y:165.00 Y:185.00
	AB-G2-0009 大板16A带16A升降开关 Large panel lower window lifter switch	Y:145.00		AB-G2-0019 大板16A多功能五孔插座 16A MF 5 pin socket	Y:128.00		AB-G2-0029 大板一位开关带16A二二三极多功 能插座(带指示灯) 1 gang switch and 5 pin multi-function socket with indicator light	Y:152.00		AB-G2-0039 大板一位电话插座 TV socket	Y:128.00		AB-G2-0049 小板16A三位开关多控 16A 3 gang 3 way switch	Y:230.00		AB-G2-0059 小板45A双极开关带指示灯 45A switch with indicator light Y:185.00	Y:185.00
	AB-G2-0010 大板16A门铃开关 Large panel gating switch	Y:109.00		AB-G2-0020 大板10A二二三极插座 10A 7 pole socket	Y:128.00		AB-G2-0030 大板一位开关带13A多功能插座 +二位USB(指示灯) Large board one position switch with 13A multi-function socket + 2USB (indicator)	Y:295.00		AB-G2-0040 大板一位电话插座 telephone socket 大板一位电脑插座 computer socket 大板一位电脑插座(超六类) computer socket(6)	Y:128.00 Y:138.00 Y:178.00		AB-G2-0050 小板16A带16A升降开关 lower window lifter switch	Y:145.00		AB-G2-0060 小板16A带16A门铃开关 16A shutter reset switch	Y:195.00

AB-G2 钢化玻璃香槟金



AB-G2-0061
小板16A德式插座
German socket
¥:146.00



AB-G2-0062
小板16A法式插座
French socket
¥:146.00



AB-G2-0063
小板16A俄式插座
Russian socket
¥:146.00



AB-G2-0064
小板16A以色列插座
Israel socket
¥:165.00



AB-G2-0065
小板16A德夫利+带式插座
Baby-German socket
¥:165.00



AB-G2-0066
小板10A二极插座
10A 2 pole socket
¥:126.00



AB-G2-0067
小板10A二极插座
10A Double 2 pole socket
¥:139.00



AB-G2-0068
小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:139.00



AB-G2-0069
小板10A一位开关带二极插座
1 gang switch and 4 pole socket
¥:146.00



AB-G2-0070
小板16A多功能三极插座
16A MF 3 pin socket
¥:109.00



AB-G2-0071
小板13A二三极多功能插座
5 pin multi-function socket
¥:128.00



AB-G2-0072
小板13A错位多五孔插座
Dislocation multi 5 pin multi-function socket
¥:128.00



AB-G2-0073
小板13A方角插座
13A square corner socket
¥:109.00



AB-G2-0074
小板15A圆形插座
15A 3 round pins socket
¥:128.00



AB-G2-0075
小板15A美商三极插座
15A three flat American 3 pin universal socket
¥:128.00



AB-G2-0076
小板15A泰式插座
15A Thai socket
¥:128.00



AB-G2-0077
小板15A泰式六孔插座
Small plate 15A Thai six hole socket
¥:138.00



AB-G2-0078
小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:136.00



AB-G2-0079
小板一位开关带15A圆形插座
1 gang switch and 15A 3 round pin socket
¥:143.00



AB-G2-0080
小板一位开关带16A多功能插座
1 gang French socket and 3 pin MF socket
¥:143.00



AB-G2-0081
小板一位开关带13A方角插座
(带指示灯)
1 gang switch and 13A square pin socket with indicator light
¥:139.00



AB-G2-0082
小板一位开关带15A圆形插座
(带指示灯)
1 gang switch and 15A 3 round pins socket with indicator light
¥:146.00



AB-G2-0083
小板一位开关带16A多功能插座
(带指示灯)
1 gang switch and 16A MF 3 pin socket with light
¥:146.00



AB-G2-0084
小板一位开关带13A多功能五孔插座
(带指示灯)
1 gang switch and 5 pin multi-function socket with indicator light
¥:152.00



AB-G2-0085
小板16A德式插座+二位USB
2 USB with German socket
¥:225.00



AB-G2-0086
小板16A法式插座+二位USB
2 USB with French socket
¥:225.00



AB-G2-0087
小板16A德式插座+USB/Type-c
Small board 16A German socket + USB / type-c
¥:225.00



AB-G2-0088
小板16A法式插座+USB/Type-c
Small board 16A French socket + USB / type-c
¥:225.00



AB-G2-0089
小板16A一位开关带德式插座
Small board 16A German socket
¥:165.00



AB-G2-0090
小板16A一位开关带法式插座
1 gang French socket
¥:165.00



AB-G2-0091
小板16A德式插座带防水
German socket and Waterproof belt
¥:135.00



AB-G2-0092
小板16A法式插座带防水
French socket and Waterproof belt
¥:155.00



AB-G2-0093
小板二位USB带13A方角插座
(横)
2 USB with 13A square corner socket with switch
¥:225.00



AB-G2-0094
小板15A美式+USB/Type-c
15A American Standard + USB / type-C
¥:225.00



AB-G2-0095
小板15A泰式+USB/Type-c
15A Thai + USB / type-C
¥:225.00



AB-G2-0096
小板二位USB带13A方角插座
(带保护门)
2 USB with 13A square corner socket with flip cover
¥:225.00



AB-G2-0097
小板二位USB带13A多功能插座
(带保护门)
2 USB with 3 pin multi-purpose socket with flip cover
¥:225.00



AB-G2-0098
小板一位开关13A多功能插座带指示灯
+二位USB
2 USB with 13A square corner socket with indicator light
¥:225.00



AB-G2-0099
小板一位开关13A方角插座带指示灯
+二位USB
Small board one position switch 13A square corner socket with indicator light + two position USB
¥:225.00



AB-G2-0100
小板13A多功能Type-c+USB
13A multifunction with type-C + USB
¥:225.00



AB-G2-0101
小板13A方角插座Type-c+USB
13A square angle band type-C + USB
¥:225.00



AB-G2-0102
小板一位开关13A多功能插座
Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose socket with type-c+USB(with light)
¥:225.00



AB-G2-0103
小板二位USB带13A多功能插座
带小开关(竖)
2 USB with three very multi-purpose socket with switch
¥:235.00



AB-G2-0104
小板一位开关13A方角插座
Type-c+USB(带指示灯)
1 gang switch 13A square insert belt Type-c+USB(with light)
¥:225.00



AB-G2-0105
小板二位USB带13A方角插座
带小开关(竖)
2 USB with 13A square corner socket with switch
¥:235.00



AB-G2-0106
小板15A美式插座+二位USB插座
15A American Standard + 2USB
¥:225.00



AB-G2-0107
小板15A泰式+二位USB插座
15A Thai + 2USB
¥:225.00



AB-G2-0108
小板二位USB带13A多功能插座(横)
2 USB with 13 pin multi-purpose socket
¥:225.00



AB-G2-0109
小板二位USB带10A二极插座
2 USB and 5 pin socket
¥:185.00



AB-G2-0110
小板二位USB带10A二极插座
带开关
2 USB and 5 pin socket with switch
¥:195.00



AB-G2-0111
小板10A五孔插座带USB+Type-c(10W)
10A 5 pole socket with USB type-C(10W)
¥:385.00
小板10A五孔插座带USB+Type-c(18W)
10A 5 pole socket with USB type-C(18W)
¥:290.00



AB-G2-0112
小板一位开关13A多功能五孔插座
带USB
1 gang switch and 5 pin multi-function socket with USB and indicator light
¥:230.00



AB-G2-0113
小板二位USB带13A多功能插座+二位USB
Small board 2 USB with 13A multi-function socket + 2 USB
¥:180.00



AB-G2-0114
小板13A二极多功能插座+二位USB
带小开关
Small board 13A three pole multi-function socket + 2 USB With small switch
¥:190.00



AB-G2-0115
小板13A多功能五孔插座+Type-C(10W)
13A MF 5 pin socket USB+Type-C(10W)
¥:180.00
小板13A多功能五孔插座+Type-C(18W)
13A MF 5 pin socket USB+Type-C(18W)
¥:290.00



AB-G2-0116
小板一位电视插座
TV socket
¥:128.00



AB-G2-0117
小板一位电话插座
telephone socket
¥:128.00
小板一位电脑插座
computer socket
¥:138.00
小板一位电脑插座(超六类)
computer socket(6)
¥:178.00



AB-G2-0118
小板双电视插座
Two TV socket
¥:158.00



AB-G2-0119
小板双电话插座
Two telephone socket
¥:158.00
小板双电视插座
Two computer socket
¥:178.00
小板双电话插座(超六类)
Two computer socket(6)
¥:258.00
小板电话+电脑插座
telephone+computer socket
¥:168.00
小板电话+电脑插座(超六类)
telephone+computer socket(6)
¥:208.00








































AB-G2-0120
小板电视电话插座
TV + telephone socket
¥:158.00
小板电视插座
TV + computer socket
¥:168.00
小板电视+电脑插座(超六类)
TV + computer socket(6)
¥:208.00

AB-G2 钢化玻璃香槟金

 <p>AB-G2-0121 小板一位电话带USB插座 TV+USB socket 小板一位电脑带USB插座 computer+USB socket 小板一位电脑带USB插座 (超六类) computer+USB socket(6)</p> <p>¥:280.00 ¥:290.00 ¥:330.00</p>	 <p>AB-G2-0131 小板单联音频插座 Single audio socket</p> <p>¥:202.00</p>	 <p>AB-G2-0141 紧急呼叫开关 Emergency call switch</p> <p>¥:210.00</p>	 <p>AB-G2-0151 一位开关带调光开关500W 1 gang with dimmer switch 500W</p> <p>¥:212.00</p>	 <p>AB-G2-0161 HDMI+USB+3.5音频 HDMI+USB+3.5 ¥:288.00</p>	 <p>AB-G2-0171 二分之一VGA+HDMI Half VGA+HDMI</p> <p>¥:288.00</p>
 <p>AB-G2-0122 小板一位TV+FM TV and FM</p> <p>¥:198.00</p>	 <p>AB-G2-0132 小板双联音频插座 Double audio socket</p> <p>¥:275.00</p>	 <p>AB-G2-0142 请勿打扰请勿清理门铃开关 (按键式) Do not disturb please namely cleaning please:late doorbell "button"</p> <p>¥:250.00</p>	 <p>AB-G2-0152 一位开关带调速开关500W 1 gang with speed switch 500W</p> <p>¥:212.00</p>	 <p>AB-G2-0162 VGA+USB+3.5音频 VGA+USB+3.5 ¥:288.00</p>	 <p>AB-G2-0172 45A出线柱 45A Outlet</p> <p>¥:248.00</p>
 <p>AB-G2-0123 小板一位卫星插座 Satellite socket</p> <p>¥:148.00</p>	 <p>AB-G2-0133 触摸延时开关(节能) Touch delay delay switch</p> <p>¥:202.00</p>	 <p>AB-G2-0143 请勿打扰门铃开关(按键式) Do not disturb+doorbell "button"</p> <p>¥:385.00</p>	 <p>AB-G2-0153 13A开关带保险丝(带指示灯) 13A switch with fuse with neon</p> <p>¥:239.00</p>	 <p>AB-G2-0163 AV+3.5音频 AV+3.5 ¥:288.00</p>	 <p>AB-G2-0173 空白面板 Blank plate</p> <p>¥:102.00</p>
 <p>AB-G2-0124 小板一位卫星插座 Double satellite socket</p> <p>¥:175.00</p>	 <p>AB-G2-0134 声光控制延时开关(节能) Touch light controlled delay switch (energy saving)</p> <p>¥:202.00</p>	 <p>AB-G2-0144 请勿打扰请勿清理门铃开关 (按键式) Do not disturb please namely cleaning please: "button"</p> <p>¥:475.00</p>	 <p>AB-G2-0154 小板20A出线柱 20A outgoing post</p> <p>¥:221.00</p>	 <p>AB-G2-0164 VGA+AV音频接口 VGA+AV audio interface</p> <p>¥:288.00</p>	 <p>AB-G2-0174 大板二位双联开关带二位13A方角 插座(带指示灯) Large board two position bipolar switch with two position 13A square angle Socket (indicator)</p> <p>¥:258.00</p>
 <p>AB-G2-0125 小板卫星+电视插座 Satellite and TV socket</p> <p>¥:166.00</p>	 <p>AB-G2-0135 红外线人体感应开关 Human body induction</p> <p>¥:220.00</p>	 <p>AB-G2-0145 智能音乐控制开关 Intelligent music control switch</p> <p>¥:2950.00</p>	 <p>AB-G2-0155 剃须插座 Shaving socket</p> <p>¥:450.00</p>	 <p>AB-G2-0165 HDMI+AV音频接口 HDMI+AV audio interface</p> <p>¥:288.00</p>	 <p>AB-G2-0175 大板二位开关带二位16A多功能 插座(带指示灯) 147 Low switch and double 16A MF socket with light</p> <p>¥:258.00</p>
 <p>AB-G2-0126 小板卫星带电话插座 Satellite and telephone socket 小板卫星带电脑插座 Satellite and computer socket 小板卫星带电脑插座(超六类) Satellite and computer socket(6)</p> <p>¥:166.00 ¥:175.00 ¥:215.00</p>	 <p>AB-G2-0136 凹型地脚灯(亮光/暖光) The footlights</p> <p>¥:395.00</p>	 <p>AB-G2-0146 温度控制调节开关 Temperature control switch</p> <p>¥:800.00</p>	 <p>AB-G2-0156 USB+电脑插座+无线路由 USB+computer socket wireless router</p> <p>¥:800.00</p>	 <p>AB-G2-0166 二分之一AV音频+卫星 Half AV audio interface+Satellite</p> <p>¥:288.00</p>	 <p>AB-G2-0176 147二位开关带一位13A方角插座 带二位USB(带指示灯) 147 Low switch and double 13A square corner socket with two USB and indicator light</p> <p>¥:358.00</p>
 <p>AB-G2-0127 小板二极插座带电视插座 2 pin socket with TV</p> <p>¥:290.00</p>	 <p>AB-G2-0137 凹型红外线人体感应地脚灯 (亮光/暖光) The human body induction footlights</p> <p>¥:330.00</p>	 <p>AB-G2-0147 温度控制调节开关 Tuning switch/control switch</p> <p>¥:850.00</p>	 <p>AB-G2-0157 蓝牙+3.5音频+二位USB+HDMI Bluetooth audio+3.5+USB+HDMI</p> <p>¥:2520.00</p>	 <p>AB-G2-0167 二分之一AV音频+USB+3.5音频 Half AV audio interface+USB+3.5 ¥:288.00</p>	 <p>AB-G2-0177 大板二位开关带二位16A多功能插座 +双USB(带指示灯) 147 Low switch and double 16A MF socket +2USB with light</p> <p>¥:358.00</p>
 <p>AB-G2-0128 小板二极插座带电话插座 2 pin socket with telephone 小板二极插座带电脑插座 2 pin socket with computer 小板二极插座带电脑插座 (超六类) 2 pin socket with computer</p> <p>¥:290.00 ¥:290.00 ¥:330.00</p>	 <p>AB-G2-0138 平面地脚灯(亮光/暖光) footlights</p> <p>¥:395.00</p>	 <p>AB-G2-0148 调音开关 Tuning switch</p> <p>¥:260.00</p>	 <p>AB-G2-0158 HDMI</p> <p>¥:288.00</p>	 <p>AB-G2-0168 二分之一VGA+TV Half VGA+TV</p> <p>¥:288.00</p>	 <p>AB-G2-0178 大板147二位开关带二位13A方角插 座+USB/type-c(带指示灯) Large board 147 two position switch with two position 13A square plug +USB /type-c (indicator)</p> <p>¥:388.00</p>
 <p>AB-G2-0129 小板一位光纤插座 Optical fiber socket</p> <p>¥:390.00</p>	 <p>AB-G2-0139 叮咚门铃 Ding dong doorbell</p> <p>¥:245.00</p>	 <p>AB-G2-0149 调光开关300W Dimming 300W ¥:198.00 调光开关600W Dimming 600W ¥:225.00 调光开关1000W Dimming 1000W ¥:252.00</p>	 <p>AB-G2-0159 USB+Type-c</p> <p>¥:324.00</p>	 <p>AB-G2-0169 二分之一VGA+电脑 Half VGA+Computer</p> <p>¥:288.00</p>	 <p>AB-G2-0179 大板147二位开关带二位13A多功能 插座+USB/type-c(带指示灯) Large plate 147 two position switch with two position 13A multifunction +USB /type-c (indicator)</p> <p>¥:388.00</p>
 <p>AB-G2-0130 小板二位USB插座 Double USB socket</p> <p>¥:230.00</p>	 <p>AB-G2-0140 机械式40A漏电保护 Mechanical card for electricity 感应式低频40A漏电保护 Low frequency induction card 感应式高频40A漏电保护 High frequency induction card for electricity</p> <p>¥:280.00 ¥:400.00 ¥:460.00</p>	 <p>AB-G2-0150 调速开关400W Speed 300W ¥:198.00 调速开关600W Speed 600W ¥:225.00 调速开关1000W Speed 1000W ¥:252.00</p>	 <p>AB-G2-0160 HDMI+USB</p> <p>¥:288.00</p>	 <p>AB-G2-0170 二分之一VGA+USB Half VGA+USB</p> <p>¥:288.00</p>	 <p>AB-G2-0180 147型45A双联开关+一位 13A方角插带灯的调光开关 147 type 45A bipolar switch with 13A square angle plug With light (stove switch) ¥:310.00</p>

AB-G2 Tempered glass champagne gold 钢化玻璃香槟金

 <p>AB-G2-0181 147型45A双极开关带指示灯 147 type 45A bipolar switch with indicator light ¥:280.00</p>	 <p>AB-G2-0182 147型空白面板 147 blank panel ¥:185.00</p>	 <p>AB-G2-0183 小板147型16A二位开关单控 Small plate 147 type 16A two position switch single control ¥:212.00 小板147型16A二位开关双控 Small plate 147 type 16A two position switch double control ¥:218.00</p>	 <p>AB-G2-0184 小板147型16A二位开关单控 Small plate 147 type 16A 2 gang 2 way switch ¥:230.00 小板147型16A二位开关双控 Small plate 147 type 16A 3 gang 2 way switch ¥:239.00</p>	 <p>AB-G2-0185 小板147型16A四位开关单控 Small plate 147 type 16A 4 gang 1 way switch ¥:248.00 小板147型16A四位开关双控 Small plate 147 type 16A 4 gang 1 way switch ¥:259.00</p>	 <p>AB-G2-0186 小板147型16A五位开关单控 Small plate 147 type 16A 5 gang 1 way switch ¥:256.00 小板147型16A五位开关双控 Small plate 147 type 16A 5 gang 2 way switch ¥:260.00</p>	 <p>AB-G2-0187 小板147型16A六位开关单控 Small plate 147 type 16A 6 gang 1 way switch ¥:260.00 小板147型16A六位开关双控 Small plate 147 type 16A 6 gang 2 way switch ¥:301.00</p>	<p>AB-G2-0188 小板147型16A七位开关单控 Small plate 147 type 16A 7 gang 1 way switch ¥:302.00 小板147型16A七位开关双控 Small plate 147 type 16A 7 gang 2 way switch ¥:321.00</p>	<p>AB-G2-0189 小板147型16A八位开关单控 Small plate 147 type 16A 8 gang 1 way switch ¥:320.00 小板147型16A八位开关双控 Small plate 147 type 16A 8 gang 2 way switch ¥:342.00</p>	<p>AB-G2-0190 147 二位16A多功能三极插座 147 Double 16A MF 3 pin socket ¥:248.00</p>	 <p>AB-G2-0191 147 二位13A多功能五孔插座 147 Double 5 pin multi-function socket ¥:281.00</p>	 <p>AB-G2-0192 小板147型二位15A美标插座 Small plate 147 two position 15A American standard flat socket ¥:279.00</p>	 <p>AB-G2-0193 147 二位15A美式多功能六孔插座 147 Double 15A Thai MF six-hole socket ¥:279.00</p>	 <p>AB-G2-0194 147 二位13A方角插座 147 Double 13A square corner socket ¥:248.00</p>	 <p>AB-G2-0195 147 二位15A圆形插座 147 Double 15A 3 round pins socket ¥:279.00</p>	 <p>AB-G2-0196 小板147型二位13A错位多功能三极插座 147 type Double 13A dislocation MF 3 pole socket ¥:299.00</p>	<p>AB-G2-0197 147型小板二位10A三极插座 147 type Double 10A two and three pole socket ¥:225.00</p>	<p>AB-G2-0198 147 二位开关带二位13A方角插座 147 low switch and double 13A square corner socket ¥:257.00</p>	<p>AB-G2-0199 147 二位开关带二位13A多功能插座 147 low switch and double 13A MF 3 pin socket with light ¥:257.00</p>	<p>AB-G2-0200 小板147型二位开关二位13A多功能三极插座 Small board 147 two position switch two position 13A multi-function three pole socket ¥:284.00</p>	 <p>AB-G2-0201 147 二位开关带二位13A方角插座 (带指示灯) 147 low switch and double 13A square corner socket with indicator light ¥:258.00</p>	 <p>AB-G2-0202 147 二位开关带二位13A多功能插座 (带指示灯) 147 low switch and double 13A MF socket with light ¥:258.00</p>	 <p>AB-G2-0203 147 二位开关带二位13A方角插座带二位USB 147 low switch and double 13A square corner socket with 2USB ¥:358.00</p>	 <p>AB-G2-0204 147 二位开关带二位13A多功能带二位USB 147 low switch and double 13A MF socket+2USB ¥:358.00</p>	 <p>AB-G2-0205 147 二位开关二位13A方插+USB/Type-c (小板) 147 two switch Double 13A square plug+USB/Type-c ¥:358.00</p>	 <p>AB-G2-0206 147 二位开关二位13A多功能+USB/Type-c (小板) 147 two switch Double 13A MF+USB/Type-c ¥:358.00</p>	<p>AB-G2-0207 147 二位开关带二位15A圆角插座 (带指示灯) 147 low switch and double 15A 3 round pins socket with indicator light ¥:293.00</p>	<p>AB-G2-0208 147 二位开关带二位13A方角插座 147 low switch and double 13A square Angle socket (with neon) ¥:293.00</p>	<p>AB-G2-0209 147 四孔剃须插座 147 two shaving socket ¥:612.00</p>	<p>AB-G2-0210 147 45A开关+一位开关16A多功能插座带指示灯 (组合厨房开关) 147 kitchen switch ¥:346.00</p>	 <p>AB-G2-0211 147 45A开关+一位开关13A方角插座带指示灯 (组合厨房开关) 147 kitchen switch ¥:346.00</p>	 <p>AB-G2-0212 147型45A双极开关+一位13A方角插座 (带指示灯) 147 type 45A bipolar switch +13A square angle plug with light (below switch) ¥:374.00</p>	 <p>AB-G2-0213 147型45A双极开关带指示灯 147 type 45A bipolar switch with indicator light ¥:324.00</p>	 <p>AB-G2-0214 147 16A二位法式插座 147 Double French socket ¥:293.00</p>	 <p>AB-G2-0215 147 16A二位法式插座 147 Double French socket ¥:293.00</p>	 <p>AB-G2-0216 小板147型二位16A插座 Small plate 147 connected two position German standard socket ¥:293.00</p>	<p>AB-G2-0217 小板147型二位16A插座 Small plate 147 connected two position normal socket ¥:293.00</p>	<p>AB-G2-0218 147 二位16A法式插座+USB/Type-c (小板) 147 double 16A German with USB/Type-c ¥:390.00</p>	<p>AB-G2-0219 147 二位16A法式插座+USB/Type-c (小板) 147 double 16A French with USB/Type-c ¥:390.00</p>	<p>AB-G2-0220 小板147型二位16A法式插座+二位USB 147 double 16A German+2USB ¥:369.00</p>	 <p>AB-G2-0221 小板147型二位16A法式插座+二位USB 147 Double 16A German+2USB ¥:369.00</p>	 <p>AB-G2-0222 147 四位USB插座 147 4 USB socket ¥:477.00</p>	 <p>AB-G2-0223 147 二位多功能插座+4USB 147 2 bit multi-function socket +4USB ¥:414.00</p>	 <p>AB-G2-0224 147 二位13A方角插座+4USB 147 two bit 13A square socket +4USB ¥:414.00</p>	 <p>AB-G2-0225 小板147型13A方角插座+二位USB Small board 147 type 13A square corner socket + 2USB ¥:376.00</p>	 <p>AB-G2-0226 147 二位16A多功能插座 (带指示灯) 147 13A MF 3 pin socket +2USB socket ¥:376.00</p>	<p>AB-G2-0227 147型二位开关二位13A多功能五孔+双USB 147 two switch and double 13A MF 5 pin + 2USB ¥:374.00</p>	<p>AB-G2-0228 147 二位开关带二位13A多功能五孔插座+2USB (带指示灯) 147 two position switch with two position 13A multifunction five hole socket + 2 USB (with indicator) ¥:522.00</p>	<p>AB-G2-0229 147 13A多功能五孔插座+四位USB 147 double 13A multi-function socket+4USB ¥:414.00</p>	<p>AB-G2-0230 小板147型二位16A法式插座+二位USB 147 double 16A German+2USB ¥:432.00</p>	 <p>AB-G2-0231 小板147型二位开关二位13A多功能五孔+USB/Type-c (小板) 147 two switch and double 13A MF 5 pin + USB /Type-c ¥:495.00</p>	 <p>AB-G2-0232 小板147型二位开关二位13A多功能插座+4USB带指示灯 147 two switch and double 13A MF +4USB (with neon) ¥:432.00</p>	 <p>AB-G2-0233 小板147型二位开关二位13A方角插座+4USB带指示灯 147 two switch and double 13A square Angle socket +4USB (with neon) ¥:329.00</p>	 <p>AB-G2-0234 147型二位开关二位16A法式插座带指示灯+USB/Type-c (小板) 147 two switch double German socket +USB/Type-c (with neon) ¥:495.00</p>	 <p>AB-G2-0235 147型二位开关二位16A法式插座带指示灯+USB/Type-c (小板) 147 two switch double French socket +USB/Type-c (with neon) ¥:495.00</p>	 <p>AB-G2-0236 147型二位开关二位16A插座 (带指示灯) 147 two switch double German socket (with neon) ¥:329.00</p>	<p>AB-G2-0237 147型二位开关二位16A法式插座 (带指示灯) 147 two switch double French socket (with neon) ¥:329.00</p>	<p>AB-G2-0238 147型二位开关二位16A法式插座带指示灯+二位USB (小板) 147 two switch double 16A German socket with neon + 2USB ¥:405.00</p>	<p>AB-G2-0239 147型二位开关二位16A法式插座带指示灯+二位USB (小板) 147 two switch with double 16A French socket with 2USB (with neon) ¥:405.00</p>	<p>AB-G2-0240 小板147型空白面板 147 Blank plate ¥:167.00</p>
--	--	--	--	--	--	--	--	--	---	---	--	---	---	--	---	---	---	--	--	---	---	---	--	--	--	--	--	---	--	---	---	--	--	--	---	--	---	---	--	--	--	--	--	--	--	---	---	--	--	---	--	--	---	---	--	--	---	---	--

颠覆革新
2.5D钢化真玻璃



智能WIFI插座



AB-G3 钢化玻璃爵士黑
Tempered glass jazz black

每一个开关都是艺术品
每一个宝贝,都是我们用心构造而成独树一帜的体验,让家更美
Every switch is a work of art
Every baby is a unique experience constructed by our heart making our home more beautiful.

ZIGBEE智能按键开关

ZIGBEE Intelligent button switch



网络协议和支持平台

Network protocol and support platform



产品参数

Product parameters

颜色分类 Color selection	金色 黑色 白色 灰色 蓝色 Gold black white gray blue
输入方式 Input mode	零火线 Zero fire line
输入电压 input voltage	110V-250VAC 50/60HZ
连网模式 Networking	WIFI+RF双模 自带WIFI模块 WIFI+RF dual mode With WiFi module
额定功率 Power rating	600W
额定电流 Rated current	10A
使用寿命 service life	10万次 10,000times
表面材质 Surface material	曲面钢化玻璃 Curved tempered glass
工作温度 Operation Temperature	-20℃ ~ +50℃
防火等级 Fire-protection rating	94-V0
待机功耗 standby power	(Standby power) 0.5W
装箱重量 Shipping weight	10.8KG
无线频率 Radio frequency	2.4GHz
无线标准 Wireless standard	IEEE802.11b/g/n

AB-G3 Tempered glass jazz black 钢化玻璃爵士黑

	AB-G3-0001 一位触摸开关(零火线) 1 gang 1 way touch switch 蓝牙WIFI一位触摸开关(零火线) 1 gang 1 way touch switch 涂鸦Zigbee一位触摸开关(零火线) 1 gang 1 way touch switch	Y:400.00 Y:500.00 Y:600.00		AB-G3-0011 大板16A英式门控开关 Large panel British gating switch	Y:109.00		AB-G3-0021 大板13A方角插座 13A square corner socket	Y:109.00		AB-G3-0031 大板一位开关带13A方角插 +二位USB(指示灯) Board one position switch with 13A square angle plug + two position USB (indicator)	Y:295.00		AB-G3-0041 大板一位电话插座 TV+telephone socket 大板一位电视电脑插座 TV+computer socket 大板一位电视电脑插座 (超六类) TV+computer socket(6)	Y:158.00 Y:168.00 Y:208.00		AB-G3-0051 小板16A门控开关 gating switch	Y:109.00
	AB-G3-0002 二位触摸开关(零火线) 2 gang 1 way touch switch 蓝牙WIFI二位触摸开关(零火线) 2 gang 1 way touch switch 涂鸦Zigbee二位触摸开关(零火线) 2 gang 1 way touch switch	Y:450.00 Y:550.00 Y:650.00		AB-G3-0012 大板16A门铃开关 Large panel doorbell switch	Y:109.00		AB-G3-0022 大板二位USB带16A多功能插座 2 USB with 5 pin multi-function socket	Y:213.00		AB-G3-0032 大板16A德式插座 Large board 16A German socket	Y:163.00		AB-G3-0042 大板二位电视插座 Two TV socket	¥:158.00		AB-G3-0052 小板16A英式门控开关 British gating switch	Y:109.00
	AB-G3-0003 三位触摸开关(零火线) 3 gang 1 way touch switch 蓝牙WIFI三位触摸开关(零火线) 3 gang 1 way touch switch 涂鸦Zigbee三位触摸开关(零火线) 3 gang 1 way touch switch	Y:500.00 Y:600.00 Y:700.00		AB-G3-0013 大板20A双极开关带指示灯 20A bipolar switch with indicator light 大板32A双极开关带指示灯 32A bipolar switch with indicator light	Y:168.00 Y:186.00		AB-G3-0023 大板16A一位开关带16A三极插座 1gang1 way switch and 16A 3 pole socket 大板16A一位开关双控带16A三极插座 1gang2 way switch and 16A 3 pole socket	Y:140.00 Y:143.00		AB-G3-0033 大板16A法式插座 Large plate 16A French socket	Y:163.00		AB-G3-0043 大板二位电视插座 Two TV socket 大板二位电脑插座 Two computer socket 大板二位电脑插座(超六类) Two computer socket(6) 大板电话+电脑插座 telephone+computer socket 大板电话+电脑插座(超六类) telephone+computer socket(6)	Y:158.00 Y:178.00 Y:258.00 Y:168.00 Y:208.00		AB-G3-0053 小板16A门铃开关 doorbell switch	Y:109.00
	AB-G3-0004 四位触摸开关(零火线) 4 gang 1 way touch switch 蓝牙WIFI四位触摸开关(零火线) 4 gang 1 way touch switch 涂鸦Zigbee四位触摸开关(零火线) 4 gang 1 way touch switch	Y:550.00 Y:650.00 Y:750.00		AB-G3-0014 大板45A双极开关带指示灯 45A bipolar switch with indicator light	Y:200.00		AB-G3-0024 大板16A一位开关单控带16A三极插座 1gang2 way switch and 16A 3 pole socket 大板16A一位开关双控带16A三极插座 1gang2 way switch and 5 pole socket	Y:140.00 Y:143.00		AB-G3-0034 大板16A俄式插座 Large board 16A Russian socket	Y:163.00		AB-G3-0044 大板空白面板 Large blank panel	Y:80.00		AB-G3-0054 小板16A拨动二位开关单控 1 gang 1 way toggle switch 小板16A拨动一位开关双控 1 gang 2 way toggle switch	Y:175.00 Y:180.00
	AB-G3-0005 大板16A一位开关单控 Large panel 16A 1 gang 1 way switch 大板16A一位开关双控 Large panel 16A 1 gang 2 way switch 大板16A一位开关三控 Large panel 16A 1 gang 3 way switch	Y:86.00 Y:90.00 Y:123.00		AB-G3-0015 大板16A三极插座 16A 3 pole socket	Y:109.00		AB-G3-0025 大板10A二位开关单控带二三极插座 2 gang 1 way switch and 3 pole socket 大板10A二位开关双控带二三极插座 2 gang 2 way switch and 5 pole socket	Y:167.00		AB-G3-0035 大板16A法式插座+二位USB German socket+2 USB	Y:255.00		AB-G3-0045 小板16A一位开关单控 16A 1 gang 1 way switch 小板16A一位开关双控 16A 1 gang 2 way switch 小板16A一位开关多控 16A 1 gang more way switch	Y:87.00 Y:90.00 Y:123.00		AB-G3-0055 小板16A拨动二位开关单控 2 gang 1 way toggle switch 小板16A拨动二位开关双控 2 gang 2 way toggle switch	Y:190.00 Y:200.00
	AB-G3-0006 大板16A二位开关单控 Large panel 16A 2 gang 1 way switch 大板16A二位开关双控 Large panel 16A 2 gang 2 way switch 大板16A二位开关多控 Large panel 16A 2 gang 3 way switch	Y:109.00 Y:110.00 Y:158.00		AB-G3-0016 大板16A多功能插座 16A 3 pin universal socket	Y:109.00		AB-G3-0026 大板一位开关带16A三极多功能插座(带指示灯) 1 gang switch and 16A 3 pin multi-purpose socket with indicator light	Y:146.00		AB-G3-0036 大板16A法式插座+二位USB French socket + 2 USB	Y:255.00		AB-G3-0046 小板16A二位开关单控 16A 2 gang 1 way switch 小板16A二位开关双控 16A 2 gang 2 way switch 小板16A二位开关多控 16A 2 gang more way switch	Y:109.00 Y:110.00 Y:158.00		AB-G3-0056 小板16A拨动三位开关单控 3 gang 1 way toggle switch Y:205.00 小板16A拨动三位开关双控 3 gang 2 way toggle switch Y:220.00	
	AB-G3-0007 大板16A三位开关单控 Large panel 16A 3 gang 1 way switch 大板16A三位开关双控 Large panel 16A 3 gang 1 way switch	Y:139.00 Y:156.00		AB-G3-0017 大板10A二三极插座 10A 5 pole socket	Y:93.00		AB-G3-0027 大板一位双极开关带13A方角插座(指示灯) Large board one position bipolar switch with 13A square angle socket (indicator light)	Y:139.00		AB-G3-0037 大板16A德式插座+USB/Type-c Large board 16A German socket + USB / type-c	Y:255.00		AB-G3-0047 小板16A三位开关单控 16A 3 gang 1 way switch 小板16A三位开关双控 16A 3 gang 2 way switch	Y:139.00 Y:156.00		AB-G3-0057 小板16A拨动四位开关单控 4 gang 1 way toggle switch Y:220.00 小板16A拨动四位开关双控 4 gang 2 way toggle switch Y:240.00	
	AB-G3-0008 大板16A四位开关单控 Large panel 16A 4 gang 1 way switch 大板16A四位开关双控 Large panel 16A 4 gang 2 way switch	Y:169.00 Y:183.00		AB-G3-0018 大板10A四位三极插座 10A Two or three pole socket	Y:117.00		AB-G3-0028 大板一位开关带15A圆孔插座(带指示灯) 1 gang switch and 15A 3 square pin socket with indicator light	Y:146.00		AB-G3-0038 大板16A法式插座+USB/Type-c Large board 16A French socket + USB / type-c	Y:255.00		AB-G3-0048 小板16A四位开关单控 16A 4 gang 1 way switch 小板16A四位开关双控 16A 4 gang 2 way switch	Y:169.00 Y:183.00		AB-G3-0058 小板20A双极开关带指示灯 20A switch with indicator light Y:165.00 小板45A双极开关带指示灯 45A switch with indicator light Y:185.00	
	AB-G3-0009 大板16A带视窗升降开关 Large panel lower window lifter switch	Y:145.00		AB-G3-0019 大板16A多功能五孔插座 16A MF 5 pin socket	Y:128.00		AB-G3-0029 大板一位开关带16A二三极多功能插座(带指示灯) 1 gang switch and 5 pin multi-function socket with indicator light	Y:152.00		AB-G3-0039 大板一位电视插座 TV socket	Y:128.00		AB-G3-0049 小板16A三位开关多控 16A 3 gang 3 way switch	Y:230.00		AB-G3-0059 小板45A双极开关带指示灯 45A switch with indicator light Y:185.00	
	AB-G3-0010 大板16A门铃开关 Large panel gating switch	Y:109.00		AB-G3-0020 大板10A二三极插座 10A 7 pole socket	Y:128.00		AB-G3-0030 大板一位开关带13A多功能插座+二位USB(指示灯) Large board one position switch with 13A multi-function socket + 2USB (indicator)	Y:295.00		AB-G3-0040 大板一位电话插座 telephone socket 大板一位电视插座 computer socket 大板一位电脑插座(超六类) computer socket(6)	Y:128.00 Y:138.00 Y:178.00		AB-G3-0050 小板16A带视窗升降开关 lower window lifter switch	Y:145.00		AB-G3-0060 小板16A带视窗升降开关 16A shutter reset switch Y:195.00	

AB-G3 钢化玻璃爵士黑

Tempered glass jazz black



AB-G3-0061
小板16A德式插座
German socket
¥:146.00



AB-G3-0062
小板16A法式插座
French socket
¥:146.00



AB-G3-0063
小板16A俄式插座
Russian socket
¥:146.00



AB-G3-0064
小板16A以色列插座
Israel socket
¥:165.00



AB-G3-0065
小板16A意大利+带式插座
Italy+German socket
¥:165.00



AB-G3-0066
小板10A二极插座
10A 2 pole socket
¥:126.00



AB-G3-0067
小板10A二极插座
10A Double 2 pole socket
¥:139.00



AB-G3-0068
小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:139.00



AB-G3-0069
小板10A一位开关带二极插座
1 gang switch and 4 pole socket
¥:146.00



AB-G3-0070
小板16A多功能三极插座
16A MF 3 pin socket
¥:109.00



AB-G3-0071
小板13A二三极多功能插座
5 pin multi-function socket
¥:128.00



AB-G3-0072
小板13A四位多五孔插座
Dislocation multi 5 pin multi function socket
¥:128.00



AB-G3-0073
小板13A方角插座
13A square corner socket
¥:109.00



AB-G3-0074
小板15A圆形插座
15A 3 round pins socket
¥:128.00



AB-G3-0075
小板15A美国三极插座
15A three flat American 3 pin universal socket
¥:128.00



AB-G3-0076
小板15A泰式插座
15A Thai socket
¥:128.00



AB-G3-0077
小板15A泰式六孔插座
Small plate 15A Thai six hole socket
¥:138.00



AB-G3-0078
小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:136.00



AB-G3-0079
小板一位开关带15A圆形插座
1 gang switch and 15A 3 round pin socket
¥:143.00



AB-G3-0080
小板一位开关带16A多功能插座
1 gang switch and 3 pin MF socket
¥:143.00



AB-G3-0081
小板一位开关带13A方角插座
(带指示灯)
13 gang switch and 13A square pin socket with indicator light
¥:139.00



AB-G3-0082
小板一位开关带15A圆形插座
(带指示灯)
13 gang switch and 15A 3 round pins socket with indicator light
¥:146.00



AB-G3-0083
小板一位开关带16A多功能插座
(带指示灯)
16 gang switch and 16A MF 3 pin socket with light
¥:146.00



AB-G3-0084
小板一位开关带13A多功能五孔插座
(带指示灯)
15 gang switch and 5 pin multi-function socket with indicator light
¥:152.00



AB-G3-0085
小板16A德式插座带二位USB
2 USB switch German socket
¥:225.00



AB-G3-0086
小板16A法式插座带二位USB
2 USB switch French socket
¥:225.00



AB-G3-0087
小板16A德式插座+USB/Type-C
Small board 16A German socket + USB / type-c
¥:225.00



AB-G3-0088
小板16A法式插座+USB/Type-C
Small board 16A French socket + USB / type-c
¥:225.00



AB-G3-0089
小板16A一位开关带德式插座
16 gang German socket
¥:165.00



AB-G3-0090
小板16A一位开关带法式插座
16 gang French socket
¥:165.00



AB-G3-0091
小板16A德式插座带防水
German socket and Waterproof belt
¥:155.00



AB-G3-0092
小板16A法式插座带防水
French socket and Waterproof belt
¥:155.00



AB-G3-0093
小板二位USB带13A方角插座(横)
2 USB with 13A square corner socket with switch
¥:225.00



AB-G3-0094
小板15A美式+USB/Type-C
15A American Standard + USB / type-c
¥:250.00



AB-G3-0095
小板15A泰式+USB/Type-C
15A Thai + USB / type-c
¥:225.00



AB-G3-0096
小板二位USB带13A方角插座
(带保护门)
2 USB with 13A square corner socket with flip cover
¥:225.00



AB-G3-0097
小板二位USB带13A多功能插座
(带保护门)
2 USB with 13 pin multi-purpose socket with flip cover
¥:225.00



AB-G3-0098
小板一位开关13A多功能插座带指示灯
(带保护门)
2 USB with 13A square corner socket with indicator light and flip cover
¥:225.00



AB-G3-0099
小板一位开关13A方角插座带指示灯
+二位USB
Small board one position switch 13A square corner socket with indicator light + two position USB
¥:225.00



AB-G3-0100
小板13A多功能带Type-C+USB
13A multifunction with type-C + USB
¥:225.00



AB-G3-0101
小板13A方角插座Type-c+USB
13A square angle band type-c + USB
¥:225.00



AB-G3-0102
小板一位开关13A多功能插座带Type-c+USB(带指示灯)
13 gang switch 13A multi-purpose socket with type-c+USB(with light)
¥:225.00



AB-G3-0103
小板二位USB带13A多功能插座
带小开关(竖)
2 USB with three very multi-purpose socket with switch
¥:235.00



AB-G3-0104
小板一位开关13A方角插座带Type-c+USB(带指示灯)
13 gang switch 13A square insert belt Type-c+USB(with light)
¥:225.00



AB-G3-0105
小板二位USB带13A方角插座
带小开关(竖)
2 USB with 13A square corner socket with switch
¥:235.00



AB-G3-0106
小板15A美式插座+二位USB插座
15A American Standard + 2USB
¥:225.00



AB-G3-0107
小板15A泰式+二位USB插座
15A Thai + 2USB
¥:225.00



AB-G3-0108
小板二位USB带13A多功能插座(横)
2 USB with 13 pin multi-purpose socket
¥:225.00



AB-G3-0109
小板二位USB带10A二三极插座
2 USB and 5 pin socket
¥:185.00



AB-G3-0110
小板二位USB带10A二三极插座
带开关
2 USB and 5 pin socket with switch
¥:195.00



AB-G3-0111
小板10A五孔插座带USB + Type-c (10W)
10A 5 pole socket with USB type-C(10W)
¥:185.00
小板10A五孔插座带USB + Type-C(18W)
10A 5 pole socket with USB type-C(18W)
¥:290.00



AB-G3-0112
小板一位开关13A多功能五孔插座带USB
13 gang switch and 5 pin multi-function socket with USB and indicator light
¥:230.00



AB-G3-0113
小板13A二三极多功能插座+二位USB
Small board 13A two three pole multi function socket + 2 USB
¥:180.00



AB-G3-0114
小板13A二三极多功能插座+二位USB带小开关
Small board 13A two three pole multi-function socket + 2 USB With small switch
¥:190.00



AB-G3-0115
小板13A多功能五孔插座带USB+Type-C(10W)
13A MF 5 pin socket USB+type-C(10W)
¥:180.00
小板13A多功能五孔插座带USB+Type-C(18W)
13A MF 5 pin socket USB+type-C(18W)
¥:290.00



AB-G3-0116
小板一位电视插座
TV socket
¥:128.00



AB-G3-0117
小板一位电话插座
15A Thai + 2USB telephone socket
¥:128.00
小板一位电话插座
computer socket
¥:138.00
小板一位电脑插座(超六类)
computer socket(6)
¥:178.00



AB-G3-0118
小板双电视插座
Two TV socket
¥:158.00



AB-G3-0119
小板双电话插座
Two telephone socket
¥:158.00
小板双电脑插座
Two computer socket
¥:178.00
小板双电话插座(超六类)
Two computer socket(6)
¥:258.00
小板电话电脑插座
telephone+computer socket
¥:168.00
小板电话电脑插座(超六类)
telephone+computer socket(6)
¥:208.00



AB-G3-0120
小板电视电话插座
TV + telephone socket
¥:158.00
小板电视电话插座
computer socket
¥:168.00
小板电视电话插座(超六类)
TV + computer socket
¥:208.00
小板电视电话插座(超六类)
TV + computer socket(6)
¥:208.00

AB-G3 Tempered glass jazz black 钢化玻璃爵士黑



AB-G3-0121
小板一位电话带USB插座
TV+USB socket
Y:280.00
小板一位电脑带USB插座
computer+USB socket
Y:290.00
小板一位电脑带USB插座
(超六类)
computer+USB socket(6)
Y:330.00



AB-G3-0122
小板一位TV+FM
TV and FM
Y:198.00



AB-G3-0123
小板一位卫星插座
Satellite socket
Y:148.00



AB-G3-0124
小板一位卫星插座
Double satellite socket
Y:175.00



AB-G3-0125
小板卫星+电视插座
Satellite and TV socket
Y:166.00



AB-G3-0126
小板卫星带电话插座
Satellite and telephone socket
Y:166.00
小板卫星带电脑插座
Satellite and computer socket
Y:175.00
小板卫星带电脑插座(超六类)
Satellite and computer socket(6)
Y:215.00



AB-G3-0127
小板二极插座带电视插座
2 pin socket with TV
Y:290.00



AB-G3-0128
小板二极插座带电话插座
2 pin socket with telephone
Y:290.00
小板二极插座带电脑插座
2 pin socket with computer
Y:290.00
小板二极插座带电脑插座
(超六类)
2 pin socket with computer
Y:330.00



AB-G3-0129
小板一位光纤插座
Optical fiber socket
Y:190.00



AB-G3-0130
小板二位USB插座
Double USB socket
Y:230.00



AB-G3-0131
小板双联音频插座
Single audio socket
Y:202.00



AB-G3-0132
小板双联音频插座
Double audio socket
Y:275.00



AB-G3-0133
触摸延时开关(节能)
Touch delay delay switch
Y:202.00



AB-G3-0134
声光控制延时开关(节能)
Sound/light controlled delay switch
(energy saving)
Y:202.00



AB-G3-0135
红外线人体感应开关
Human body induction
Y:220.00



AB-G3-0136
脚灯脚灯(亮光/暖光)
The footlights
Y:195.00



AB-G3-0137
脚灯脚灯(亮光/暖光)
The human body induction footlights
Y:330.00



AB-G3-0138
脚灯脚灯(亮光/暖光)
footlights
Y:195.00



AB-G3-0139
叮咚门铃
Ding dong doorbell
Y:245.00



AB-G3-0140
机械式40A插卡取电
Mechanical card for electricity
Y:280.00
感应式低频40A插卡取电
Low frequency induction card
Y:400.00
感应式高频40A插卡取电
High frequency induction card
for electricity
Y:460.00



AB-G3-0141
紧急呼叫开关
Emergency call switch
Y:210.00



AB-G3-0142
请勿打扰/清理门铃开关
(按键式)
Do not disturb please namely cleaning
please/late doorbell "button"
Y:250.00



AB-G3-0143
请勿打扰门铃开关(按键式)
Do not disturb-doorbell "button"
Y:385.00



AB-G3-0144
请勿打扰/清理门铃开关
(按键式)
Do not disturb please namely cleaning
please "button"
Y:475.00



AB-G3-0145
智能音乐控制开关
Intelligent music control switch
Y:2950.00



AB-G3-0146
温度控制调节开关
Temperature control switch
Y:800.00



AB-G3-0147
温度控制调节开关
Tuning switch/control switch
Y:850.00



AB-G3-0148
调音开关
Tuning switch
Y:260.00



AB-G3-0149
调音开关300W
Dimming 300W
Y:198.00
调音开关600W
Dimming 600W
Y:225.00
调音开关1000W
Dimming 1000W
Y:252.00



AB-G3-0150
调音开关300W
Speed 300W
Y:198.00
调音开关600W
Speed 600W
Y:225.00
调音开关1000W
Speed 1000W
Y:252.00



AB-G3-0151
一位开关带调光开关500W
1 gang with dimmer switch
Y:212.00



AB-G3-0152
一位开关带调速开关500W
1 gang with speed switch
Y:212.00



AB-G3-0153
13A开关带保险丝(带指示灯)
13A switch with fuse with neon
Y:239.00



AB-G3-0154
小板20A出线柱
20A outgoing post
Y:221.00



AB-G3-0155
剃须插座
Shaving socket
Y:450.00



AB-G3-0156
USB+电脑插座+无线路由
USB-computer socket wireless router
Y:800.00



AB-G3-0157
蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio+3.5+USB+HDMI
Y:5250.00



AB-G3-0158
HDMI
Y:288.00



AB-G3-0159
USB+Type-c
Y:324.00



AB-G3-0160
HDMI+USB
Y:288.00



AB-G3-0161
HDMI+USB+3.5音频
HDMI+USB+3.5
Y:288.00



AB-G3-0162
VGA+USB+3.5音频
VGA+USB+3.5
Y:288.00



AB-G3-0163
AV+3.5音频
AV+3.5
Y:288.00



AB-G3-0164
VGA+AV音频接口
VGA+AV audio interface
Y:288.00



AB-G3-0165
HDMI+AV音频接口
HDMI+AV audio interface
Y:288.00



AB-G3-0166
二分之一AV音频+卫星
Half AV audio interface+Satellite
Y:288.00



AB-G3-0167
二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
Y:288.00



AB-G3-0168
二分之一VGA+TV
Half VGA+TV
Y:288.00



AB-G3-0169
二分之一VGA+电脑
Half VGA+Computer
Y:288.00



AB-G3-0170
二分之一VGA+USB
Half VGA+USB
Y:288.00



AB-G3-0171
二分之一VGA+HDMI
Half VGA+HDMI
Y:288.00



AB-G3-0172
45A出线柱
45A Outlet
Y:248.00



AB-G3-0173
空白面板
Blank plate
Y:102.00



AB-G3-0174
大板二位双联开关带二位13A方角
插座(带指示灯)
Large board two position bipolar switch
with two position 13A square angle
socket (indicator)
Y:258.00



AB-G3-0175
大板二位开关带二位16A多功能
插座(带指示灯)
147 Low switch and double 16A MF
sign socket with light
Y:258.00



AB-G3-0176
147二位开关带二位13A方角插座
带二位USB(带指示灯)
147 Low switch and double 13A square
corner socket with two USB and indicator
light
Y:358.00



AB-G3-0177
大板二位开关带二位16A多功能插座
+双USB(带指示灯)
147 Low switch and double 16A MF
socket + 2USB with light
Y:358.00



AB-G3-0178
大板147型二位开关带二位13A方角
插座+USB/Type-c(带指示灯)
Large board 147 two position switch with
two position 13A square plug
USB / type-c (indicator)
Y:388.00


























































AB-G3-0179
大板147型二位开关带二位13A多功能
插座+USB/Type-c(带指示灯)
Large board 147 two position switch with
two position 13A multifunction
+USB / type-c (indicator)
Y:388.00




AB-G3-0180
147型45A双联开关+一位
13A方角插座带灯(带开关)
147 type 45A bipolar switch
with 13A square angle plug with
light (stove switch)
Y:310.00

AB-G3 钢化玻璃爵士黑

 <p>AB-G3-0181 147型45A双极开关带指示灯 147 type 45A bipolar switch with indicator light ¥:280.00</p>	 <p>AB-G3-0191 147 二位13A多功能五孔插座 147 Double 5 pin multi-function socket ¥:281.00</p>	 <p>AB-G3-0201 147 二位开关带二位13A方角插座 (带指示灯) 147 low switch and double 13A square corner socket with indicator light ¥:258.00</p>	 <p>AB-G3-0211 147 45A开关+一位开关13A方角插座带指示灯 (组合厨房开关) 147 type 45A bipolar switch + 13A square corner socket with indicator light ¥:346.00</p>	 <p>AB-G3-0221 小板147型二位16A德式+二位USB 147 Double 16A German+2USB ¥:369.00</p>	 <p>AB-G3-0231 小板147型二位开关二位13A多功能五孔+USB/type-c 147 two switch and double 13A MF 5 pin + USB / type-C ¥:495.00</p>
 <p>AB-G3-0182 147型空白面板 147 Blank panel ¥:185.00</p>	 <p>AB-G3-0192 小板147型二位15A美标插座 Small plate 147 two position 15A American standard flat socket ¥:279.00</p>	 <p>AB-G3-0202 147 二位开关带二位13A多功能插座 (带指示灯) 147 low switch and double 13A MF socket with light ¥:258.00</p>	 <p>AB-G3-0212 147型45A双极开关+一位13A方角插座带灯 (炉具开关) 147 type 45A bipolar switch +13A square angle plug with light (above switch) ¥:374.00</p>	 <p>AB-G3-0222 147 四位USB插座 147 4 USB socket ¥:477.00</p>	 <p>AB-G3-0232 小板147型二位开关二位13A多功能插座+4USB带指示灯 147 two switch and double 13A MF + 4USB (with neon) ¥:432.00</p>
 <p>AB-G3-0183 小板147型16A二位开关单控 Small plate 147 type 16A two position switch single control ¥:212.00 小板147型16A二位开关双控 Small plate 147 type 16A two position switch double control ¥:218.00</p>	 <p>AB-G3-0193 147 二位15A美式多功能六孔插座 147 Double 15A Thai MF six-hole socket ¥:279.00</p>	 <p>AB-G3-0203 147 二位开关带二位13A方角插座二位USB 147 low switch and double 13A square corner socket with 2USB ¥:358.00</p>	 <p>AB-G3-0213 147型45A双极开关带指示灯 147 type 45A bipolar switch with indicator light ¥:324.00</p>	 <p>AB-G3-0223 147 二位多功能插座+4USB 147 2 bit multi-function socket + 4USB ¥:414.00</p>	 <p>AB-G3-0233 小板147型二位开关二位13A方角插座+4USB带指示灯 147 two switch and double 13A square Angle Socket +4USB (with neon) ¥:392.00</p>
 <p>AB-G3-0184 小板147型16A二位开关单控 Small plate 147 type 16A 2 gang 2 way switch ¥:260.00 小板147型16A二位开关双控 Small plate 147 type 16A 3 gang 2 way switch ¥:239.00</p>	 <p>AB-G3-0194 147 二位13A方角插座 147 Double 13A square corner ¥:248.00</p>	 <p>AB-G3-0204 147 二位开关带二位13A多功能二位USB 147 low switch and double 13A MF socket+2USB ¥:358.00</p>	 <p>AB-G3-0214 147 16A二位德式插座 147 Double German socket ¥:293.00</p>	 <p>AB-G3-0224 147 二位13A方角插座+4USB 147 two bit 13A square socket +4USB ¥:414.00</p>	 <p>AB-G3-0234 147型二位开关二位16A德式插座带指示灯+USB/type-c (小板) 147 two switch double German socket +USB/type-c (with neon) ¥:495.00</p>
 <p>AB-G3-0185 小板147型16A三位开关单控 Small plate 147 type 16A 4 gang 1 way switch ¥:248.00 小板147型16A三位开关双控 Small plate 147 type 16A 4 gang 2 way switch ¥:259.00</p>	 <p>AB-G3-0195 147 二位15A圆孔插座 147 Double 15A 3 round pins socket ¥:279.00</p>	 <p>AB-G3-0205 147 二位开关二位13A方插+USB/type-c (小板) 147 two switch Double 13A square plug+ USB/type-c ¥:358.00</p>	 <p>AB-G3-0215 147 16A二位法式插座 147 Double French socket ¥:293.00</p>	 <p>AB-G3-0225 小板147型13A方角插座二位USB Small board 147 type 13A square corner socket + 2USB ¥:376.00</p>	 <p>AB-G3-0235 147型二位开关二位16A法式插座带指示灯+USB/type-c (小板) 147 two switch double French socket +USB/type-c (with neon) ¥:495.00</p>
 <p>AB-G3-0186 小板147型16A五位开关单控 Small plate 147 type 16A 5 gang 1 way switch ¥:266.00 小板147型16A五位开关双控 Small plate 147 type 16A 5 gang 2 way switch ¥:280.00</p>	 <p>AB-G3-0196 小板147型二位13A错位多功能二极插座 147 type Double 13A dislocation MF 5 pole socket ¥:299.00</p>	 <p>AB-G3-0206 147 二位开关二位13A多功能+USB/type-c (小板) 147 two switch Double 13A MF+USB/type-c ¥:358.00</p>	 <p>AB-G3-0216 小板147型二位德标插座 Small plate 147 connected two position German normal socket ¥:293.00</p>	 <p>AB-G3-0226 147 一位16A多功能插座二位USB插座 147 13A MF 3 pin socket + 2USB socket ¥:376.00</p>	 <p>AB-G3-0236 147型二位开关二位16A德标插座 (带指示灯) 147 two switch double German socket (with neon) ¥:329.00</p>
 <p>AB-G3-0187 小板147型16A六位开关单控 Small plate 147 type 16A 6 gang 1 way switch ¥:300.00 小板147型16A六位开关双控 Small plate 147 type 16A 6 gang 2 way switch ¥:301.00</p>	 <p>AB-G3-0197 147型小板二位10A二极插座 147 type Double 10A two and three pole socket ¥:225.00</p>	 <p>AB-G3-0207 147 二位开关带二位15A圆角插座 (带指示灯) 147 low switch and double 15A 3 round pins socket with indicator light ¥:293.00</p>	 <p>AB-G3-0217 小板147型二位法式插座 Small plate 147 connected two position normal socket ¥:293.00</p>	 <p>AB-G3-0227 147型二位开关二位13A多功能五孔+双USB 147 two switch and double 13A MF 5 pin + 2USB ¥:374.00</p>	 <p>AB-G3-0237 147型二位开关二位16A德式插座 (带指示灯) 147 two switch double French socket (with neon) ¥:329.00</p>
 <p>AB-G3-0188 小板147型16A七位开关单控 Small plate 147 type 16A 7 gang 1 way switch ¥:302.00 小板147型16A七位开关双控 Small plate 147 type 16A 7 gang 2 way switch ¥:321.00</p>	 <p>AB-G3-0198 147 二位开关二位13A方角插座 147 low switch and double 13A square corner socket ¥:257.00</p>	 <p>AB-G3-0208 147 二位开关带二位13A方角插座二位USB 147 low switch and double 13A square Angle socket (with neon) /Type-c (小板) ¥:293.00</p>	 <p>AB-G3-0218 147 16A二位德式插座+USB/type-c (小板) 147 double 16A German with USB/type-c ¥:390.00</p>	 <p>AB-G3-0228 147 二位开关带二位13A多功能五孔插座+2USB带指示灯 147 two position switch with two position 13A multifunction five hole socket + 2 USB (with indicator) ¥:522.00</p>	 <p>AB-G3-0238 147型二位开关二位16A德式插座带指示灯+二位USB (小板) 147 two switch double 16A German socket with neon + 2USB ¥:405.00</p>
 <p>AB-G3-0189 小板147型16A八位开关单控 Small plate 147 type 16A 8 gang 1 way switch ¥:320.00 小板147型16A八位开关双控 Small plate 147 type 16A 8 gang 2 way switch ¥:342.00</p>	 <p>AB-G3-0199 147 二位开关带二位13A多功能插座 147 low switch and double 13A MF 3 pin socket with light ¥:257.00</p>	 <p>AB-G3-0209 147 四位剃须插座 147 two shaving socket ¥:612.00</p>	 <p>AB-G3-0219 147 16A二位法式插座+USB/type-c (小板) 147 double 16A French with USB/type-c ¥:390.00</p>	 <p>AB-G3-0229 147 13A多功能五孔插座+四位USB 147 double 5 pin multi-function socket+4USB ¥:414.00</p>	 <p>AB-G3-0239 147型二位开关二位16A法式插座带指示灯+二位USB (小板) 147 two switch double 16A French socket with 2USB (with neon) ¥:405.00</p>
 <p>AB-G3-0190 147 二位16A多功能三极插座 147 Double 13A MF 3 pin socket ¥:248.00</p>	 <p>AB-G3-0200 小板147型二位开关二位13A多功能二极插座 Small board 147 two position switch two position 13A multi-function two three pole socket ¥:284.00</p>	 <p>AB-G3-0210 147 45A开关+一位开关16A多功能插座带指示灯 (组合厨房开关) 147 kitchen switch + 16A multi-function socket with indicator light ¥:346.00</p>	 <p>AB-G3-0220 147 45A开关+一位开关16A德式+二位USB 147 double 16A German+2USB ¥:369.00</p>	 <p>AB-G3-0230 147型二位13A多功能五孔带4USB+小开关 (带指示灯) 147 double 13A MF 5 pin with 4USB+ small switch (w/neon) ¥:432.00</p>	 <p>AB-G3-0240 小板147型空白面板 147 Blank plate ¥:167.00</p>

AB-G4 钢化玻璃火山灰

Tempered glass volcanic grey



Zigbee智能按键开关

Zigbee Intelligent button switch



Zigbee一开
¥ 1150.00

Zigbee二开
¥ 1250.00

Zigbee三开
¥ 1350.00


二极USB/Type-c+开关
¥ 240.00

语音/APP/轻触机械控制
Voice /APP/ touch mechanical control

情景模式/联动/定时
Scenario mode/linkage/timing

支持多款AI音响
Support a variety of AI audio

涂鸦无线场景开关
(单火线零火通用)
Doodle wireless scene switch
(Single fire and zero fire universal)



AB-G4 钢化玻璃火山灰

Tempered glass volcanic grey

	AB-G4-0001 一位触摸开关(零火线) 1 gang 1 way touch switch 蓝牙WiFi一位触摸开关(零火线) 1 gang 1 way touch switch 涂鸦ZigBee一位触摸开关(零火线) 1 gang 1 way touch switch	Y:400.00 Y:500.00 Y:600.00		AB-G4-0011 大板16A英式门控开关 Large panel British gating switch	Y:109.00		AB-G4-0021 大板13A方角插座 13A square corner socket	Y:109.00		AB-G4-0031 大板一位开关带13A方角插 +二位USB (指示灯) Board one position switch with 13A square angle plug + two position USB (indicator)	Y:295.00		AB-G4-0041 大板一位电话插座 TV+telephone socket 大板一位电视电脑插座 TV+computer socket 大板一位电视电脑插座 (超六类) TV+computer socket(6)	Y:158.00 Y:168.00 Y:208.00		AB-G4-0051 小板16A门控开关 British gating switch	Y:109.00
	AB-G4-0002 二位触摸开关(零火线) 2 gang 1 way touch switch 蓝牙WiFi二位触摸开关(零火线) 2 gang 1 way touch switch 涂鸦ZigBee二位触摸开关(零火线) 2 gang 1 way touch switch	Y:450.00 Y:550.00 Y:650.00		AB-G4-0012 大板16A门铃开关 Large panel doorbell switch	Y:109.00		AB-G4-0022 大板二位USB带16A多功能孔插座 2 USB with 5 pin multi-function socket	Y:213.00		AB-G4-0032 大板16A德式插座 Large board 16A German socket	Y:163.00		AB-G4-0042 大板二位电视插座 Two TV socket	¥:158.00		AB-G4-0052 小板16A英式门控开关 British gating switch	Y:109.00
	AB-G4-0003 三位触摸开关(零火线) 3 gang 1 way touch switch 蓝牙WiFi三位触摸开关(零火线) 3 gang 1 way touch switch 涂鸦ZigBee三位触摸开关(零火线) 3 gang 1 way touch switch	Y:500.00 Y:600.00 Y:700.00		AB-G4-0013 大板20A双极开关带指示灯 20A bipolar switch with indicator light 大板32A双极开关带指示灯 32A bipolar switch with indicator light	Y:168.00 Y:186.00		AB-G4-0023 大板16A一位开关带16A三极插座 1 gang 1 way switch and 16A 3 pole socket 大板16A一位开关带16A三极插座 1 gang 2 way switch and 16A 3 pole socket	Y:140.00 Y:143.00		AB-G4-0033 大板16A法式插座 Large plate 16A French socket	Y:163.00		AB-G4-0043 大板二位电视插座 Two TV socket 大板二位电视插座 (超六类) 大板电话+电脑插座 telephone+computer socket 大板电话+电脑插座(超六类) telephone+computer socket(6)	Y:158.00 Y:178.00 Y:258.00 Y:168.00 Y:208.00		AB-G4-0053 小板16A门铃开关 doorbell switch	Y:109.00
	AB-G4-0004 四位触摸开关(零火线) 4 gang 1 way touch switch 蓝牙WiFi四位触摸开关(零火线) 4 gang 1 way touch switch 涂鸦ZigBee四位触摸开关(零火线) 4 gang 1 way touch switch	Y:550.00 Y:650.00 Y:750.00		AB-G4-0014 大板45A双极开关带指示灯 45A bipolar switch with indicator light	Y:200.00		AB-G4-0024 大板16A一位开关带16A三极插座 1 gang 2 way switch and 16A 3 pole socket 大板16A一位开关带16A三极插座 1 gang 2 way switch and 5 pole socket	Y:140.00 Y:143.00		AB-G4-0034 大板16A俄式插座 Large board 16A Russian socket	Y:163.00		AB-G4-0044 大板空白面板 Large blank panel	Y:80.00		AB-G4-0054 小板16A一位开关单控 1 gang 1 way toggle switch 小板16A一位开关双控 1 gang 2 way toggle switch	Y:175.00 Y:180.00
	AB-G4-0005 大板16A一位开关单控 Large panel 16A 1 gang 1 way switch 大板16A一位开关双控 Large panel 16A 1 gang 2 way switch 大板16A一位开关多控 Large panel 16A 1 gang 3 way switch	Y:86.00 Y:90.00 Y:123.00		AB-G4-0015 大板16A三极插座 16A 3 pole socket	Y:109.00		AB-G4-0025 大板10A二位开关带二二三极插座 2 gang 1 way switch and 2二三极插座 大板10A二位开关带二二三极插座 2 gang 2 way switch and 5 pole socket	Y:167.00		AB-G4-0035 大板16A德式插座+二位USB German socket+2 USB	Y:255.00		AB-G4-0045 小板16A一位开关单控 16A 1 gang 1 way switch 小板16A一位开关双控 16A 1 gang 2 way switch 小板16A一位开关多控 16A 1 gang more way switch	Y:87.00 Y:90.00 Y:123.00		AB-G4-0055 小板16A一位开关单控 2 gang 1 way toggle switch 小板16A一位开关双控 2 gang 2 way toggle switch 小板16A一位开关多控 2 gang 2 way toggle switch	Y:190.00 Y:205.00 Y:200.00
	AB-G4-0006 大板16A二位开关单控 Large panel 16A 2 gang 1 way switch 大板16A二位开关双控 Large panel 16A 2 gang 2 way switch 大板16A二位开关多控 Large panel 16A 2 gang 3 way switch	Y:109.00 Y:110.00 Y:158.00		AB-G4-0016 大板16A多功能插座 16A 3 pin universal socket	Y:109.00		AB-G4-0026 大板一位开关带16A三极多功能插座(带指示灯) 1 gang switch and 16A 3 pin multi-purpose socket with indicator light	Y:146.00		AB-G4-0036 大板16A法式插座+二位USB French socket + 2 USB	¥:255.00		AB-G4-0046 小板16A二位开关单控 16A 2 gang 1 way switch 小板16A二位开关双控 16A 2 gang 2 way switch 小板16A二位开关多控 16A 2 gang more way switch	Y:109.00 Y:110.00 Y:158.00		AB-G4-0056 小板16A一位开关单控 3 gang 1 way toggle switch 小板16A一位开关双控 3 gang 2 way toggle switch 小板16A一位开关多控 3 gang 2 way toggle switch	Y:205.00 Y:220.00 Y:220.00
	AB-G4-0007 大板16A三位开关单控 Large panel 16A 3 gang 1 way switch 大板16A三位开关双控 Large panel 16A 3 gang 1 way switch	Y:139.00 Y:156.00		AB-G4-0017 大板10A二二三极插座 10A 3 pole socket	Y:93.00		AB-G4-0027 大板一位双极开关带13A方角插座 (指示灯) Large board one position bipolar switch with 13A square angle socket indicator light	Y:139.00		AB-G4-0037 大板16A德标插座+USB/Type-c Large board 16A German socket + USB / type-c	Y:255.00		AB-G4-0047 小板16A三位开关单控 16A 3 gang 1 way switch 小板16A三位开关双控 16A 3 gang 2 way switch	Y:139.00 Y:156.00		AB-G4-0057 小板16A一位开关单控 4 gang 1 way toggle switch 小板16A一位开关双控 4 gang 2 way toggle switch	Y:220.00 Y:240.00
	AB-G4-0008 大板16A四位开关单控 Large panel 16A 4 gang 1 way switch 大板16A四位开关双控 Large panel 16A 4 gang 2 way switch	Y:169.00 Y:183.00		AB-G4-0018 大板10A二位二三极插座 10A Two or three pole socket	Y:117.00		AB-G4-0028 大板一位开关带15A圆孔插座(带指示灯) 1 gang switch and 15A 3 square pin socket with indicator light	Y:146.00		AB-G4-0038 大板16A法式插座+USB/Type-c Large board 16A French socket + USB / type-c	Y:255.00		AB-G4-0048 小板16A四位开关单控 16A 4 gang 1 way switch 小板16A四位开关双控 16A 4 gang 2 way switch	Y:169.00 Y:183.00		AB-G4-0058 大板20A双极开关带指示灯 20A switch with indicator light 大板45A双极开关带指示灯 45A switch with indicator light	Y:165.00 Y:185.00
	AB-G4-0009 大板16A带升降开关 Large panel lower window lifter switch	Y:145.00		AB-G4-0019 大板16A多功能五孔插座 16A MF 5 pin socket	Y:128.00		AB-G4-0029 大板一位开关带16A二二三极多功能插座(带指示灯) 1 gang switch and 5 pin multi-function socket with indicator light	Y:152.00		AB-G4-0039 大板一位电话插座 TV socket	Y:128.00		AB-G4-0049 小板16A一位开关多控 16A 3 gang 1 way switch	Y:230.00		AB-G4-0059 大板45A双极开关带指示灯 45A switch with indicator light	Y:185.00
	AB-G4-0010 大板16A门铃开关 Large panel gating switch	Y:109.00		AB-G4-0020 大板10A二二三极插座 10A 7 pole socket	Y:128.00		AB-G4-0030 大板一位开关带13A多功能插座 +二位USB (指示灯) Large board one position switch with 13A multi-function socket + 2USB (indicator)	Y:295.00		AB-G4-0040 大板一位电话插座 telephone socket 大板一位电视插座 computer socket 大板一位电视插座(超六类) computer socket(6)	Y:128.00 Y:138.00 Y:178.00		AB-G4-0050 小板16A带升降开关 lower window lifter switch	Y:145.00		AB-G4-0060 小板16A带升降开关 16A shutter reset switch	Y:195.00

AB-G4 钢化玻璃火山灰

Tempered glass volcanic gray



AB-G4-0061
小板16A德式插座
German socket
¥:146.00



AB-G4-0062
小板16A法式插座
French socket
¥:146.00



AB-G4-0063
小板16A俄式插座
Russian socket
¥:146.00



AB-G4-0064
小板16A以色列插座
Israel socket
¥:165.00



AB-G4-0065
小板16A意大利+德式插座
Italy-German socket
¥:165.00



AB-G4-0066
小板10A二极插座
10A 2 pole socket
¥:126.00



AB-G4-0067
小板10A二极插座
10A Double 2 pole socket
¥:139.00



AB-G4-0068
小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:139.00



AB-G4-0069
小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:146.00



AB-G4-0070
小板16A多功能三极插座
16A MF 3 pin socket
¥:109.00



AB-G4-0071
小板13A二三极多功能插座
5 pin multi-function socket
¥:128.00



AB-G4-0072
小板13A四位多五孔插座
Dislocation multi 5 pin multi function socket
¥:128.00



AB-G4-0073
小板13A方角插座
13A square corner socket
¥:109.00



AB-G4-0074
小板13A侧插插座
15A 3 round pins socket
¥:128.00



AB-G4-0075
小板15A美国三极插座
15A three flat American 3 pin universal socket
¥:128.00



AB-G4-0076
小板15A泰式插座
15A Thai socket
¥:128.00



AB-G4-0077
小板15A泰式六孔插座
Small plate 15A Thai six hole socket
¥:138.00



AB-G4-0078
小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:136.00



AB-G4-0079
小板一位开关带15A侧插插座
1 gang switch and 15A 3 round pin socket
¥:143.00



AB-G4-0080
小板一位开关带16A多功能插座
1 gang switch and 3 pin MF socket
¥:143.00



AB-G4-0081
小板一位开关带13A方角插座
(带指示灯)
1 gang switch and 13A square pin socket with indicator light
¥:139.00



AB-G4-0082
小板一位开关带15A侧插插座
(带指示灯)
1 gang switch and 15A 3 round pins socket with indicator light
¥:146.00



AB-G4-0083
小板一位开关带16A多功能插座
(带指示灯)
1 gang switch and 16A MF 3 pin socket with light
¥:146.00



AB-G4-0084
小板一位开关带13A多功能五孔插座
(带指示灯)
1 gang switch and 5 pin multi-function socket with indicator light
¥:152.00



AB-G4-0085
小板16A德式插座+二位USB
2 USB with German socket
¥:225.00



AB-G4-0086
小板16A法式插座带二位USB
2 USB with French socket
¥:225.00



AB-G4-0087
小板16A德式插座+USB/Type-c
Small board 16A German socket + USB / type-c
¥:225.00



AB-G4-0088
小板16A法式插座+USB/Type-c
Small board 16A French socket + USB / type-c
¥:225.00



AB-G4-0089
小板16A一位开关带德式插座
16A German socket
¥:165.00



AB-G4-0090
小板16A一位开关带法式插座
16A French socket
¥:165.00



AB-G4-0091
小板16A德式插座带防水
German socket and Waterproof belt
¥:135.00



AB-G4-0092
小板16A法式插座带防水
French socket and Waterproof belt
¥:155.00



AB-G4-0093
小板二位USB带13A方角插座(横)
2 USB with 13A square corner socket with switch
¥:225.00



AB-G4-0094
小板15A美式+USB/Type-c
15A American Standard + USB / type-c
¥:225.00



AB-G4-0095
小板15A美式+USB/Type-c
15A Thai + USB / type-c
¥:225.00



AB-G4-0096
小板二位USB带13A方角插座
(带保护门)
2 USB with 13A square corner socket with flip cover
¥:225.00



AB-G4-0097
小板二位USB带13A多功能插座
(带保护门)
2 USB with 3 pin multi-purpose socket with flip cover
¥:225.00



AB-G4-0098
小板一位开关13A多功能插座带指示灯
(带保护门)
1 gang switch and 13A square corner socket with indicator light and flip cover
¥:225.00



AB-G4-0099
小板二位开关13A方角插座带指示灯
+二位USB
Small board one position switch 13A square corner socket with indicator light + two position USB
¥:225.00



AB-G4-0100
小板13A多功能带Type-c+USB
13A multifunction with type-C + USB
¥:225.00



AB-G4-0101
小板13A方角插座Type-c+USB
13A square angle band type-C + USB
¥:225.00



AB-G4-0102
小板一位开关13A多功能插座带Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose socket with type-c+USB(with light)
¥:225.00



AB-G4-0103
小板二位USB带13A多功能插座
带小开关(带)
2 USB with three very multi-purpose socket with switch
¥:235.00



AB-G4-0104
小板一位开关13A方角插座
Type-c+USB(带指示灯)
1 gang switch 13A square insert belt Type-c+USB(with light)
¥:225.00



AB-G4-0105
小板二位USB带13A方角插座
带小开关
2 USB with 13A square corner socket with switch
¥:235.00



AB-G4-0106
小板15A美式插座+二位USB插座
15A American Standard + 2USB
¥:225.00



AB-G4-0107
小板15A泰式+二位USB插座
15A Thai + 2USB
¥:225.00



AB-G4-0108
小板二位USB带13A多功能插座(横)
2 USB with 3 pin multi-purpose socket
¥:225.00



AB-G4-0109
小板二位USB带10A二极插座
2 USB and 5 pin socket
¥:185.00



AB-G4-0110
小板二位USB带10A二三极插座
带开关
2 USB and 5 pin socket with switch
¥:195.00



AB-G4-0111
小板10A五孔插座带USB+Type-c(10W)
10A 5 pole socket with USB type-C(10W)
¥:185.00
小板10A五孔插座带USB+Type-c(18W)
10A 5 pole socket with USB type-C(18W)
¥:290.00



AB-G4-0112
小板一位开关13A多功能五孔插座带USB
1 gang switch and 5 pin multi-function socket with USB and indicator light
¥:230.00



AB-G4-0113
小板二位USB带13A多功能插座+二位USB
Small board 13A two three pole multi function socket + 2 USB
¥:180.00



AB-G4-0114
小板13A二极多功能插座+二位USB
带小开关
Small board 13A two three pole multi-function socket + 2 USB With small switch
¥:190.00



AB-G4-0115
小板13A多功能五孔插座+Type-C(10W)
13A MF 5 pin socket USB+type-C(10W)
¥:180.00
小板13A多功能五孔插座+Type-C(18W)
13A MF 5 pin socket USB+type-C(18W)
¥:290.00



AB-G4-0116
小板一位电视插座
TV socket
¥:128.00



AB-G4-0117
小板一位电话插座
telephone socket
¥:128.00
小板一位电脑插座
computer socket
¥:138.00
小板一位电脑插座(带六类)
computer socket(6)
¥:178.00



AB-G4-0118
小板双电视插座
Two TV socket
¥:158.00



AB-G4-0119
小板双电话插座
Two telephone socket
¥:158.00
小板双电脑插座
Two computer socket
¥:178.00
小板双电话插座(带六类)
Two computer socket(6)
¥:258.00
小板电话电脑插座
telephone-computer socket
¥:168.00
小板电话电脑插座(带六类)
telephone-computer socket(6)
¥:208.00



AB-G4-0120
小板电视电话插座
TV+telephone socket
¥:158.00
小板电视插座
TV-computer socket
¥:168.00
小板电视电话插座(带六类)
TV+computer socket(6)
¥:208.00

AB-G4 钢化玻璃火山灰

Tempered glass volcanic gray
钢化玻璃火山灰



AB-G4-0121
小板一位电话带USB插座
TV+USB socket
小板一位电脑带USB插座
computer+USB socket
小板一位电脑带USB插座
(超六类)
computer+USB socket(6)



AB-G4-0122
小板一位TV+FM
TV and FM
¥:198.00



AB-G4-0123
小板一位卫星插座
Satellite socket
¥:148.00



AB-G4-0124
小板一位卫星插座
Double satellite socket
¥:175.00



AB-G4-0125
小板卫星+电视插座
Satellite and TV socket
¥:166.00



AB-G4-0126
小板卫星带电话插座
Satellite and telephone socket
小板卫星带电脑插座
Satellite and computer socket
小板卫星带电脑插座(超六类)
Satellite and computer socket(6)



AB-G4-0127
小板二极插座带电视插座
2 pin socket with TV
¥:290.00



AB-G4-0128
小板二极插座带电话插座
2 pin socket with telephone
小板二极插座带电脑插座
2 pin socket with computer
小板二极插座带电脑插座
(超六类)
2 pin socket with computer



AB-G4-0129
小板一位光纤插座
Optical fiber socket
¥:390.00



AB-G4-0130
小板二位USB插座
Double USB socket
¥:230.00



AB-G4-0131
小板单联音频插座
Single audio socket
¥:202.00



AB-G4-0132
小板双联音频插座
Double audio socket
¥:275.00



AB-G4-0133
触摸延时开关(节能)
Touch delay delay switch
¥:202.00



AB-G4-0134
声光控制延时开关(节能)
Sound-light controlled delay switch
(energy saving)
¥:202.00



AB-G4-0135
红外线人体感应开关
Human body induction
¥:220.00



AB-G4-0136
凹型地脚灯(亮光/暖光)
The footlights
¥:395.00



AB-G4-0137
凹型红外线人体感应地脚灯
(亮光/暖光)
The human body induction footlights
¥:330.00



AB-G4-0138
平面地脚灯(亮光/暖光)
footlights
¥:395.00



AB-G4-0139
叮咚门铃
Ding dong doorbell
¥:245.00



AB-G4-0140
机械式40A断路器
Mechanical card for electricity
¥:280.00
感应式低频40A断路器
Low frequency induction card
¥:400.00
感应式高频40A断路器
High frequency induction card
for electricity
¥:460.00



AB-G4-0141
紧急呼叫开关
Emergency call switch
¥:210.00



AB-G4-0142
请勿打扰请即清理门铃开关
(按键式)
Do not disturb please namely cleaning
please late doorbell "button"
¥:250.00



AB-G4-0143
请勿打扰门铃开关(按键式)
Do not disturb+doorbell "button"
¥:385.00



AB-G4-0144
请勿打扰请即清理门铃开关
(按键式)
Do not disturb please namely cleaning
please "button"
¥:475.00



AB-G4-0145
智能音乐控制开关
Intelligent music control switch
¥:2950.00



AB-G4-0146
温度控制调节开关
Temperature control switch
¥:800.00



AB-G4-0147
温度控制调节开关
Tuning switch/control switch
¥:850.00



AB-G4-0148
调音开关
Tuning switch
¥:260.00



AB-G4-0149
调音开关300W
Dimming 300W
¥:198.00
调音开关600W
Dimming 600W
¥:225.00
调音开关1000W
Dimming 1000W
¥:252.00



AB-G4-0150
调音开关300W
Speed 300W
¥:198.00
调音开关600W
Speed 600W
¥:225.00
调音开关1000W
Speed 1000W
¥:252.00



AB-G4-0151
一位开关带调光开关500W
1 gang with dimmer switch
¥:212.00



AB-G4-0152
一位开关带调速开关500W
1 gang with speed switch
¥:212.00



AB-G4-0153
13A开关带保险丝(带指示灯)
13A switch with fuse with neon
¥:239.00



AB-G4-0154
小板20A出线柱
20A outgoing post
¥:221.00



AB-G4-0155
剃须插座
Shave socket
¥:450.00



AB-G4-0156
USB+电脑插座+无线路由
USB+computer socket wireless router
¥:800.00



AB-G4-0157
蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio+3.5+USB+HDMI
¥:2520.00



AB-G4-0158
HDMI
¥:288.00



AB-G4-0159
USB+Type-c
¥:324.00



AB-G4-0160
HDMI+USB
¥:288.00



AB-G4-0161
HDMI+USB+3.5音频
HDMI+USB+3.5
¥:288.00



AB-G4-0162
VGA+USB+3.5音频
VGA+USB+3.5
¥:288.00



AB-G4-0163
AV+3.5音频
AV+3.5
¥:288.00



AB-G4-0164
VGA+AV音频接口
VGA+AV audio interface
¥:288.00



AB-G4-0165
HDMI+AV音频接口
HDMI+AV audio interface
¥:288.00



AB-G4-0166
二分之一AV音频+卫星
Half AV audio interface+Satellite
¥:288.00



AB-G4-0167
二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
¥:288.00



AB-G4-0168
二分之一VGA+TV
Half VGA+TV
¥:288.00



AB-G4-0169
二分之一VGA+电脑
Half VGA+Computer
¥:288.00



AB-G4-0170
二分之一VGA+USB
Half VGA+USB
¥:288.00



AB-G4-0171
二分之一VGA+HDMI
Half VGA+HDMI
¥:288.00



AB-G4-0172
45A出线柱
45A Outlet
¥:248.00



AB-G4-0173
空白面板
Blank plate
¥:102.00



AB-G4-0174
大板二位双联开关带二位13A方角
插座(带指示灯)
Large board two position bipolar switch
with two position 13A square angle
Socket (indicator)
¥:258.00



AB-G4-0175
大板二位开关带二位16A多功能
插座(带指示灯)
147 Low switch and double 16A MF
socket with light
¥:258.00



AB-G4-0176
147二位开关带一位13A方角插座
带二位USB(带指示灯)
147 Low switch and double 13A square
corner socket with two USB and indicator
light
¥:358.00



AB-G4-0177
大板二位开关带一位16A多功能插座
+双USB(带指示灯)
147 Low switch and double 16A MF
socket + 2USB with light
¥:358.00



AB-G4-0178
大板147型二位开关带一位13A方角
插座+USB/Type-C(带指示灯)
Large board 147 two position switch with
two position 13A square plug
+USB / type-C (indicator)
¥:388.00






AB-G4-0179
大板147型二位开关带一位13A多功能
插座+USB/Type-C(带指示灯)
Large plate 147 two position switch with
two position 13A multifunction
+USB / type-C (indicator)
¥:388.00



AB-G4-0180
147型45A双联开关+一位
13A方角插座带灯(带开关)
147 type 45A bipolar switch
with 13A square angle plug with
light (stove switch)
¥:310.00

AB-G4 钢化玻璃火山灰

 <p>AB-G4-0181 147型45A双极开关带指示灯 147 type 45A bipolar switch with indicator light ¥:280.00</p>	 <p>AB-G4-0182 147型空白面板 147 blank panel ¥:185.00</p>	 <p>AB-G4-0183 小板147型16A二位开关单控 Small plate 147 type 16A 2 position switch single control ¥:212.00 小板147型16A二位开关双控 Small plate 147 type 16A two position switch double control ¥:218.00</p>	 <p>AB-G4-0184 小板147型16A二位开关单控 Small plate 147 type 16A 2 gang 2 way switch ¥:263.00 小板147型16A二位开关双控 Small plate 147 type 16A 3 gang 2 way switch ¥:239.00</p>	 <p>AB-G4-0185 小板147型16A四位开关单控 Small plate 147 type 16A 4 gang 1 way switch ¥:248.00 小板147型16A四位开关双控 Small plate 147 type 16A 4 gang 2 way switch ¥:259.00</p>	 <p>AB-G4-0186 小板147型16A五位开关单控 Small plate 147 type 16A 5 gang 1 way switch ¥:266.00 小板147型16A五位开关双控 Small plate 147 type 16A 5 gang 2 way switch ¥:280.00</p>	 <p>AB-G4-0187 小板147型16A六位开关单控 Small plate 147 type 16A 6 gang 1 way switch ¥:280.00 小板147型16A六位开关双控 Small plate 147 type 16A 6 gang 2 way switch ¥:301.00</p>	<p>AB-G4-0188 小板147型16A七位开关单控 Small plate 147 type 16A 7 gang 1 way switch ¥:302.00 小板147型16A七位开关双控 Small plate 147 type 16A 7 gang 2 way switch ¥:321.00</p>	<p>AB-G4-0189 小板147型16A八位开关单控 Small plate 147 type 16A 8 gang 1 way switch ¥:320.00 小板147型16A八位开关双控 Small plate 147 type 16A 8 gang 2 way switch ¥:342.00</p>	<p>AB-G4-0190 147二位16A多功能三极插座 147 Double 13A MF 3 pin socket ¥:248.00</p>	<p>AB-G4-0191 147二位13A多功能五孔插座 147 Double 5 pin multi-function socket ¥:281.00</p>	<p>AB-G4-0192 小板147型二位15A美标插座 Small plate 147 two position 15A American standard flat socket ¥:279.00</p>	<p>AB-G4-0193 147二位15A美式多功能六孔插座 147 Double 15A Thai MF six-hole socket ¥:279.00</p>	<p>AB-G4-0194 147二位13A方角插座 147 Double 13A square corner ¥:248.00</p>	<p>AB-G4-0195 147二位15A圆形插座 147 Double 15A 3 round pins socket ¥:279.00</p>	<p>AB-G4-0196 小板147型二位13A错位多功能三极插座 147 type Double 13A dislocation MF 3 pin socket ¥:299.00</p>	<p>AB-G4-0197 147型小板二位10A三极插座 147 type Double 10A two and three pole socket ¥:225.00</p>	<p>AB-G4-0198 147二位开关二位13A方角插座 147 low switch and double 13A square corner socket ¥:257.00</p>	<p>AB-G4-0199 147二位开关二位13A多功能插座 147 low switch and double 13A MF 3 pin socket with light ¥:257.00</p>	<p>AB-G4-0200 小板147型二位开关二位13A多功能三极插座 Small board 147 two position switch two position 13A multi-function two three pole socket ¥:284.00</p>	<p>AB-G4-0201 147二位开关带二位13A方角插座(带指示灯) 147 low switch and double 13A square corner socket with indicator light ¥:258.00</p>	<p>AB-G4-0202 147二位开关带二位13A多功能插座(带指示灯) 147 low switch and double 13A MF socket with light ¥:258.00</p>	<p>AB-G4-0203 147二位开关带二位13A方角插座带二位USB 147 low switch and double 13A square socket with 2USB ¥:358.00</p>	<p>AB-G4-0204 147二位开关带二位13A多功能带二位USB 147 low switch and double 13A MF socket +2USB ¥:358.00</p>	<p>AB-G4-0205 147位开关二位13A方插+USB/Type-c(小板) 147 two switch Double 13A square plug+USB/Type-c ¥:358.00</p>	<p>AB-G4-0206 147二位开关二位13A多功能+USB/Type-c(小板) 147 two switch Double 13A MF +USB/Type-c ¥:358.00</p>	<p>AB-G4-0207 147二位开关带二位15A圆角插座(带指示灯) 147 low switch and double 15A 3 round pins socket with indicator light ¥:293.00</p>	<p>AB-G4-0208 147二位开关带二位13A方角插座 147 low switch and double 13A square Angle socket (with neon) ¥:293.00</p>	<p>AB-G4-0209 147四位剃须插座 147 two shaving socket ¥:612.00</p>	<p>AB-G4-0210 147 45A开关+一位开关16A多功能插座带指示灯(组合厨房开关) 147 kitchen switch ¥:346.00</p>	<p>AB-G4-0211 147 45A开关+一位开关13A方角插座带指示灯(组合厨房开关) 147 kitchen switch ¥:346.00</p>	<p>AB-G4-0212 147型45A双极开关+一位13A方角插座带指示灯(炉具开关) 147 type 45A bipolar switch +13A square angle plug With light (below switch) ¥:374.00</p>	<p>AB-G4-0213 147型45A双极开关带指示灯 147 type 45A bipolar switch with indicator light ¥:324.00</p>	<p>AB-G4-0214 147 16A二位法式插座 147 Double German socket ¥:293.00</p>	<p>AB-G4-0215 147 16A二位法式插座 147 Double French socket ¥:293.00</p>	<p>AB-G4-0216 小板147型连体二位德标插座 Small plate 147 connected two position German standard socket ¥:293.00</p>	<p>AB-G4-0217 小板147型连体二位法标插座 Small plate 147 connected two position normal socket ¥:293.00</p>	<p>AB-G4-0218 147二位16A德式插座+USB/Type-c(小板) 147 double 16A German with USB/Type-c ¥:390.00</p>	<p>AB-G4-0219 147二位16A法式插座+USB/Type-c(小板) 147 double 16A French with USB/Type-c ¥:390.00</p>	<p>AB-G4-0220 小板147型二位16A德式+二位USB 147 double 16A German+2USB ¥:369.00</p>	<p>AB-G4-0221 小板147型二位16A德式+二位USB 147 Double 16A German+2USB ¥:369.00</p>	<p>AB-G4-0222 147四位USB插座 147 4 USB socket ¥:477.00</p>	<p>AB-G4-0223 147二位多功能插座+4USB 147 2 bit multi-function socket + 4USB ¥:414.00</p>	<p>AB-G4-0224 147二位13A方角插座+4USB 147 two bit 13A square socket +4USB ¥:414.00</p>	<p>AB-G4-0225 小板147型13A方角插座+二位USB Small board 147 type 13A square corner socket + 2USB ¥:376.00</p>	<p>AB-G4-0226 147一位16A多功能插座+二位USB插座 147 13A MF 3 pin socket + 2USB socket ¥:376.00</p>	<p>AB-G4-0227 147型二位开关二位13A多功能五孔+双USB 147 two switch and double 13A MF 5 pin + 2USB ¥:374.00</p>	<p>AB-G4-0228 147二位开关二位13A多功能五孔插座+2USB(带指示灯) 147 two position switch with two position 13A multifunction five hole socket + 2 USB (with indicator) ¥:390.00</p>	<p>AB-G4-0229 147二位13A多功能五孔插座+二位USB 147 double 5 pin multi-function socket+2USB ¥:414.00</p>	<p>AB-G4-0230 小板147型二位16A德式+二位USB 147 double 16A German+2USB ¥:369.00</p>	<p>AB-G4-0231 小板147型二位开关二位13A多功能五孔+USB/Type-c 147 two switch and double 13A MF 5 pin + USB /Type-c ¥:495.00</p>	<p>AB-G4-0232 小板147型二位开关二位13A多功能插座+4USB带指示灯 147 two switch and double 13A MF +4USB (with neon) ¥:432.00</p>	<p>AB-G4-0233 小板147型二位开关二位13A方角插座+4USB带指示灯 147 two switch and double 13A square Angle socket +4USB (with neon) ¥:432.00</p>	<p>AB-G4-0234 147型二位开关二位16A德式插座带指示灯+USB/Type-c(小板) 147 two switch double German socket +USB/Type-c (with neon) ¥:495.00</p>	<p>AB-G4-0235 147型二位开关二位16A法式插座带指示灯+USB/Type-c(小板) 147 two switch double French socket +USB/Type-c (with neon) ¥:495.00</p>	<p>AB-G4-0236 147型二位开关二位16A德式插座(带指示灯) 147 two switch double German socket (with neon) ¥:329.00</p>	<p>AB-G4-0237 147型二位开关二位16A德式插座(带指示灯) 147 two switch double French socket (with neon) ¥:329.00</p>	<p>AB-G4-0238 147型二位开关二位16A德式插座带指示灯+二位USB(小板) 147 two switch double 16A German socket with neon + 2USB ¥:405.00</p>	<p>AB-G4-0239 147型二位开关二位16A法式插座带指示灯+二位USB(小板) 147 two switch double 16A French socket with 2USB (with neon) ¥:405.00</p>	<p>AB-G4-0240 小板147型空白面板 147 Blank plate ¥:167.00</p>
--	--	--	--	--	--	--	--	--	--	--	--	--	---	---	--	---	---	--	--	---	---	---	--	---	---	--	---	--	---	--	--	---	---	---	---	--	--	--	---	---	--	---	--	---	--	--	---	--	---	---	---	---	---	---	--	--	---	--	---



Zigbee智能按键开关

Zigbee Intelligent button switch



Zigbee一开
¥1150.00



Zigbee二开
¥1250.00



Zigbee三开
¥1350.00



二三极USB/Type-c+开关
¥240.00

AB-G5 钢化玻璃水晶蓝

Tempered glass crystal blue



时尚玻璃
每面都是惊艳

语音/APP/轻触机械控制
Voice /APP/ touch mechanical control















情景模式/联动/定时
Scenario mode/Linkage/timing

支持多款AI音箱
Support a variety of AI audio

涂鸦无线场景开关
(单火零火通用)
Doodle wireless scene switch
(Single fire and zero fire universal)

AB-G5 钢化玻璃水晶蓝

Tempered glass crystal blue

	AB-G5-0001 一位触摸开关(零火线) 1 gang 1 way touch switch 蓝牙WiFi一位触摸开关(零火线) 1 gang 1 way touch switch 涂鸦Zigbee一位触摸开关(零火线) 1 gang 1 way touch switch	¥:400.00 ¥:500.00 ¥:600.00		AB-G5-0011 大板16A英式门控开关 Large panel British gating switch	¥:109.00		AB-G5-0021 大板13A方角插座 13A square corner socket	¥:109.00		AB-G5-0031 大板一位开关带13A方角插 +二位USB (指示灯) Board one position switch with 13A square angle plug + two position USB (indicator)	¥:295.00		AB-G5-0041 大板一位电话插座 TV+telephone socket 大板一位电视电脑插座 TV+computer socket 大板一位电视电脑插座 (超六类) TV+computer socket(6)	¥:158.00 ¥:168.00 ¥:208.00		AB-G5-0051 小板16A门控开关 gating switch	¥:109.00
	AB-G5-0002 二位触摸开关(零火线) 2 gang 1 way touch switch 蓝牙WiFi二位触摸开关(零火线) 2 gang 1 way touch switch 涂鸦Zigbee二位触摸开关(零火线) 2 gang 1 way touch switch	¥:450.00 ¥:550.00 ¥:650.00		AB-G5-0012 大板16A门铃开关 Large panel doorbell switch	¥:109.00		AB-G5-0022 大板二位USB带16A多功能孔插座 2 USB with 5 pin multi-function socket	¥:213.00		AB-G5-0032 大板16A德式插座 Large board 16A German socket	¥:163.00		AB-G5-0042 大板二位电视插座 Two TV socket	¥:158.00		AB-G5-0052 小板16A英式门控开关 British gating switch	¥:109.00
	AB-G5-0003 三位触摸开关(零火线) 3 gang 1 way touch switch 蓝牙WiFi三位触摸开关(零火线) 3 gang 1 way touch switch 涂鸦Zigbee三位触摸开关(零火线) 3 gang 1 way touch switch	¥:500.00 ¥:600.00 ¥:700.00		AB-G5-0013 大板20A双极开关带指示灯 20A bipolar switch with indicator light	¥:168.00		AB-G5-0023 大板16A一位开关单控带16A三极插座 1gang 1 way switch and 16A 3 pole socket	¥:143.00		AB-G5-0033 大板16A法式插座 Large plate 16A French socket	¥:163.00		AB-G5-0043 大板二位电视插座 Two TV socket 大板二位电脑插座 Two computer socket 大板二位电视插座(超六类) 大板电话+电脑插座(超六类) telephone+computer socket 大板电话+电脑插座(超六类) telephone+computer socket(6)	¥:158.00 ¥:178.00 ¥:258.00 ¥:168.00 ¥:208.00		AB-G5-0053 小板16A门铃开关 doorbell switch	¥:109.00
	AB-G5-0004 四位触摸开关(零火线) 4 gang 1 way touch switch 蓝牙WiFi四位触摸开关(零火线) 4 gang 1 way touch switch 涂鸦Zigbee四位触摸开关(零火线) 4 gang 1 way touch switch	¥:550.00 ¥:650.00 ¥:750.00		AB-G5-0014 大板45A双极开关带指示灯 45A bipolar switch with indicator light	¥:200.00		AB-G5-0024 大板16A一位开关单控带16A三极插座 1gang 1 way switch and 16A 3 pole socket	¥:140.00		AB-G5-0034 大板16A俄式插座 Large board 16A Russian socket	¥:163.00		AB-G5-0044 大板空白面板 Large blank panel	¥:80.00		AB-G5-0054 小板16A一位开关单控 1 gang 1 way toggle switch	¥:175.00
	AB-G5-0005 大板16A一位开关单控 Large panel 16A 1 gang 1 way switch 大板16A一位开关双控 Large panel 16A 1 gang 2 way switch 大板16A一位开关多控 Large panel 16A 1 gang 3 way switch	¥:86.00 ¥:90.00 ¥:123.00		AB-G5-0015 大板16A三极插座 16A 3 pole socket	¥:109.00		AB-G5-0025 大板10A二位开关单控带二三极插座 2 gang 1 way switch and 5 pole socket	¥:167.00		AB-G5-0035 大板16A德式插座+二位USB German socket+2 USB	¥:255.00		AB-G5-0045 小板16A一位开关单控 16A 1 gang 1 way switch 小板16A一位开关双控 16A 1 gang 2 way switch 小板16A一位开关多控 16A 1 gang more way switch	¥:87.00 ¥:90.00 ¥:123.00		AB-G5-0055 小板16A一位开关单控 2 gang 1 way toggle switch	¥:190.00
	AB-G5-0006 大板16A二位开关单控 Large panel 16A 2 gang 1 way switch 大板16A二位开关双控 Large panel 16A 2 gang 2 way switch 大板16A二位开关多控 Large panel 16A 2 gang 3 way switch	¥:109.00 ¥:110.00 ¥:158.00		AB-G5-0016 大板16A多功能插座 16A 3 pin universal socket	¥:109.00		AB-G5-0026 大板一位开关带16A三极多功能插座(带指示灯) 1 gang switch and 16A 3 pin multi-purpose socket with indicator light	¥:146.00		AB-G5-0036 大板16A法式插座+二位USB French socket + 2 USB	¥:255.00		AB-G5-0046 小板16A二位开关单控 16A 2 gang 1 way switch 小板16A二位开关双控 16A 2 gang 2 way switch 小板16A二位开关多控 16A 2 gang more way switch	¥:109.00 ¥:110.00 ¥:158.00		AB-G5-0056 小板16A一位开关单控 3 gang 1 way toggle switch	¥:205.00
	AB-G5-0007 大板16A三位开关单控 Large panel 16A 3 gang 1 way switch 大板16A三位开关双控 Large panel 16A 3 gang 1 way switch	¥:139.00 ¥:156.00		AB-G5-0017 大板10A二三极插座 10A 3 pole socket	¥:93.00		AB-G5-0027 大板一位双极开关带13A方角插座 (指示灯) Large board one position bipolar switch with 13A square angle socket indicator light	¥:139.00		AB-G5-0037 大板16A德标插座+USB/Type-c Large board 16A German socket + USB / type-c	¥:255.00		AB-G5-0047 小板16A三位开关单控 16A 3 gang 1 way switch 小板16A三位开关双控 16A 3 gang 2 way switch	¥:139.00 ¥:156.00		AB-G5-0057 小板16A一位开关单控 4 gang 1 way toggle switch ¥:220.00 小板16A一位开关双控 4 gang 2 way toggle switch ¥:240.00	
	AB-G5-0008 大板16A四位开关单控 Large panel 16A 4 gang 1 way switch 大板16A四位开关双控 Large panel 16A 4 gang 2 way switch	¥:169.00 ¥:183.00		AB-G5-0018 大板10A四位三极插座 10A Two or three pole socket	¥:117.00		AB-G5-0028 大板一位开关带15A圆孔插座(带指示灯) 1 gang switch and 15A 3 square pin socket with indicator light	¥:146.00		AB-G5-0038 大板16A法式插座+USB/Type-c Large board 16A French socket + USB / type-c	¥:255.00		AB-G5-0048 小板16A四位开关单控 16A 4 gang 1 way switch 小板16A四位开关双控 16A 4 gang 2 way switch	¥:169.00 ¥:183.00		AB-G5-0058 大板20A双极开关带指示灯 20A switch with indicator light ¥:165.00 大板45A双极开关带指示灯 45A switch with indicator light ¥:185.00	
	AB-G5-0009 大板16A带视窗升降开关 Large panel lower window lifter switch	¥:145.00		AB-G5-0019 大板16A多功能五孔插座 16A MF 5 pin socket	¥:128.00		AB-G5-0029 大板一位开关带16A二三极多功能插座(带指示灯) 1 gang switch and 5 pin multi-function socket with indicator light	¥:152.00		AB-G5-0039 大板一位电视插座 TV socket	¥:128.00		AB-G5-0049 小板16A一位开关多控 16A 3 gang 3 way switch	¥:230.00		AB-G5-0059 大板45A双极开关带指示灯 45A switch with indicator light ¥:185.00	
	AB-G5-0010 大板16A门铃开关 Large panel gating switch	¥:109.00		AB-G5-0020 大板10A二三极插座 10A 3 pole socket	¥:128.00		AB-G5-0030 大板一位开关带13A多功能插座 +二位USB (指示灯) Large board one position switch with 13A multi-function socket + 2USB indicator	¥:295.00		AB-G5-0040 大板一位电话插座 telephone socket 大板一位电脑插座 computer socket 大板一位电脑插座(超六类) computer socket(6)	¥:128.00 ¥:138.00 ¥:178.00		AB-G5-0050 小板16A带视窗升降开关 lower window lifter switch	¥:145.00		AB-G5-0060 小板16A带视窗升降开关 16A shutter reset switch	¥:195.00

AB-G5 钢化玻璃水晶蓝

Tempered glass crystal blue
钢化玻璃水晶蓝



AB-G5-0061
小板16A德式插座
German socket
¥:146.00



AB-G5-0062
小板16A法式插座
French socket
¥:146.00



AB-G5-0063
小板16A俄式插座
Russian socket
¥:146.00



AB-G5-0064
小板16A以色列插座
Israel socket
¥:165.00



AB-G5-0065
小板16A德大利+带式插座
Baby-German socket
¥:165.00



AB-G5-0066
小板10A二极插座
10A 2 pole socket
¥:126.00



AB-G5-0067
小板10A二极插座
10A Double 2 pole socket
¥:139.00



AB-G5-0068
小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:139.00



AB-G5-0069
小板10A一位开关带二极插座
1 gang switch and 4 pole socket
¥:146.00



AB-G5-0070
小板16A多功能三极插座
16A MF 3 pin socket
¥:109.00



AB-G5-0071
小板13A二三极多功能插座
5 pin multi-function socket
¥:128.00



AB-G5-0072
小板13A四位多五孔插座
Dislocation multi 5 pin multi function socket
¥:128.00



AB-G5-0073
小板13A方角插座
13A square corner socket
¥:109.00



AB-G5-0074
小板15A圆形插座
15A 3 round pins socket
¥:128.00



AB-G5-0075
小板15A美商三极插座
15A three flat American 3 pin universal socket
¥:128.00



AB-G5-0076
小板15A泰式插座
15A Thai socket
¥:128.00



AB-G5-0077
小板15A泰式六孔插座
Small plate 15A Thai six hole socket
¥:138.00



AB-G5-0078
小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:136.00



AB-G5-0079
小板一位开关带15A圆形插座
1 gang switch and 15A 3 round pin socket
¥:143.00



AB-G5-0080
小板一位开关带16A多功能插座
1 gang switch and 3 pin MF socket
¥:143.00



AB-G5-0081
小板一位开关带13A方角插座
(带指示灯)
1 gang switch and 13A square pin socket with indicator light
¥:139.00



AB-G5-0082
小板一位开关带15A圆形插座
(带指示灯)
1 gang switch and 15A 3 round pins socket with indicator light
¥:146.00



AB-G5-0083
小板一位开关带16A多功能插座
(带指示灯)
1 gang switch and 16A MF 3 pin socket with light
¥:146.00



AB-G5-0084
小板一位开关带13A多功能五孔插座
(带指示灯)
1 gang switch and 5 pin multi-function socket with indicator light
¥:152.00



AB-G5-0085
小板16A泰式插座+二位USB
2 USB with German socket
¥:225.00



AB-G5-0086
小板16A法式插座+二位USB
2 USB with French socket
¥:225.00



AB-G5-0087
小板16A德式插座+USB/Type-c
Small board 16A German socket + USB / type-c
¥:225.00



AB-G5-0088
小板16A法式插座+USB/Type-c
Small board 16A French socket + USB / type-c
¥:225.00



AB-G5-0089
小板16A一位开关带德式插座
1 gang switch and German socket
¥:165.00



AB-G5-0090
小板16A一位开关带法式插座
1 gang French socket
¥:165.00



AB-G5-0091
小板16A德式插座带防水
German socket and Waterproof belt
¥:135.00



AB-G5-0092
小板16A法式插座带防水
French socket and Waterproof belt
¥:155.00



AB-G5-0093
小板二位USB带13A方角插座
(横)
2 USB with 13A square corner socket with switch
¥:225.00



AB-G5-0094
小板15A美式+USB/Type-c
15A American Standard + USB / type-c
¥:225.00



AB-G5-0095
小板15A泰式+USB/Type-c
15A Thai + USB / type-c
¥:225.00



AB-G5-0096
小板二位USB带13A方角插座
(带保护门)
2 USB with 13A square corner socket with flip cover
¥:225.00



AB-G5-0097
小板二位USB带13A多功能插座
(带保护门)
2 USB with 3 pin multi-purpose socket with flip cover
¥:225.00



AB-G5-0098
小板一位开关13A多功能插座带指示灯
+二位USB
2 USB with 13A square corner socket with flip cover
¥:225.00



AB-G5-0099
小板一位开关13A方角插座带指示灯
+二位USB
Small board one position switch 13A square corner socket with indicator light + two position USB
¥:225.00



AB-G5-0100
小板13A多功能Type-c+USB
13A multifunction with type-C + USB
¥:225.00



AB-G5-0101
小板13A方角插座Type-c+USB
13A square angle band type-C + USB
¥:225.00



AB-G5-0102
小板一位开关13A多功能插座带Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose socket with type-c+USB(with light)
¥:225.00



AB-G5-0103
小板二位USB带13A多功能插座
(带开关+带)
2 USB with three very multi-purpose socket with switch
¥:235.00



AB-G5-0104
小板一位开关13A方角插座带Type-c+USB(带指示灯)
1 gang switch 13A square insert belt Type-c+USB(with light)
¥:225.00



AB-G5-0105
小板二位USB带13A方角插座
(带开关+带)
2 USB with 13A square corner socket with switch
¥:235.00



AB-G5-0106
小板15A美式插座+二位USB插座
15A American Standard + 2USB
¥:225.00



AB-G5-0107
小板15A泰式+二位USB插座
15A Thai + 2USB
¥:225.00



AB-G5-0108
小板二位USB带13A多功能插座(横)
2 USB with 3 pin multi-purpose socket
¥:225.00



AB-G5-0109
小板二位USB带10A二三极插座
2 USB and 5 pin socket
¥:185.00



AB-G5-0110
小板二位USB带10A二三极插座
带开关
2 USB and 5 pin socket with switch
¥:195.00



AB-G5-0111
小板10A五孔插座带USB + Type-c (10W)
10A 5 pole socket with USB type-c(10W)
¥:185.00
小板10A五孔插座带USB + Type-c (18W)
10A 5 pole socket with USB type-c(18W)
¥:290.00



AB-G5-0112
小板一位开关13A多功能五孔插座带USB
1 gang switch and 5 pin multi-function socket with USB and indicator light
¥:230.00



AB-G5-0113
小板小板13A二三极多功能插座+二位USB
Small board 13A two three pole multi function socket + 2 USB
¥:180.00



AB-G5-0114
小板小板13A二三极多功能插座+二位USB
带小开关
Small board 13A two three pole multi-function socket + 2 USB With small switch
¥:190.00



AB-G5-0115
小板13A多功能五孔插座USB+Type-C(10W)
13A MF 5 pin socket USB+type-C(10W)
¥:180.00
小板13A多功能五孔插座USB+Type-C(18W)
13A MF 5 pin socket USB+type-c(18W)
¥:290.00



AB-G5-0116
小板一位电视插座
TV socket
¥:128.00



AB-G5-0117
小板一位电话插座
telephone socket
¥:128.00
小板一位电脑插座
computer socket
¥:138.00
小板一位电脑插座(带六类)
computer socket(6)
¥:178.00



AB-G5-0118
小板双电视插座
Two TV socket
¥:158.00



AB-G5-0119
小板双电话插座
Two telephone socket
¥:158.00
小板双电脑插座
Two computer socket
¥:178.00
小板双电话插座(带六类)
Two computer socket(6)
¥:258.00
小板电话+电脑插座
telephone+computer socket
¥:168.00
小板电话+电脑插座(带六类)
telephone+computer socket(6)
¥:208.00



AB-G5-0120
小板一位电视电话插座
TV + telephone socket
¥:158.00
小板一位电视插座
TV + computer socket
¥:168.00
小板一位电视电话插座(带六类)
TV + computer socket(6)
¥:208.00

AB-G5 钢化玻璃水晶蓝

Tempered glass crystal blue
钢化玻璃水晶蓝



AB-G5-0121
小板一位电话带USB插座
TV+USB socket
¥:280.00
小板一位电脑带USB插座
computer+USB socket
¥:330.00
小板一位电脑带USB插座
(超六类)
computer+USB socket(6)



AB-G5-0122
小板一位TV+FM
TV and FM
¥:198.00



AB-G5-0123
小板一位卫星插座
Satellite socket
¥:148.00



AB-G5-0124
小板一位卫星插座
Double satellite socket
¥:175.00



AB-G5-0125
小板卫星+电视插座
Satellite and TV socket
¥:166.00



AB-G5-0126
小板卫星带电话插座
Satellite and telephone socket
¥:166.00
小板卫星带电脑插座
Satellite and computer socket
¥:175.00
小板卫星带电脑插座(超六类)
Satellite and computer socket(6)



AB-G5-0127
小板二位插座带电视插座
2 pin socket with TV
¥:290.00



AB-G5-0128
小板二位插座带电话插座
2 pin socket with telephone
¥:290.00
小板二位插座带电脑插座
2 pin socket with computer
¥:330.00
小板二位插座带电脑插座
(超六类)
2 pin socket with computer



AB-G5-0129
小板一位光纤插座
Optical fiber socket
¥:390.00



AB-G5-0130
小板一位USB插座
Double USB socket
¥:230.00



AB-G5-0131
小板单联音频插座
Single audio socket
¥:202.00



AB-G5-0132
小板双联音频插座
Double audio socket
¥:275.00



AB-G5-0133
触摸延时开关(节能)
Touch delay delay switch
¥:202.00



AB-G5-0134
声光控制延时开关(节能)
Sound light controlled delay switch
(energy saving)
¥:202.00



AB-G5-0135
红外线人体感应开关
Human body induction
¥:220.00



AB-G5-0136
脚灯脚灯(亮光/暖光)
The footlights
¥:395.00



AB-G5-0137
脚灯脚灯(亮光/暖光)
The human body induction footlights
¥:330.00



AB-G5-0138
脚灯脚灯(亮光/暖光)
footlights
¥:395.00



AB-G5-0139
叮咚门铃
Ding dong doorbell
¥:245.00



AB-G5-0140
机械式40A插卡取电
Mechanical card for electricity
¥:280.00
感应式低频40A插卡取电
Low frequency induction card
¥:400.00
感应式高频40A插卡取电
High frequency induction card
for electricity
¥:460.00



AB-G5-0141
紧急呼叫开关
Emergency call switch
¥:210.00



AB-G5-0142
请勿打扰请勿清理门铃开关
(按键式)
Do not disturb please namely cleaning
please late doorbell "button"
¥:250.00



AB-G5-0143
请勿打扰门铃开关(按键式)
Do not disturb+doorbell "button"
¥:385.00



AB-G5-0144
请勿打扰请勿清理门铃开关
(按键式)
Do not disturb please namely cleaning
please "button"
¥:475.00



AB-G5-0145
智能音乐控制开关
Intelligent music control switch
¥:2950.00



AB-G5-0146
温度控制调节开关
Temperature control switch
¥:800.00



AB-G5-0147
温度控制调节开关
Tuning switch/control switch
¥:850.00



AB-G5-0148
调音开关
Tuning switch
¥:260.00



AB-G5-0149
调光开关300W
Dimming 300W
¥:198.00
调光开关600W
Dimming 600W
¥:225.00
调光开关1000W
Dimming 1000W
¥:252.00



AB-G5-0150
调光开关300W
Speed 300W
¥:198.00
调光开关600W
Speed 600W
¥:225.00
调光开关1000W
Speed 1000W
¥:252.00



AB-G5-0151
一位开关带调光开关500W
1 gang with dimmer switch
¥:212.00



AB-G5-0152
一位开关带调光开关500W
1 gang with speed switch
¥:212.00



AB-G5-0153
13A开关带保险丝(带指示灯)
13A switch with fuse with neon
¥:239.00



AB-G5-0154
小板20A出线柱
20A outgoing post
¥:221.00



AB-G5-0155
剩流插座
Shunt socket
¥:450.00



AB-G5-0156
USB+电脑插座+无线路由
USB-computer socket wireless router
¥:800.00



AB-G5-0157
蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio+3.5+USB+HDMI
¥:5250.00



AB-G5-0158
HDMI
¥:288.00



AB-G5-0159
USB+Type-c
¥:324.00



AB-G5-0160
HDMI+USB
¥:288.00



AB-G5-0161
HDMI+USB+3.5音频
HDMI+USB+3.5
¥:288.00



AB-G5-0162
VGA+USB+3.5音频
VGA+USB+3.5
¥:288.00



AB-G5-0163
AV+3.5音频
AV+3.5
¥:288.00



AB-G5-0164
VGA+AV音频接口
VGA+AV audio interface
¥:288.00



AB-G5-0165
HDMI+AV音频接口
HDMI+AV audio interface
¥:288.00



AB-G5-0166
二分之一AV音频+卫星
Half AV audio interface+Satellite
¥:288.00



AB-G5-0167
二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
¥:288.00



AB-G5-0168
二分之一VGA+TV
Half VGA+TV
¥:288.00



AB-G5-0169
二分之一VGA+电脑
Half VGA+Computer
¥:288.00



AB-G5-0170
二分之一VGA+USB
Half VGA+USB
¥:288.00



AB-G5-0171
二分之一VGA+HDMI
Half VGA+HDMI
¥:288.00



AB-G5-0172
45A出线柱
45A Outlet
¥:248.00



AB-G5-0173
空白面板
Blank plate
¥:102.00



AB-G5-0174
大板二位双联开关带二位13A方角
插座(指示灯)
Large board two position bipolar switch
with two position 13A square angle
Socket (indicator)
¥:258.00



AB-G5-0175
大板二位开关带二位16A多功能
插座(带指示灯)
147 Low switch and double 16A MF
sign socket with light
¥:258.00



AB-G5-0176
147二位开关带二位13A方角插座
带二位USB(带指示灯)
147 Low switch and double 13A square
corner socket with two USB and indicator
light
¥:358.00



AB-G5-0177
大板二位开关带二位16A多功能插座
+双USB(带指示灯)
147 Low switch and double 16A MF
socket +2USB with light
¥:358.00



AB-G5-0178
大板147二位开关带二位13A方插
+USB/Type-C(带指示灯)
Large board 147 two position switch with
two position 13A square plug
+USB /type-C (indicator)
¥:388.00









































AB-G5-0179
大板147二位开关带二位13A多功能
+USB/Type-C(带指示灯)
Large plate 147 two position switch with
two position 13A multifunction
+USB /type-C (indicator)
¥:388.00



AB-G5-0180
147型45A双联开关+一位
13A方角插带灯的调开关
147 type 45A bipolar switch
+13A square angle plug With
light (stove switch)
¥:310.00

AB-G5 Tempered glass crystal blue 钢化玻璃水晶蓝

	AB-G5-0181 147型45A双极开关带指示灯 147 type 45A bipolar switch with indicator light ¥:280.00		AB-G5-0182 147型空白面板 147 blank panel ¥:185.00		AB-G5-0183 小板147型16A二位开关单控 Small plate 147 type 16A two position switch single control ¥:212.00 小板147型16A二位开关双控 Small plate 147 type 16A two position switch double control ¥:218.00		AB-G5-0184 小板147型16A二位开关单控 Small plate 147 type 16A 2 gang 2 way switch ¥:253.00 小板147型16A二位开关双控 Small plate 147 type 16A 3 gang 2 way switch ¥:239.00		AB-G5-0185 小板147型16A四位开关单控 Small plate 147 type 16A 4 gang 1 way switch ¥:248.00 小板147型16A四位开关双控 Small plate 147 type 16A 4 gang 2 way switch ¥:259.00		AB-G5-0186 小板147型16A六位开关单控 Small plate 147 type 16A 6 gang 1 way switch ¥:256.00 小板147型16A六位开关双控 Small plate 147 type 16A 6 gang 2 way switch ¥:280.00		AB-G5-0187 小板147型16A六位开关单控 Small plate 147 type 16A 6 gang 1 way switch ¥:280.00 小板147型16A六位开关双控 Small plate 147 type 16A 6 gang 2 way switch ¥:301.00		AB-G5-0188 小板147型16A七位开关单控 Small plate 147 type 16A 7 gang 1 way switch ¥:302.00 小板147型16A七位开关双控 Small plate 147 type 16A 7 gang 2 way switch ¥:321.00		AB-G5-0189 小板147型16A八位开关单控 Small plate 147 type 16A 8 gang 1 way switch ¥:320.00 小板147型16A八位开关双控 Small plate 147 type 16A 8 gang 2 way switch ¥:342.00		AB-G5-0190 147二位16A多功能三极插座 147 Double 16A MF 3 pin socket ¥:248.00		AB-G5-0191 小板147型二位15A美标插座 Small plate 147 two position 15A American standard flat socket ¥:279.00		AB-G5-0193 小板147型二位15A美标插座 Small plate 147 two position 15A American standard flat socket ¥:279.00		AB-G5-0194 147二位13A方角插座 147 Double 13A square corner ¥:248.00		AB-G5-0195 147二位15A三极插座 147 Double 15A 3 round pins socket ¥:279.00		AB-G5-0196 小板147型二位13A错位多功能三极插座 147 type Double 13A dislocation MF 3 pin socket ¥:299.00		AB-G5-0197 147型小板二位10A三极插座 147 type 10A two and three pole socket ¥:225.00		AB-G5-0198 147二位开关二位13A方角插座 147 low switch and double 13A square corner socket ¥:257.00		AB-G5-0199 147二位开关二位13A多功能插座 147 low switch and double 13A MF 3 pin socket with light ¥:257.00		AB-G5-0200 小板147二位开关二位13A多功能三极插座 Small board 147 two position switch two position 13A multi-function three pole socket ¥:284.00		AB-G5-0201 147二位开关带二位13A方角插座(带指示灯) 147 low switch and double 13A square corner socket with indicator light ¥:258.00		AB-G5-0202 147二位开关带二位13A多功能插座(带指示灯) 147 low switch and double 13A MF socket with light ¥:258.00		AB-G5-0203 147二位开关带二位13A方角插座带二位USB 147 low switch and double 13A square corner socket with 2USB ¥:358.00		AB-G5-0204 147二位开关带二位13A多功能带二位USB 147 low switch and double 13A MF socket +2USB ¥:358.00		AB-G5-0205 147二位开关二位13A方插+USB/Type-c(小板) 147 two switch Double 13A square plug+USB/Type-c ¥:379.00		AB-G5-0206 147二位开关二位13A多功能+USB/Type-c(小板) 147 two switch Double 13A MF +USB/Type-c ¥:358.00		AB-G5-0207 147二位开关带二位15A圆角插座(带指示灯) 147 low switch and double 15A 3 round pins socket with indicator light ¥:293.00		AB-G5-0208 147二位开关带二位13A方角插座 147 low switch and double 13A square Angle socket (with neon) ¥:293.00		AB-G5-0209 147四位剃须插座 147 two shaving socket ¥:612.00		AB-G5-0210 147 45A开关+一位开关16A多功能插座带指示灯(组合厨房开关) 147 kitchen switch ¥:346.00		AB-G5-0211 147 45A开关+一位开关13A方角插座带指示灯(组合厨房开关) 147 kitchen switch ¥:346.00		AB-G5-0212 147型45A双极开关+一位13A方角插座灯(炉具开关) 147 type 45A bipolar switch +13A square angle plug with light (stove switch) ¥:374.00		AB-G5-0213 147型45A双极开关带指示灯 147 type 45A bipolar switch with indicator light ¥:324.00		AB-G5-0214 147 16A二位法式插座 147 Double German socket ¥:293.00		AB-G5-0215 147 16A二位法式插座 147 Double French socket ¥:293.00		AB-G5-0216 小板147型二位16A插座 Small board 147 connected two position German socket ¥:293.00		AB-G5-0217 小板147型二位16A插座 Small board 147 connected two position German socket ¥:293.00		AB-G5-0218 147二位16A法式插座+USB/Type-c(小板) 147 double 16A German with USB/Type-c ¥:293.00		AB-G5-0219 147二位16A法式插座+USB/Type-c(小板) 147 double 16A French with USB/Type-c ¥:390.00		AB-G5-0220 小板147型二位16A法式插座+二位USB 147 double 16A German +2USB ¥:369.00		AB-G5-0221 小板147型二位16A法式+二位USB 147 Double 16A German+2USB ¥:369.00		AB-G5-0222 147四位USB插座 147 4 USB socket ¥:477.00		AB-G5-0223 147二位多功能插座+4USB 147 2 bit multi-function socket +4USB ¥:414.00		AB-G5-0224 147二位13A方角插座+4USB 147 two switch double 13A square corner socket +4USB ¥:414.00		AB-G5-0225 小板147型13A方角插座+二位USB Small board 147 type 13A square corner socket +2USB ¥:376.00		AB-G5-0226 147二位16A多功能插座+二位USB插座 147 16A MF 3 pin socket +2USB socket ¥:376.00		AB-G5-0227 147二位16A多功能插座+二位USB插座 147 16A MF 3 pin socket +2USB socket ¥:376.00		AB-G5-0228 147二位16A多功能插座+二位USB插座 147 16A MF 3 pin socket +2USB socket ¥:376.00		AB-G5-0229 147二位16A多功能插座+二位USB插座 147 16A MF 3 pin socket +2USB socket ¥:376.00		AB-G5-0230 147二位16A多功能插座+二位USB插座 147 16A MF 3 pin socket +2USB socket ¥:376.00		AB-G5-0231 小板147型二位开关二位13A多功能五孔+USB/Type-c 147 two switch and double 13A MF 5 pin + USB /type-c ¥:495.00		AB-G5-0232 小板147型二位开关二位13A多功能插座+4USB带指示灯 147 two switch and double 13A MF +4USB (with neon) ¥:432.00		AB-G5-0233 147二位开关带二位13A方角插座+4USB带指示灯 147 two switch and double 13A square Angle socket +4USB (with neon) ¥:329.00		AB-G5-0234 147型二位开关二位16A法式插座带指示灯+USB/Type-c(小板) 147 two switch double German socket +USB/Type-c (with neon) ¥:495.00		AB-G5-0235 147型二位开关二位16A法式插座带指示灯+USB/Type-c(小板) 147 two switch double French socket +USB/Type-c (with neon) ¥:495.00		AB-G5-0236 147型二位开关二位16A法式插座带指示灯 147 two switch double German socket (with neon) ¥:329.00		AB-G5-0237 147型二位开关二位16A法式插座带指示灯 147 two switch double French socket (with neon) ¥:329.00		AB-G5-0238 147型二位开关二位16A法式插座带指示灯+二位USB(小板) 147 two switch double 16A German socket with neon +2USB ¥:405.00		AB-G5-0239 147型二位开关二位16A法式插座带指示灯+二位USB(小板) 147 two switch double 16A French socket with 2USB (with neon) ¥:405.00		AB-G5-0240 小板147型空白面板 147 Blank plate ¥:167.00
---	--	---	--	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	--	---	--	---	--	---	---	---	---	---	--	---	--	---	---	---	--	---	---	---	---	---	---	---	--	---	--	---	--	---	---	---	--	---	---	---	--	---	---	---	--	---	---	---	--	---	--	---	--	---	--	---	--	---	---	---	---	---	---	---	--	---	---	---	---	---	--	---	---	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	---	---	---	---	---	---	---	---	--