


W88-02

不锈钢本色+灰
Stainless steel color + grey series



不锈钢
stainless steel



舒适— 源自细节

Comfort from the details of the

结构平实牢靠,新式概念引领生活
外观简洁优雅,洋溢现代风情
夜间指示灯柔和舒适,让家居更显魅力

The structure is flat and solid, and the new concept leads life
The appearance is simple and elegant, full of modern style
Night light soft and comfortable, so that home more attractive

W88-02 不锈钢本色+灰

Stainless steel color + grey series

W88-02-0001
 小板16A一位开关单控
 16A 1 gang 1 way switch
 小板16A一位开关双控
 16A 1 gang 2 way switch
 小板16A一位开关多控
 16A 1 gang more way switch

¥:48.00
 ¥:52.00
 ¥:88.00

W88-02-0002
 小板16A二位开关单控
 16A 1 gang 1 way switch
 小板16A二位开关双控
 16A 1 gang 2 way switch
 小板16A二位开关多控
 16A 1 gang more way switch

¥:62.00
 ¥:68.00
 ¥:120.00

W88-02-0003
 小板16A三位开关单控
 16A 3 gang 1 way switch
 小板16A三位开关双控
 16A 3 gang 2 way switch

¥:75.00
 ¥:84.00

W88-02-0004
 小板16A四位开关单控
 16A 4 gang 1 way switch
 小板16A四位开关双控
 16A 4 gang 2 way switch

¥:88.00
 ¥:100.00

W88-02-0005
 小板16A三位开关多控
 16A 3 gang 3 way switch
 ¥:88.00

W88-02-0006
 门控开关
 gating switch
 ¥:68.00

W88-02-0007
 英式门控开关
 British gating switch
 ¥68.00

W88-02-0008
 门铃开关
 doorbell switch
 ¥:68.00

W88-02-0009
 百叶窗升降开关
 louver window lifter switch
 ¥:83.00

W88-02-0010
 小板16A拨动一位开关单控
 1 gang 1 way toggle switch
 ¥:138.00
 小板16A拨动一位开关双控
 1 gang 2 way toggle switch
 ¥:148.00

W88-02-0011
 小板16A拨动二位开关单控
 2 gang 1 way toggle switch
 ¥:158.00
 小板16A拨动二位开关双控
 2 gang 2 way toggle switch
 ¥:170.00

W88-02-0012
 小板16A拨动三位开关单控
 3 gang 1 way toggle switch
 ¥:178.00
 小板16A拨动三位开关双控
 3 gang 2 way toggle switch
 ¥:196.00

W88-02-0013
 小板16A拨动四位开关单控
 4 gang 1 way toggle switch
 ¥:198.00
 小板16A拨动四位开关双控
 4 gang 2 way toggle switch
 ¥:222.00

W88-02-0014
 一位轻触开关
 1 gang 1 way tact switch
 强电 /Strong electricity ¥:450.00
 弱电 /Weak electricity ¥:300.00

W88-02-0015
 二位轻触开关
 2 gang 1 way tact switch
 强电 /Strong electricity ¥:500.00
 弱电 /Weak electricity ¥:350.00

W88-02-0016
 三位轻触开关
 3 gang 1 way tact switch
 强电 /Strong electricity ¥:550.00
 弱电 /Weak electricity ¥:400.00

W88-02-0017
 一位轻触开关
 1 gang 1 way tact switch
 强电 /Strong electricity ¥:450.00
 弱电 /Weak electricity ¥:300.00

W88-02-0018
 二位轻触开关
 2 gang 1 way tact switch
 强电 /Strong electricity ¥:500.00
 弱电 /Weak electricity ¥:350.00

W88-02-0019
 三位轻触开关
 3 gang 1 way tact switch
 强电 /Strong electricity ¥:550.00
 弱电 /Weak electricity ¥:400.00

W88-02-0020
 一位轻触开关
 1 gang 1 way tact switch
 强电 /Strong electricity ¥:450.00
 弱电 /Weak electricity ¥:300.00

W88-02-0021
 二位轻触开关
 2 gang 1 way tact switch
 强电 /Strong electricity ¥:500.00
 弱电 /Weak electricity ¥:350.00

W88-02-0022
 三位轻触开关
 3 gang 1 way tact switch
 强电 /Strong electricity ¥:550.00
 弱电 /Weak electricity ¥:400.00

W88-02-0023
 四位轻触开关
 4 gang 1 way tact switch
 强电 /Strong electricity ¥:600.00
 弱电 /Weak electricity ¥:450.00

W88-02-0024
 一位轻触开关
 1 gang 1 way tact switch
 强电 /Strong electricity ¥:450.00
 弱电 /Weak electricity ¥:300.00

W88-02-0025
 二位轻触开关
 2 gang 1 way tact switch
 强电 /Strong electricity ¥:500.00
 弱电 /Weak electricity ¥:350.00

W88-02-0026
 三位轻触开关
 3 gang 1 way tact switch
 强电 /Strong electricity ¥:550.00
 弱电 /Weak electricity ¥:400.00

W88-02-0027
 四位轻触开关
 4 gang 1 way tact switch
 强电 /Strong electricity ¥:600.00
 弱电 /Weak electricity ¥:450.00

W88-02-0028
 小板20A双极开关带指示灯
 20A swich with indicator light
 ¥:148.00
 小板45A双极开关带指示灯
 45A swich with indicator light
 ¥:168.00

W88-02-0029
 45A开关带指示灯
 45A swich with indicator light
 ¥:158.00

W88-02-0030
 小板16A卷帘门复位开关
 Shutter reset switch
 ¥:142.00

W88-02-0031
 16A三极插座
 16A 3 pole socket
 ¥:58.00

W88-02-0032
 10A二三极五孔插座
 10A 5 pole socket
 ¥:49.00

W88-02-0033
 错位二 三极插座
 10A Two or three pole socket
 ¥:61.00

W88-02-0034
 二 二 三极插座
 10A 7 pole socket
 ¥:66.00

W88-02-0035
 小板16A多功能三极插座
 16A 3 pin multi-function socket
 ¥:58.00

W88-02-0036
 小板13A二三极多功能插座
 5 pin multi-function socket
 ¥:65.00

W88-02-0037
 小板13A错位多功能二三极插座
 Dislocation multi 5 pin multi-function socket
 ¥:95.00

W88-02-0038
 一开单控带16A三极插座
 1gang 1 way switch and 16A 3 pole socket
 ¥:71.00
 一开双控带16A三极插座
 1gang 2 way switch and 16A 3 pole socket
 ¥:74.00

W88-02-0039
 一开单控带10A二 三极插座
 1gang 1 way switch and 10A 5 pole socket
 ¥:68.00
 一开双控带10A二 三极插座
 1gang 2 way switch and 10A 5 pole socket
 ¥:71.00

W88-02-0040
 二位单控开关带二 三极插座
 2 gang 1 way switch and 5 pole socket
 ¥:87.00
 二位双控开关带二 三极插座
 2 gang 2 way switch and 5 pole socket
 ¥:93.00

W88-02-0041
 10A二极插座
 10A 2 pole socket
 ¥:55.00

W88-02-0042
 10A二二极插座
 10A Double 2 pole socket
 ¥:63.00

W88-02-0043
 小板10A一位开关带二极插座
 1 gang switch and 2 pole socket
 ¥:61.00

W88-02-0044
 小板10A一位开关带二二极插座
 1gang switch and 4 pole socket
 ¥:71.00

W88-02-0045
 小板13A方角插座
 13A square corner socket
 ¥:61.00

W88-02-0046
 小板15A圆角插座
 15A 3 round pins socket
 ¥:85.00

W88-02-0047
 小板16A德式插座
 German socket
 ¥:71.00

W88-02-0048
 小板16A法式插座
 French socket
 ¥:71.00

W88-02-0049
 小板16A俄式插座
 Russian socket
 ¥:71.00

W88-02-0050
 小板16A以色列插座
 Israel socket
 ¥:105.00

W88-02-0051
 小板16A意大利+德式插座
 Italy+German socket
 ¥:105.00

W88-02-0052
 小板16A德式插座带二位USB
 2 USB with German socket
 ¥:203.00

W88-02-0053
 小板16A法式插座带二位USB
 2 USB with French socket
 ¥:203.00

W88-02-0054
 小板16A德式插座+USB/Type-c
 Small board 16A German socket
 + USB / type-c
 ¥:330.00

W88-02-0055
 小板16A法式插座+USB/Type-c
 Small board 16A French socket
 + USB / type-c
 ¥:330.00

W88-02-0056
 小板15A泰式插座
 15A Thai socket
 ¥:61.00

W88-02-0057
 小板15A美标扁三极插座
 15A triode flat American standard socket
 ¥:65.00

W88-02-0058
 小板错位泰式六孔插座
 Dislocation Thai 6 pin socket
 ¥:61.00

W88-02-0059
 小板一位开关带16A多功能插座
 1 gang switch and 3 pin MF socket
 ¥:78.00

W88-02-0060
 一位开关带13A方角插座
 1 gang switch and 13A square pin socket
 ¥:71.00

W88-02 不锈钢本色+灰

Stainless steel color + grey series

	W88-02-0061 小板一位开关带15A圆孔插座 1 gang switch and 15A 3 round pin socket ¥:76.00		W88-02-0071 小板二位USB带13A多功能插座(横) 2 USB with 3 pin multi-purpose socket ¥:205.00		W88-02-0081 小板二位USB带13A方角插座(竖) 2 USB with 13A square corner socket ¥:163.00		W88-02-0091 小板13A二位USB带多功能五孔插座带开关 2 USB with 5 pin multi-function socket with switch ¥:173.00		W88-02-0101 小板一位卫星插座 Satellite socket ¥:78.00		W88-02-0111 触摸延迟开关(节能) Touch delay switch (energy saving) ¥:113.00
	W88-02-0062 一位开关带13A方角插座(带指示灯) 1 gang switch and 13A square pin socket with indicator light ¥:73.00		W88-02-0072 15A美式三极扁插带USB+type-c American Standard + USB / type-c ¥:310.00		W88-02-0082 小板二位USB带13A多功能插座带小开关(竖) 2 USB with 13A 3 pin MF socket with little switch ¥:173.00		W88-02-0092 小板13A多功能五孔插座带Type-c+USB 13A multi-functional five hole plug tape type-C + USB ¥:310.00		W88-02-0102 小板二位卫星插座 Double satellite socket ¥:121.00		W88-02-0112 声光控延迟开关(节能) Sound-light controlled delay switch (energy saving) ¥:113.00
	W88-02-0063 一位开关带15A圆角插座(带指示灯) 1 gang switch and 15A 3 round pins socket with indicator light ¥:78.00		W88-02-0073 15A泰式多功能插座带USB+type-c 15A Thai+ USB / type-c ¥:310.00		W88-02-0083 小板二位USB带13A方角插座带小开关(竖) 2 USB with 13A square corner socket with little switch ¥:173.00		W88-02-0093 小板一位电视插座 TV socket ¥:65.00		W88-02-0103 小板卫星+电视插座 Satellite and TV socket ¥:101.00		W88-02-0113 红外线人体感应开关 Human body induction ¥:248.00
	W88-02-0064 小板一位开关带16A多功能插座(带指示灯) 1 gang switch and 16A 3 pin MF socket with flip cover ¥:80.00		W88-02-0074 小板二位USB带13A多功能插座(带保护门) 2 USB with 3 pin multi-purpose socket with flip cover ¥:203.00		W88-02-0084 15A美式三极扁插带二位USB American Standard + 2USB ¥:185.00		W88-02-0094 小板双电视插座 Two TV socket ¥:91.00		W88-02-0104 小板卫星带电话插座 ¥:101.00 Satellite and telephone socket 小板卫星带电脑插座 ¥:111.00 Satellite and computer socket 小板卫星带电脑插座(超六类) ¥:151.00 Satellite and computer socket(6)		W88-02-0114 凹型地脚灯(亮光/暖光) The footlights ¥:153.00
	W88-02-0065 小板一位开关带13A多功能五孔插座(带指示灯) 1 gang switch and 5 pin multi-function socket with indicator light ¥:88.00		W88-02-0075 小板二位USB带13A方角插座(带保护门) 2 USB with 13A square corner socket with flip cover ¥:203.00		W88-02-0085 15A泰式多功能插座带二位USB 15A Thai MF socket + 2USB ¥:185.00		W88-02-0095 小板一位电话插座 ¥:65.00 telephone socket 小板一位电脑插座 ¥:78.00 computer socket 小板一位电脑插座(超六类) ¥:118.00 computer socket(6)		W88-02-0105 小板二极插座带电视插座 2 pin socket with TV ¥:151.00		W88-02-0115 凹型红外线人体感应地脚灯(亮光/暖光) The human body induction footlights ¥:268.00
	W88-02-0066 小板16A一位开关带德式插座 1 gang German socket ¥:110.00		W88-02-0076 小板一位开关带二位USB带13A多功能插座(带指示灯) 1 gang switch with 2USB and 13A MF socket ¥:173.00		W88-02-0086 二位USB带二 三极插座 2 USB and 5 pin socket ¥:163.00		W88-02-0096 小板双电话插座 ¥:91.00 Two telephone socket 小板双电脑插座 ¥:121.00 Two computer socket 小板双电脑插座(超六类) ¥:181.00 Two computer socket(6)		W88-02-0106 小板二极插座带电话插座 ¥:270.00 2 pin socket with telephone 小板二极插座带电脑插座 ¥:270.00 2 pin socket with computer 小板二极插座带电脑(超六类) ¥:310.00 2 pin socket with computer		W88-02-0116 平面地脚灯(亮光/暖光) Footlights ¥:153.00
	W88-02-0067 小板16A一位开关带法式插座 1 gang French socket ¥:110.00		W88-02-0077 小板一位开关带二位USB带13A方角插座(带指示灯) 2 USB with 13A square corner socket with flip cover ¥:173.00		W88-02-0087 二位USB带二 三极插座(带开关) 2 USB and 5 pin socket with switch ¥:173.00		W88-02-0097 小板电话电脑插座 ¥:101.00 telephone+computer socket 小板电话电脑插座(超六类) ¥:141.00 telephone+computer socket(6)		W88-02-0107 小板一位光纤插座 Optical fiber socket ¥:128.00		W88-02-0117 叮咚门铃 Ding dong doorbell ¥:175.80
	W88-02-0068 小板16A德式插座带防水 German socket and Waterproof belt ¥:105.00		W88-02-0078 小板13A多功能带Type-c+USB 13A multifunction with type-C + USB ¥:310.00		W88-02-0088 小板10A二 三极插座带Type-c+USB 10A two and three pole socket with type-C + USB ¥:310.00		W88-02-0098 电视电话插座 ¥:91.00 TV + telephone socket 电视电脑插座 ¥:101.00 TV + computer socket 电视电脑插座(超六类) ¥:141.00 TV + computer socket(6)		W88-02-0108 二位USB插座 Double USB socket ¥:203.00		W88-02-0118 机械式40A插卡取电 ¥:263.00 Mechanical card for electricity 感应式低频40A插卡取电 ¥:453.00 Low frequency induction card for electricity 感应式高频40A插卡取电 ¥:553.00 High frequency induction card for electricity
	W88-02-0069 小板16A法式插座带防水 French socket and Waterproof belt ¥:105.00		W88-02-0079 小板13A方角插座带Type-c+USB 13A square angle band type-C + USB ¥:310.00		W88-02-0089 小板一位开关带13A多功能五孔插座带USB 1 gang switch and 5 pin multi-function socket with USB and indicator light ¥:240.00		W88-02-0099 小板一位电话带USB插座 ¥:238.00 TEL + USB socket 小板一位电脑带USB插座 ¥:238.00 computer + USB socket 小板一位电脑带USB插座(超六类) ¥:288.00 computer + USB socket(6)		W88-02-0109 小板单联音响插座 Single audio socket ¥:133.00		W88-02-0119 紧急呼叫开关 Emergency call switch ¥:163.00
	W88-02-0070 二位USB带13A方角插座 2 USB with 13A square corner socket ¥:163.00		W88-02-0080 小板二位USB带13A多功能插座(竖) 2 USB with Three very multi-purpose socket ¥:183.00		W88-02-0090 小板13A二位USB带多功能五孔插座 2 USB with 5 pin multi-function socket ¥:163.00		W88-02-0100 小板一位TV+FM TV and FM ¥:190.00		W88-02-0110 小板双联音响插座 Double audio socket ¥:183.00		W88-02-0120 请勿打扰请即清理门铃开关(按键式) Do not disturb, please namely cleaning please + later doorbell "button" ¥:191.00

W88-02 不锈钢本色+灰

Stainless steel color + grey series



W88-02-0121
请勿打扰门铃开关 (按键式)
Do not disturb + doorbell "button"
¥:323.00



W88-02-0122
请勿打扰请即清理门铃开关
(按键式)
Do not disturb please namely cleaning
please "button"
¥:323.00



W88-02-0123
智能音乐控制开关
Intelligent music control switch
¥:2630.00



W88-02-0124
小板温度控制调节器
Temperature control switch
¥:710.00



W88-02-0125
温度控制调节开关
Temperature control switch
¥:683.00



W88-02-0126
调音开关(消防)
Tuning switch (fire)
¥:163.00



W88-02-0127
调光开关300W ¥:133.00
Dimming 300W
调光开关600W ¥:173.00
Dimming 600W
调光开关1000W ¥:213.00
Dimming 1000W



W88-02-0128
调速开关300W ¥:133.00
Speed 300W
调速开关600W ¥:173.00
Speed 600W
调速开关1000W ¥:213.00
Speed 1000W



W88-02-0129
一位开关带调光开关
1 gang with dimmer switch
¥:165.00



W88-02-0130
一位开关带调速开关
1 gang with speed switch
¥:165.00



W88-02-0131
13A开关带保险丝(带指示灯)
13A switch with fuse(with light)
¥:163.00



W88-02-0132
20A出线柱
20A outgoing post
¥:82.50



W88-02-0133
剃须插座
Shaving socket
¥:430.00



W88-02-0134
USB+电脑插座+无线路由
USB + computer socket,wireless router
¥:803.00



W88-02-0135
蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio + 3.5
+ 2USB + HDMI
¥:5203.00



W88-02-0136
HDMI
¥:243.00



W88-02-0137
USB+TYPE-C
¥:310.00



W88-02-0138
HDMI+USB
¥:243.00



W88-02-0139
HDMI+USB+3.5音频
hemi+USB+3.5
¥:243.00



W88-02-0140
VGA+USB+3.5音频
VGA+USB+3.5
¥:243.00



W88-02-0141
AV+3.5音频
AV +3.5
¥:243.00



W88-02-0142
VGA+AV音频接口
VGA + AV audio interface
¥:243.00



W88-02-0143
HDMI+AV音频接口
HDMI + AV audio interface
¥:127.50



W88-02-0144
二分之一AV音频+卫星
Half AV audio interface+Satellite
socket
¥:270.00



W88-02-0145
二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
¥:270.00



W88-02-0146
二分之一VGA+TV
Half VGA+TV
¥:270.00



W88-02-0147
二分之一VGA+电脑插座
Half VGA+computer socket
¥:270.00



W88-02-0148
二分之一VGA+USB
Half VGA+USB
¥:270.00



W88-02-0149
二分之一VGA+HDMI
Half VGA+HDMI
¥:270.00



W88-02-0150
45A出线柱
45A Outlet
¥:200.00



W88-02-0151
空白面板
Blank plate
¥:16.90



W88-02-0152
小板147型二位开关单控
147 2 gang 1 way switch
¥:96.00
小板147型二位开关双控
147 2 gang 2 way switch
¥:242.00



W88-02-0153
小板147型16A三位开关单控
147 3 gang 1 way switch
¥:110.00
小板147型16A三位开关双控
147 3 gang 2 way switch
¥:120.00



W88-02-0154
小板147型四位开关单控
147 4 gang 1 way switch
¥:276.00
小板147型四位开关双控
147 4 gang 2 way switch
¥:288.00



W88-02-0155
小板147型16A五位开关单控
147 5 gang 1 way switch
¥:137.00
小板147型16A五位开关双控
147 5 gang 2 way switch
¥:152.00



W88-02-0156
小板147型六位开关单控
147 6 gang 1 way switch
¥:311.00
小板147型六位开关双控
147 6 gang 2 way switch
¥:334.00



W88-02-0157
小板147型16A七位开关单控
147 7 gang 1 way switch
¥:163.00
小板147型16A七位开关双控
147 7 gang 2 way switch
¥:184.00



W88-02-0158
小板147型16A八位开关单控
147 8 gang 1 way switch
¥:176.00
小板147型16A八位开关双控
147 8 gang 2 way switch
¥:200.00



W88-02-0159
147 二位16A多功能三极插座
147 Double 16A MF socket
¥:123.00



W88-02-0160
147 二位13A多功能五孔插座
147 Double 5 pin multi-function
socket
¥:138.00



W88-02-0161
小板147型二位15A美标扁插座
147 Double 15A triode flat
Ammerican standard socket
¥:138.00



W88-02-0162
小板147型二位15A泰式三极插座
147 Double 15A triode flat
Ammerican standard socket
¥:138.00



W88-02-0163
147 二位13A方角插座
147 Double 13A square corner
¥:123.00



W88-02-0164
147 二位15A圆孔插座
147 Double 15A 3 round pins
socket
¥:310.00



W88-02-0165
小板147型二位13A错位多功能五孔插座
147 type Double 13A dislocation
multi-function 5 hole socket
¥:332.00



W88-02-0166
147 二位10A二三极插座
147 Double position two and
three pole socket
¥:250.00



W88-02-0167
147 二开带二位16A多功能插座
Two switch and double 16A
MF 3 pin socket
¥:168.00



W88-02-0168
二位开关带二位13A方角插座
Two switch and double 13A square
corner socket
¥:168.00




W88-02-0169
147二位开关带二位五孔多功能插座(带指示灯)
147 Tow switch and double 5 pin
multi-purpose socket with indicator
light
¥:310.00




W88-02-0170
147 二位开关带二位13A方角插座(带指示灯)
147 Tow switch and double 13A
square corner socket with indicator
light
¥:168.00



W88-02-0171
147 二位开关带二位16A多功能插座(带指示灯)
147 Tow switch and double 16A
MF socket with light
¥:168.00



W88-02-0172
147二位开关二位13A方插+二位USB(小板)
147 Tow switch and double 13A
square corner socket+2USB
¥:283.00



W88-02-0173
147二位开关二位13A多功能+二位USB(小板)
147 Tow switch and double 13A
MF socket+2USB
¥:283.00



W88-02-0174
147 二位开关二位13A方插+USB/Type-c
147 two switch double 13A square
band lamp+USB/Type-c
¥:500.00



W88-02-0175
147 二位开关二位13A多功能插带灯+USB/Type-c
147 two switch double 13A MF
band lamp+USB/Type-c
¥:500.00



W88-02-0176
147 二位开关带二位15A圆角插座(带指示灯)
147 Tow switch and double 15A 3
round pins socket with indicator light
¥:156.00



W88-02-0177
小板147型二位开关带二位13A方角插座(带指示灯)
147 two switch with double 13A square
angle socket (with indicator light)
¥:146.00



W88-02-0178
147型二位剃须插座
147 two shaving socket
¥:563.00



W88-02-0179
147 45A开关+一位开关16A多功能插座带指示灯(组合厨房开关)
147 kitchen switch
¥:263.00



W88-02-0180
14745A开关+一位开关13A方角插带指示灯(组合厨房开关)
147 kitchen switch
¥:263.00

W88-02 不锈钢本色+灰

Stainless steel color + grey series



W88-02-0181
147 45A开关+一位开关13A方插带灯(厨房开关)
147 Kitchen switch
¥:263.00



W88-02-0191
147 四位USB插座
147 4 USB socket
¥:413.00



W88-02-0201
147型二位开关带二位13A多功能带四位USB(带指示灯)
147 two switch and double 13A MF +4USB socket (with indicator light)
¥:480.00



W88-02-0211
147型二位13A多功能带四位USB带小开关
147 type 2 13A 3pin multi-function socket + 4USB with small switch
¥:480.00



W88-02-0221
147型二位一开单控带二位10A二三极插座
147 type 2 gang 1 way switch double 10A 5 pole socket
¥:320.00



W88-02-0231
147二位开关二位16A法式插座带指示灯+USB/Type-c(小板)
147 double switch double French socket+USB/Type-c with light
¥:500.00



W88-02-0182
147 45A双极开关带指示灯
147 type 45A bipolar switch
¥:183.00



W88-02-0192
147 二位多功能插座+4USB
147 2-bit multi-function socket + 4USB
¥:326.00



W88-02-0202
147型二开带二位13A方插带四位USB
147 type two switch two position 13A square inserting band 4 USB
¥:480.00



W88-02-0212
147型二位13A方插带四位USB带小开关
147 double 13A square plug with 4USB with small switch
¥:480.00



W88-02-0222
147型二位10A二三极插座带USB+type-c
147 type double 10A 5 pole socket USB + type-C
¥:720.00



W88-02-0232
147二位开关二位16A德式插座(带指示灯)
147 two switch double 16A German socket with light
¥:190.00



W88-02-0183
147 16A二位德式插座
147 Double German socket
¥:148.00



W88-02-0193
147 二位13A方角插座+4USB
147 two bit 13A square socket +4USB
¥:326.00



W88-02-0203
147二位13A方插带四位USB
147 type double position 13A square inserting band 4 USB
¥:335.00



W88-02-0213
147 二位一开16A多功能带指示灯
147 Two switch and double 16A MF 3 pin socket with neon
¥:326.00



W88-02-0223
147型二位多功能五孔插座带USB+type-c
147 type double 5 pin multi-functional socket USB + type-c
¥:720.00



W88-02-0233
147二位开关二位16A法式插座(带指示灯)
147 two switch double 16A French socket with light
¥:190.00



W88-02-0184
147 16A二位法式插座
147 Double French socket
¥:148.00



W88-02-0194
147 一位13A方角插座+二位USB
13A square corner socket and Two USB
¥:271.00



W88-02-0204
147 二位13A多功能+4USB(带盖板)
147 double 13A multi-function + 4USB (with cover plate)
¥:380.00



W88-02-0214
147 二位13A多功能插座带4USB(带指示灯)
147 type MF 3 pin socket and 4USB with neon
¥:350.00



W88-02-0224
147型13A多功能双USB带多五孔插座
147 type 13A multi-function 2USB with 5 pin multi-functional socket
¥:389.00



W88-02-0234
147二位开关二位16A德式插座带指示灯+二位USB(小板)
147 two switch double 16A German socket + 2usb with light
¥:440.00




W88-02-0185
147 16A二位德式插座
147 Double Geman socket
¥:148.00



W88-02-0195
147 一位16A多功能插座+二位USB插座
16A MF 3 pin socket and 2USB socket
¥:271.00



W88-02-0205
147型二位13A方插带四位USB(带盖板)
147 double 13A square inserting +4USB socket
¥:380.00



W88-02-0215
147 16A多功能+万用五孔插座
147 16A MF 3 pin + 5 pin MF socket
¥:295.00



W88-02-0225
147型二位电脑插座带二位USB插座
147 type double computer with 2USB socket
¥:460.00



W88-02-0235
147二位开关二位16A法式插座带指示灯+二位USB(小板)
147 two switch double 16A French socket +2USB with light
¥:440.00



W88-02-0186
147 16A二位法式插座
147 Double French socket
¥:148.00



W88-02-0196
147型二位开关带二位多功能五孔插座带双USB
147 Two switch and double 13A 5 pin MF socket+2USB
¥:310.00



W88-02-0206
147一开单控开关带多功能五孔插座
147 1 gang 1 way switch with 5 pin MF socket
¥:274.00



W88-02-0216
147 10A二二三极插座
10A 8 pole socket
¥:310.00



W88-02-0226
147型二位电话带二位电脑插座
147 double telephone with double computer socket
¥:390.00



W88-02-0236
147 二位10A二三极五孔带4USB+小开关(带指示灯)
147 double 10A 5 pin socket+4USB two little switch with indicator light
¥:350.00



W88-02-0187
147型二位德式带USB+type-c(模块)
147 double German + USB / type-C (module)
¥:510.00



W88-02-0197
147 二位开关带二位13A多功能五孔插座+2 USB(带指示灯)
147 two switch and double 13A MF 5 pin socket + 2USB (with indicator)
¥:460.00



W88-02-0207
147 一开单控带13A方角插座+双USB
147 1 gang 1 way socket with 13A square Angle socket +2USB
¥:348.00



W88-02-0217
147二开单控开关带16A多功能插座
147 two switch single control 16A MF 3 pin socket
¥:276.00



W88-02-0227
147型 二位电脑插座带16A多功能插座
147 double computer with 16A MF pin socket
¥:333.00



W88-02-0237
147 二位一开13A多功能五孔插座带指示灯
147 two switch and double 13A MF 5 pin socket (with indicator)
¥:330.00



W88-02-0188
147型二位法式带USB+type-c(模块)
147 double French + USB / type-C (module)
¥:510.00



W88-02-0198
147 二位13A多功能五孔插座+四位USB
147 13A double 5 pin MF socket+4USB
¥:330.00



W88-02-0208
147型一开单控带15A泰式插座
147 one open single control with 15A Thai socket
¥:283.00



W88-02-0218
147型二开单控带13A方角插座
147 type double open single control socket with 13A square angle
¥:276.00



W88-02-0228
147型二位16A德式插座带防水
147 two position 16A German socket with waterproof
¥:350.00



W88-02-0238
147二位双16A法式插座带四位USB(带指示灯)
147 double 16A German socket 4 USB (with indicator)
¥:400.00




W88-02-0189
二位17A德式+二位USB(小板连体)
147 Double German with 2USB
¥:410.00



W88-02-0199
147 二位开关二位13A多功能五孔插座+四位USB
147 two switch double 5 pin MF socket+4USB
¥:460.00



W88-02-0209
147型一开单控带多功能五孔+双USB插座
147 one open single control and MF 5 pin + 2USB socket
¥:348.00



W88-02-0219
147型10A二极带10A二极插座
147 10A two pole with 10A two pole socket
¥:280.00



W88-02-0229
147型二位16A法式插座带防水
147 two position 16A French socket with waterproof
¥:350.00



W88-02-0239
147二位双16A法式插座带四位USB(带指示灯)
147 double 16A French socket 4 USB (with indicator)
¥:400.00




W88-02-0190
147二位16A法式+2USB(小板连体)
147 Double French with 2USB
¥:410.00



W88-02-0200
147型二位开关带二位多功能五孔插座带USB+type-c
147 Two switch and double 5 pin MF socket+USB/type-c
¥:500.00



W88-02-0210
147型二位10A二三极五孔带四位USB插座
147 double 10A 5 pin socket + 4 USB with indicator light
¥:440.00



W88-02-0220
147型二位一开单控带二位16A三板插座
147 type 2 gang 1 way switch double 16A three pole socket
¥:320.00



W88-02-0230
147二位开关二位16A德式插座带指示灯+USB/Type-c(小板)
147 double switch double German socket+USB/Type-c with light
¥:500.00



W88-02-0240
147型二位空白面板
147 Blank plate
¥:28.00